

# VECTOR

**USER'S GUIDE**  
for the

***VECTOR***

VB75 to VB1100S

***FLUX VECTOR***  
**DRIVES FOR STANDARD  
AC SQUIRREL CAGE  
INDUCTION MOTORS**

0.75 kW to 11 kW



### Health and Safety at Work

The voltages present in this drive module are capable of inflicting a severe electric shock, and may be lethal. It is the responsibility of the owner or user to ensure that the installation of this equipment and the way in which it is operated and maintained complies with the requirements of the Health & Safety at Work Act in the United Kingdom and applicable legislation and regulations and codes of practice in the UK or elsewhere.

Only qualified personnel should install this equipment, after first reading and understanding the information in this Guide. The installation instructions should be adhered to. Any question or doubt should be referred to the supplier of the equipment.

The manufacturer accepts no liability for any consequences resulting from inappropriate, negligent or incorrect installation, operation or maintenance of the equipment, or adjustment of the optional operating parameters, or from mismatching of the drive to the motor and driven load.

The contents of this Guide are believed to be correct at the time of printing. In the interests of a commitment to a policy of continuous development and improvement, the manufacturer reserves the right to change the specification of the product or its performance or the contents of the User's Guide without notice.

All rights reserved. No part of this book may be reproduced or transmitted in any form or by any means, electronic or mechanical including photocopying, recording, or by any information storage or retrieval system without permission from the publisher in writing.

Copyright © 1998 Control Techniques plc

USER'S GUIDE -- VECTOR/VB  
Part No. **0433-0001**  
Issue No 3 — May 1998  
SOFTWARE VERSION V8.X.X

# **USER'S GUIDE**

for the

## *VECTOR*

**VB75 to VB1100S**

## *FLUX VECTOR*

**DRIVES FOR STANDARD  
AC SQUIRREL CAGE  
INDUCTION MOTORS**

**0.75 kW to 11 kW**

## Contents


	Page
<b>Features of the VECTOR range of drives</b>	4
<b>1 Introduction</b>	5
<b>2 Data</b>	6
2.1 General Specifications	6
2.2 Ratings	7
2.3 Derating	7
2.4 Losses and Cooling	7
2.5 Ventilation	8
2.6 Encoder Specification	8
<b>3 Installation — Mechanical</b>	9
3.1 Mounting	9
3.2 Cooling and Ventilation	9
<b>4 Installation — Electrical</b>	12
4.1 Introduction	13
4.2 Power Connections	13
4.3 Fuses and Power Cabling	14
4.4 Guide to Line Choke Sizes	14
4.5 Control Connections	15
4.6 Terminals	17
4.7 Braking Resistors	18
<b>5 Operating Procedures</b>	19
5.1 Keypad and Display	19
5.2 Manipulation of Parameters	19
5.3 Security Code	21
<b>6 Commissioning</b>	22
6.1 Commissioning — Safety	23
6.2 Motor Map	23
6.3 Fine Tuning	27
6.4 Protection	28
6.5 Diagnostics — Fault Finding	28
— Healthy Indications	29
— Trip Codes and Error Codes	30
<b>7 Parameters</b>	31
7.1 Parameters, Values and Function	31
7.2 Numerical Parameters — R-W	32
7.3 Numerical Parameters — R-O	40
7.4 Bit Parameters — R-W	42
7.5 Bit Parameters — R-O	46
7.6 Index of Parameters — Numerical Parameters	49
— Bit Parameters	50
— System Logic Diagram — following page	50
<b>8 Serial Communications</b>	51
<b>9 Braking</b>	59
<b>10 Electromagnetic Compatibility (EMC)</b>	64

## Illustrations

<b>Fig.</b>		<b>Page</b>
1	<i>VECTOR</i> Drive System Schematic Diagram	5
2	Locations of principal components	8
3	Dimensions of <i>VECTOR</i> drives	10
4	Mounting — Minimum Clearances	11
5	Typical Enclosure, Heat Dispersal	11
6	Power Connections	12
7	Control Connections	15
8	Terminals — Layout	16
9	External Braking Resistor — Connections	18
10	Keypad	19
11	Parameter Manipulation	20
12	System Control Overview	22
13	Multidrop Link and Serial Address	52
14	RS485/RS422 Connections	52
15	RS232 Connections	52
16	External Braking Resistor — Connections	60
17	Resistor Cooling Curves (typical)	62
	SYSTEM LOGIC DIAGRAM	Following page 50

## **FEATURES of the VECTOR RANGE**

- **VECTOR** drives have been designed in "bookshelf" format to optimise cubicle space when utilised in multiple drive systems.
- **VECTOR** drives are designed to operate standard 3-phase induction motors and special high-frequency motors fitted with encoders.
- Insulated gate bipolar transistor (IGBT) inverter output bridge for high speed switching and low power consumption
- Digital control of the output bridge by micro-processor.
- Internal control power provided by switch-mode power supply (SMPS) giving regulated control voltage for a wide range of input voltage.
- Choice of four PWM output switching frequencies to match applications.
- Acceleration and deceleration with programmable ramps.
- Full torque at zero speed.
- Constant-speed control at varying loads.
- Independent control of torque and speed from zero.
- Rapid dynamic response.
- Start on to a spinning motor.
- Full PID control.
- Dynamic braking with on-board power resistor as standard.
- Internal monitoring and protection includes  $I \times t$  overload, current limit, instantaneous short circuit, earth fault and heatsink overtemperature protection.
- External motor-protection inputs from thermistor and/or thermal relay.
- Parameter and diagnostic data saved during power loss for fault diagnosis and quick restart without reprogramming in the event of a trip.
- Parameter data input fully digital. No potentiometers and no links to adjust.
- A range of analog input and output signals for compatibility with non-digital equipment and systems.
- Control circuits impedance-isolated from power circuits.
- Serial communications interconnection standard RS485. Software protocol standard ANSI x 3.28-2.5-A4.
- Plug-and-socket connection of power and control wiring ensures rapid and reliable disconnection and reconnection of drives.



CONTROL TECHNIQUES DRIVES LTD  
79 MOCHDRE INDUSTRIAL ESTATE  
NEWTOWN, POWYS SY16 4LE

### **DECLARATION OF CONFORMITY**

The AC variable speed drive product bookcase Vector power range 0.75kW - 2.2kW and 4.0kW-7.5kW, and 11.0kW, has been designed and manufactured in accordance with the following European harmonised, national and international standards:

EN60249	Base materials for printed circuits
IEC326-1	Printed boards: General information for the specification writer
IEC326-5	Printed boards: Specification for single and double sided printed boards with plated through holes
IEC326-6	Printed boards: Specification for multilayer printed boards
IEC664-1	Insulation co-ordination for equipment within low-voltage systems: Principles, requirements and tests
EN60529	Degrees of protection provided by enclosures (IP code)
UL94	Flammability rating of plastic materials

This product complies with the Low Voltage Directive 73/23/EEC and the CE Marking Directive 93/68/EEC.

W. Drury  
Technical Director

Newtown  
Date: 13 January 1997

#### Note

This electronic drive product is intended to be used with an appropriate motor, controller, electrical protection components and other equipment to form a complete end product or system. It must only be installed by a professional assembler who is familiar with requirements for safety and electromagnetic compatibility ("EMC"). The assembler is responsible for ensuring that the end product or system complies with all the relevant laws in the country where it is to be used. Refer to the product manual or EMC data sheet for further information on EMC standards complied with by the product, and guidelines for installation.

Steve Leyland  
13/01/97

Rev.0  
Issue C

## VECTOR ADDENDUM for Issue2 Manual

### MODULE DIMENSIONS (PAGES 6 AND 10)

NEW PACKAGE DIMENSIONS (mm)

	VB75 - VB200	VB400 - VB1100S
WIDTH	78.5	127
HEIGHT	352	352
DEPTH	323.5	328.5

### EARTHING (PAGE 13)

The Protective Earth connection is now an Earth lug on the top of the drive casing. The connection marked **Y** on the main power connector is now used for connection of varistors to earth for transient voltage protection. This in not recommended for grounded Delta systems and this terminal is no longer the protective earth.

### EXTERNAL BRAKING RESISTORS (PAGE 18)

#### VB75 - VB200.

An extra power connector has been added on top of the case to allow access to the DC Link and Dynamic Braking connections for DC bus paralleling and applications requiring external Braking resistors.

The Terminal connections are as follows:-

- 1 +DC bus.
- 2 Not Connected.
- 3 INTERNAL braking resistor.
- 4 Not Connected.
- 5 EXTERNAL braking Resistor.
- 6 Not Connected.
- 7 -DC bus.

#### VB400 - VB1100S

A removeable Link has been fitted at the bottom of the case to allow disconnection of the internal braking resistor, existing terminals already allow for connection of an external braking resistor and access to the DC bus.



## Hardware Addendum For D'Ax 0.75kW to 11kW

### Braking Resistor Protection

In applications which require the use of braking resistors, the braking duty cycle must be carefully considered. If the resistor is under-specified for the application, the power dissipated will cause the resistor to overheat, leading to damage to the resistor and the drive increasing the risk of fire. Use of thermal overload protection relays can provide a means of either tripping the power to the system if the duty cycle is exceeded, or sending a signal to a controlling PLC. The relays do not actually try to break the DC current.

Need to specify:


$P_{max}$	-	maximum power dissipation
$t_{max}$	-	maximum time for $P_{max}$ dissipation
$R$	-	total braking resistance
$V_{dc}$	-	max d.c. link voltage

During the period of dissipation, the average current through the resistor is given by:

$$I_{ave} = \frac{P_{max}}{V_{max}}$$

where;  $V_{max}$  = maximum DC link voltage.

The braking control of the drive actually uses a chopper transistor to switch in the resistor, so the actual current waveform in the resistor similar to that shown below.



where:

$$I_{pk} = \frac{V_{max}}{R}$$

The duty cycle of the transistor is given as:

$$D = \frac{I_{ave}}{I_{pk}} = \frac{t_{on}}{t_{on} + t_{off}}$$

The RMS current in the resistor can now be calculated by:

$$I_{rms} = \sqrt{I_{pk}^2 * D}$$

The relay should be set up for the expected RMS current in the resistor and the value of  $t_{max}$ .

Worked Example 1: Specify a thermal overload for use with a DB140 using its internal resistor. The application is working the resistor close to its maximum specification of 1.5kW for 10 seconds, with 90 seconds cooling time. The nominal resistance is 80Ω.

Data:

$P_{max} = 1.5kW$   
 $t_{max} = 10 \text{ seconds}$   
 $R = 80\Omega$   
 $V_{dc} = 750V$

Since the continuous rating of the resistor is 150W the average current must be limited to

$$\sqrt{\frac{150}{80}} = 1.369 \text{ Amps}$$

$$I_{pk} = \frac{750}{80} = 9.375 \text{ Amps}$$

$$\text{Duty} = \frac{1.369}{9.375} = 0.146$$

$$I_{rms} = \sqrt{9.375^2 \cdot 0.146} = 3.582 \text{ Amps}$$

$$I_{set} = \frac{3.582}{4} = 0.895 \text{ Amps}$$

This is the current that must be set on the relay so relay type LR2-D1306 (1.0A to 1.6A) should be used.

The short circuit condition will overload the relay by a factor of 8.5, and this will cause the relay to trip out after approximately 4 seconds.

The diagrams below cover the following drives

Vector	CDE	Digitax	Spindax
VBE400	CDE400	DBE420	SA010
VBE550	CDE550	DBE600	SA016
VBE750	CDE750	DBE750	SA022
VBE1100S	CDE1100S	DBE1100S	

### Electrical Installation

The following diagrams show how to connect the relay to protect the internal resistor for the drives stated, or external resistors if used.





The previous diagrams refer to the following drives:

Vector	CDE	DigitAx	SpindAx
VBE75	CDE75	DBE140	SA005
VBE110	CDE110	DBE220	
VBE150	CDE150		
VBE220	CDE220		

The normally closed contacts 95 and 96 should be connected in series with the line contactor coil.

# 1 Introduction

## The VECTOR Drive for Standard Squirrel-cage Induction Motors


VECTOR has been developed to operate standard run-of-production squirrel-cage motors. The performance of the VECTOR with *standard* motors is comparable to the performance achieved with more costly motors specifically designed for flux vector drive control.

True flux vector control requires a feedback so that the rotor position can be monitored continuously. An incremental encoder on the motor shaft is essential for this purpose ( $E_F$  in Fig. 1). It is usually fitted at the non-drive end and is a simple modification. The feedback encoder, the VECTOR drive and the motor thus become a true closed-loop system, able to give precise control of torque and speed.

Although the function of the feedback encoder is primarily to transmit the rotor position to the drive logic, the same signal is utilised for motor speed sensing by measuring the rate of change of position of the rotor. An additional and separate tachogenerator is not necessary for this purpose.

Standard squirrel-cage induction motors are primarily single-speed machines. The VECTOR drive can operate standard motors at speeds from zero up to 6000rpm. Further, *maximum torque* is available from base speed down to zero speed. In applications where motor speeds below base speed will be used, motor cooling must be considered in relation to the speeds and torque outputs involved. For high speed applications above base speed, the quality of rotor balance and bearing type should be specified.

If there is any doubt about an application which is to involve low-speed or high-speed operation, it is advisable to consult the supplier of the motor for practical advice.



## 2 Data

### 2.1 General Specifications

#### Physical Dimensions

Refer also to Figs. 2 and 3.

Module type	Module height mm	Width max mm	Depth including heat sink mm	Vertical fixing centres mm
VB75-VB220	340.0	75.0	325.0	357 (372*)
VB400-VB1100S	340.0	125.5	325.0	357 (372*)

\*When fixing brackets are positioned for through-panel mounting — Figs. 2 and 3.

#### Ingress Protection (IP) Enclosure

VECTOR drives are constructed in accordance with IP20 specification. Internal cooling fans (where fitted) for the heatsinks conform to IP20.

#### Power Supply

Balanced 3-phase 50Hz or 60Hz, 380V -10% to 460V +10%. Supply frequency tolerance 48Hz to 62Hz.

#### Inverter Output

The three phase balanced output can produce up to  $\pm 6000$ rpm with 2-, 4-, 6- or 8-pole motors. Maximum output voltage is nominally equal to the input (line) voltage.

#### Ambient Temperature and Humidity

Ambient temperature range -10°C to +50°C.

Storage temperature range -40°C to +50°C for one year maximum.

Humidity — non-condensing.

#### Derating

Nominal ratings are affected by —

- The altitude of the installation. Where the site is above 1000m, reduce the normal full load current by 1% for each additional 100m.
- The ambient temperature. The drive should be installed where the maximum ambient temperature will not be exceeded due to heat generated by other apparatus nearby.
- Use of the higher PWM switching frequencies — refer to 2.2 Ratings and Derating.

#### Starts per Hour

Motor according to manufacturer's recommendations. Drive limited to 10 starts per hour if started by switching the supply. If the motor is started only by electronic control of the drive, the number of starts per hour is unlimited for the drive.

#### PWM Switching Frequencies

Constant switching frequency selectable from four values — 3.0kHz, 6.0kHz, 9.0kHz or 12.0kHz.

## 2.2 Ratings

<i>Module type</i>	<i>Motor power</i> kW	<i>Maximum continuous current output</i> A	<i>Input current</i> A	<i>Input at 415V</i> kVA	<i>Output at 415V</i> kVA
VB75	0.75	2.1	3.4	2.4	1.5
VB110	1.1	2.8	4.5	3.2	2.0
VB150	1.5	3.8	5.5	4.0	2.7
VB220	2.2	5.6	8.7	6.3	4.0
VB400	4.0	9.5	13.2	9.5	6.8
VB550	5.5	12.0	13.5	9.7	8.6
VB750	7.5	16.0	16.7	12.0	11.5
VB1100S	11	22*	23.4	17	16

\* See under 2.3 - Derating

## 2.3 Derating

- Modules VB75 to VB750 inclusive can achieve the rated output currents shown in the Ratings table above, without derating, in a 50°C ambient temperature and 12 kHz Switching Frequency.
- Module VB1100S at 12 kHz Switching Frequency can only achieve rated output current, without derating, in a 40°C ambient temperature.
- If module VB1100S must operate in a 50°C ambient temperature, derate as follows —  
*Switching frequency 9 kHz*      20 A *maximum continuous current output*  
*Switching frequency 12 kHz*      17 A *maximum continuous current output*

## 2.4 Losses and Cooling

N = Natural circulation

F = Integral cooling fans fitted

<i>Module type</i>	<i>Losses</i>		<i>Cooling</i>
	<i>3.0 kHz PWM</i> W	<i>12.0 kHz PWM</i> W	
VB75	45	80	N
VB110	50	110	N
VB150	60	140	N
VB220	90	170	N
VB400	130	280	F
VB550	170	370	F
VB750	220	410	F
VB1100S	260	470	F

## 2.5 Ventilation

VECTOR drives do not require external fans. Cooling fans for the heat sinks are built into those modules that require them.

VECTOR drives may be installed in an enclosure, but care must be taken to ensure that —



- the drive module is mounted vertically;
- adequate air space is provided within the enclosure to allow for correct air flow over the heatsink cooling fins.
- adequate clearance for air flow is provided above and below each module, Fig. 4, page 11.

## 2.6 Encoder Specification

Incremental shaft position encoder, 5V, 200mA, 1024 pulses per revolution (ppr), TTL differential line driver.

It is recommended that the encoder is connected by overall-screened cable having individually-screened pairs.

For a cable exceeding 150m in length it will probably be necessary to arrange an external supply for the cable because of the voltage drop due to the cable length. It may also be necessary to arrange a local power supply close to the encoder.





## 3 Installation — Mechanical

### 3.1 Mounting

*VECTOR* drives are to be installed only in a vertical position, to ensure the best flow of air for the cooling fins of the heat sink. Installation vertically above other drives or any heat-producing equipment may result in overheating.

#### Location

The installation should be located in a place free from excessive dust, corrosive vapours, gases and all liquids.

Care must also be taken to avoid condensation of vaporised liquids, including atmospheric moisture. If the drive is to be located where condensation is likely to occur when the drive is not in use, a suitable anti-condensation heater must be installed. The heater must be switched OFF when the drive is energised. An automatic changeover switching arrangement is recommended.

*VECTOR* drives are not to be installed in classified hazardous areas unless correctly mounted in an approved enclosure and certified. (Refer also to HAZARDOUS AREAS, Chapter 4 Section 1.)

#### Fixing brackets

Two alternative arrangements are provided for in the design of *VECTOR* drives:

Either —

- the drive may be mounted on an open panel or wholly within a cubicle, in which case the fixing brackets are located in position A, Fig. 3 Page 10,

or —

- the heat sink may project through the mounting panel into a free air space behind, in which case the fixing brackets are located in position B.

The fixing brackets are attached to the material of the heat sink or to the frame of the drive by two screws each. Self-tapping screws are provided, to ensure good earth connection to the supporting framework or cubicle which should itself be bonded to earth in accordance with good practice.

Where two or more drives are to be installed side-by-side there must be a gap, 3mm minimum, between adjacent modules to facilitate removal of the the front terminal cover, Fig. 4 page 11.

### 3.2 Cooling and Ventilation

#### The Drive Enclosure


*VECTOR* drives are protected from damage caused by overheating. A thermal sensor is mounted on the heat sink. If the temperature rises to 95°C, the drive trips automatically. This setting is not adjustable.

Cubicle-mounted *VECTOR* drives can be mounted either wholly enclosed, or with the heat sink projecting through the rear panel. Through-panel mounting allows for physical segregation between the control section of the drive and the power electronics, enabling the heat-producing (power) section to dissipate heat without affecting the temperature within an enclosure.

This may be an advantage when a number of drives are to be enclosed in a single cubicle. In any case, cubicle size must be verified by calculation to ensure that there is adequate space to allow free circulation of the air within an enclosure. All equipment in the enclosure must be taken into account in calculating the internal temperature. Installation vertically above other drives or any heat-producing equipment may result in overheating.

As standard, all models of *VECTOR* drives are equipped with an on-board braking resistor. For special applications, some servo systems may require braking capacity in excess of the standard. **A larger braking resistor can be connected** (models VB400, VB550, VB750 and VB1100S only) **externally to the drive. The on-board resistor must be disconnected (it is essential to consult the supplier of the drive in this case).**

When an external resistor is fitted it is vitally important to take account of the increase in heat generated. It is recommended that the external resistor should be mounted where its heat losses cannot affect the drive.



### To find the dimensions of an enclosure

If a cubicle is to be fabricated to suit the installation, there is a free choice of dimensions. Alternatively, it may be decided to choose a cubicle from a range of standard products. Either way, it is important to take into account the dimensions of the drive module, and to ensure adequate clearance for air circulation.

The procedure is to estimate two of the dimensions — the height and depth, for example — then calculate the third, and finally check that it allows adequate internal clearance.

The effective surface area  $A_e$  for an enclosure, Fig. 5, containing equipment which generates heat is calculated from the following equation —

$$A_e = \frac{P_l}{k(T - T_{amb})}$$

where

$A_e$  = Effective heat-conducting area in  $m^2$ , equal to the sum of the areas of the surfaces which are not in contact with any other surface.

$P_l$  = Power loss of all heat-producing equipment in watts.

$T$  = Maximum permissible operating temperature of the drive module in  $^{\circ}C$ .

$T_{amb}$  = Maximum external ambient temperature in  $^{\circ}C$ .

$k$  = Heat transmission coefficient of the material from which the enclosure is made.

The effective heat-conducting area of a cubicle typically located on the floor and against one wall, is —

$$A_e = 2AB + AC + BC$$

where A is the cubicle height, B is the depth, front to back, and C the width, Fig. 5.

Suppose the cubicle height  $A$  is 1.8m, and the depth  $B$  is 0.5m, as a first estimate. The actual figures chosen in practice will be guided by available space, perhaps, or standard enclosure sizes.


Since  $A_e$  can be found, and  $A$  and  $B$  are known, the dimension to be calculated is  $C$ . The equation needs to be rearranged to enable  $C$  to be found, thus —

$$A_e - 2AB = C(A + B)$$

$$\text{or — } A_e = \frac{A_e - 2AB}{A + B}$$

If an enclosure is to be selected from a stock catalogue, the corresponding surface area should be not less than the figure calculated above for  $A_e$ .

As a general rule, it is better to locate heat-generating equipment low in an enclosure to encourage internal convection and distribute the heat. If it is unavoidable to place such equipment near the top, consideration should be given to increasing the dimensions of the top at the expense of the height, or to installing internal 'stirrer' fans with drive modules which have no fans of their own to ensure air-circulation.



#### Enclosure ventilation

If a high IP rating is not a critical factor, the enclosure can be smaller if a fan is used to exchange air between the inside and the outside of the enclosure.

To calculate the volume of ventilating air,  $V$ , the following formula is used —

$$V = \frac{3.1 \times P_l}{T - T_{amb}}$$


- where
- $V$  = Required air flow in  $\text{m}^3 \text{h}^{-1}$
  - $A_e$  = Effective heat-conducting area, in  $\text{m}^2$ , equal to the the sum of the areas of the surfaces which are not in contact with any other surface.
  - $P_l$  = Power loss of all heat-producing equipment in Watts.
  - $T$  = Maximum permissible operating temperature of the drive module in  $^{\circ}\text{C}$ .
  - $T_{amb}$  = Maximum external ambient temperature in  $^{\circ}\text{C}$ .


#### The Motor

The VECTOR range of drives is capable of operating induction motors at speeds below the speed for which they are intended when driven from a fixed-frequency supply. Normally, the cooling of the motor is dependent on a shaft-mounted internal fan. This rapidly loses its effectiveness when operating at speeds below the normal near-synchronous speed of operation.

Designers intending to make full use of the benefits of variable speed control should give careful consideration to the possible need for supplementary cooling (by an external air supply, for example) if the application is one that requires periods of operation at reduced speed, or prolonged acceleration times at full torque.

Most manufacturers of standard induction motors are able to provide guidance, as is the supplier of VECTOR drives.





## 4 Installation — Electrical

### 4.1 Introduction

#### SAFETY

The voltages present in the supply cables, the output cables and terminals, the externally-mounted DC link choke, the external braking circuit if fitted, and within certain parts of the inverter are capable of causing severe electric shock and may be lethal.

#### IP Rating

The drive enclosure conforms to international enclosure specification IP20. It is therefore necessary to consider the location of and access to the module in the light of local safety regulations applicable to the type of installation.

#### ***ELECTRIC SHOCK RISK!***

Whenever the inverter has been energised, it **MUST** be ISOLATED. A period of seven minutes **MUST** elapse after isolation to allow the DC link choke and internal capacitors to discharge fully. Until the discharge period has passed, dangerous voltages may be present at the terminals and within the module.

Persons supervising and performing electrical installation or maintenance must be suitably-qualified and competent in these duties.

#### Hazardous Areas

The application of variable speed drives and soft starters of all types may invalidate the hazardous area certification (Apparatus Group and/or Temperature Class) of Ex-protected squirrel cage induction motors. Approval and certification should be obtained for the complete installation of motor and drive. (Please refer also to LOCATION, Chapter 3 Section 1.)

#### Earthing

The drive must be connected to the system earth by the earth terminal provided on the power terminal block, Fig. 6.

Earth impedance must conform to the requirements of local industrial safety regulations and should be inspected and tested at appropriate and regular intervals.

Control cable screens should be terminated to a 0V terminal, Connector B3, *at the drive end only*, to minimise the possibility of interference.

### 4.2 Power Connections

Refer to Figs. 6 and 8.

The power terminals are located on the upper surface of the module. The terminals for the control circuits are on the front, protected by a removable cover. This arrangement enables the power cables to be run in from above the module and the control wiring from below, with the advantage that the two are well-separated, for the avoidance of interference with control signals. For cable sizes, refer to page 14.

#### Protection

The drive must be protected on the supply side either by hrc fuses (refer to 4.3 below and Fig.6) or by suitably-rated MCB or MCCB switches equipped with thermal and magnetic trips.

#### Power Circuit Earthing

Earth cable runs should be as short as possible. Earth loop impedance should be verified in accordance with the applicable approved code of practice and local regulations.

Screened cable may be used for the output cabling to the motor. Screening should be connected to earth at Connector 'A'.

### 4.3 Fuses and Power Cabling

<i>Module type</i>	<i>* Recommended fuse ratings at 380V</i>	<i>† Typical cable size</i>
	<b>A</b>	<b>mm<sup>2</sup></b>
VB75	6	1.0
VB110	6	1.0
VB150	10	1.5
VB220	10	1.5
VB400	16	2.5
VB550	16	2.5
VB750	20	2.5
VB1100S	35	4.0

\* As a current peak may appear at power-on because of the effect of the DC link capacitor, the use of 'slow' fuses is recommended. As an alternative to fuses, mcbs or mccbs may be used if equipped with adjustable thermal and magnetic trip devices of a suitable rating.

† The cable sizes are for 3-core and 4-core pvc-insulated armoured cable rated at 600V AC (1000V DC) and laid in accordance with the maker's defined conditions.

### 4.4 Guide to Line Choke Size

Installations with long cable runs to the motor may require the addition of line chokes (inductors) to prevent spurious overload tripping of the drive.

The table shows cable lengths above which chokes of 1mH or 2mH, rated according to motor size, may be typically required.


<i>Module type</i>	<i>Choke Value</i>		<i>Current Rating</i>
	<i>1mH</i>	<i>2mH</i>	
	<b>m</b>	<b>m</b>	<b>A</b>
VB75	30	90	5
VB110	40	125	5
VB150	50	145	5
VB220	60	165	9
VB400	80	200	9
VB550	140	300	20
VB750	140	300	20
VB1100S	200	400	25


## 4.5 Control Connections

Refer to Figs. 7 and 8.

The control system wiring should be 0.5mm<sup>2</sup>, screened overall. The screen should be connected to 0V at the drive end only. Control cables and encoder and digital reference cables should be segregated from the power cables. If they have to cross, they should do so at right-angles. Contactor, solenoid and brake coils should be fitted with RC suppressors or the equivalent. Please refer also to Encoder Specification, page 8, and Electromagnetic Compatibility, Chapter 10.

For the RS485 serial link, twisted-pair cables should be used. Serial link connections are illustrated in Figs. 14 and 15, page 52.







## 4.6 Terminals

Refer to Fig. 8.

### Power Terminals Models VB75, VB110, VB150, VB220

No	Function	Type	Description
A1	Phase U	out	Output to motor
A2	Phase V	out	
A3	Phase W	out	
A4	Earth		Frame earth common
A5	Line 1 (R)	in	Power supply input
A6	Line 2 (S)	in	
A7	Line 3 (T)	in	

### Power Terminals Models VB400, VB550, VB750, VB1100S

No	Function	Type	Description
A1	Phase U	out	Output to motor
A2	Phase V	out	
A3	Phase W	out	
A4	Earth		To system earth
A5	Line 1 (R)	in	Power supply input
A6	Line 2 (S)	in	
A7	Line 3 (T)	in	
A8	DC bus negative pole		
A9	External braking resistor		
A10	DC bus positive pole		

### Control Terminals

No	Name & Function	Description
B1	ENABLE	0 to 24V at 1mA — Connect to 0V to RUN
B2	Programmable channel 2	INPUTS 0 to 24V at 1mA
B3	Programmable channel 1	
B4	Programmable channel 0	
B5	Programmable channel 2	OUTPUTS 0 to 24V at 1mA with 50mA sink and source capability
B6	Programmable channel 1	
B7	Programmable channel 0	
B8	24V 50mA	OUTPUT
B9	0V	
B10	Analog channel 2	OUTPUT channels 5mA maximum
B11	Analog channel 1	
B12	0V	
B13	Analog channel 4	INPUT, 10-bit resolution channels, 100kΩ impedance
B14	Analog channel 3	
B15	-10V 10mA	
B16	Analog channel 2	INPUT, 12-bit resolution channels, 100kΩ impedance
B17	Analog channel 1	
B18	+10V 10mA	

### Encoder Terminals

B19	C	MARKER PULSE
B20	C	
B21	B	B CHANNEL
B22	B	
B23	0V	
B24	5V 200mA	
B25	A	A CHANNEL
B26	A	

### Serial Link Terminals, RS485

Please refer also to Figs. 13 and 14 Chapter 8.

#### Connector C

1	0V
2	TX
3	RX
4	
5	
6	TX
7	RX

## 4.7 Braking Resistors


Module type	Resistor size	Maximum regenerative power
VB75 VB110 VB150	80Ω, 150W	1.5kW for 10s, continuous rating, with a minimum cooling time of 90s.
VB220 VB400 VB550 VB750 VB1100S	40Ω, 300W	3.0kW for 10s, continuous rating, with a minimum cooling time of 90s.

## External Braking Resistor Connections

Refer to Fig. 9.

ON the larger *VECTOR* drives, (VB400, VB550, VB750 and VB1100S), provision is made to fit an external resistor of higher rating than the standard on-board resistor for increased dynamic braking performance. To protect the installation from the risk of damage it is essential that —

- The internal resistor is disconnected. For this it is essential to consult the supplier of the drive.
- The external resistor is fitted with a thermal protection relay, wired to trip the supply contactor.



## 5 Operating Procedures

### 5.1 Keypad and Display


The Control Pod, Fig.10, combines keypad and display functions. All operational functions of the drive and motor can be controlled and all parameter values can be changed from the keypad. Parameters and their values are adjusted by the three keys, which control the parameters in two modes —

- selecting** a parameter number  
(mode LED illuminated)
- and
- changing** a parameter value  
(mode LED illuminated).

Motor start, stop and reverse operations can be directly controlled from the keypad, which holds all control parameters.

Parameter identity numbers or parameter values, as appropriate, are shown in the four-window display. The display indicates when a value is negative by a negative sign in a display window.

When parameters are not being read or changed, or after 8 seconds without a keystroke, the display defaults to the Present Indication. The following description of the method of manipulation of the parameters is illustrated by Fig. 11.



10 VECTOR keypad.

### 5.2 Manipulation of Parameters

Refer to Fig. 11

#### To SELECT a Parameter Number

The MODE key enables a parameter number to be selected. When the MODE key is pressed the green LED above the MODE key is illuminated and the number of the last parameter to have been read or changed is displayed. The parameter number alternates with its present value. If a keystroke is not made within 8 seconds, the display will default to the Normal Indication of the output of the drive, as shown in Fig. 11.


With the Mode LED illuminated, press the UP or the DOWN key once to select the NEXT parameter. To scroll through parameter numbers either press UP or DOWN repeatedly, or press and hold for fast scrolling.

If a further keystroke is not made within 8 seconds, the display will default to the Normal Indication. To return to the parameter previously selected, press MODE again.

The sequence of parameters is continuous, as shown in Fig. 11, to facilitate quick selection. For example, if the last parameter selected was b80 and the next required is Pr10, it is not necessary to scroll all the way down though b00; scroll up, through b99 and Pr00.

#### To READ a Parameter Value

Select a parameter as above. The display will show the number, alternating with the present value, of whichever parameter was last read or changed. (If a further keystroke is not made within 8 seconds, the display will default to Normal Indication.) If a different parameter is required, press UP or DOWN.



11 Parameter manipulation

**To CHANGE a Parameter Value**

Parameter values cannot be changed from the keypad if the drive is in the TRIP condition. The display must show either **rdY**, if the drive is stopped, or the present value of speed if it is running.

**NOTE** — If a Security Code has been assigned it is not possible to **change** any R/W parameter values until the correct code has been entered. Write the correct security code number and press **MODE**, then continue. (Any parameter can be **read** without need for the Security Code.) For the procedure for assigning and changing a Security Code, see below.

**Select** a parameter as above. When the required parameter is seen in the display, press **MODE** once. The display will hold the parameter value steady. If a further keystroke is not made within 8 seconds **and** if the parameter is read/write (R/W), the display will default to Present Indication.

**Change** the parameter value by pressing the UP or the DOWN key. A single keystroke changes the value by plus or minus one unit. Press either key repeatedly, or press and hold, to increase or decrease the parameter value to the maximum or minimum available.

For most parameters, a change of value acts immediately on the internal setting. For others, the drive must be powered-down and up again to give effect to a new value, or a Software Trip (**b01**) performed; these parameters are marked by the symbol \* in the parameter descriptions starting at page 31, and in the Indexes of Parameters, pages 49 and 50.

**Decimal Values**

The display operates an automatic floating decimal point. According to the range of values of the parameter, the display inserts a decimal point appropriately.

For example, the range of **Pr13** is +0.1 to +8.0pu. The display will therefore show all values between 0.1 and 8.0 with a resolution of 0.1. The range of **Pr44** is +3.50 to +31.99 rad s<sup>-1</sup>. The values displayed will therefore range from 3.50 to 31.99, with a resolution of 0.01.

**Negative Values**

Reducing a parameter value past zero makes it negative. A negative value is indicated by a negative sign '-' appearing in the window to the left of the value displayed. Any parameter which cannot possess a negative value will not reduce below zero.

**PRESENT INDICATION**

When parameters are not being read or adjusted, the display shows either drive status or running performance, thus —

DRIVE CONDITION	DISPLAY
Healthy and stopped	Either <b>rdY</b> or any selected R-O parameter value.
Healthy and running	Either speed in rpm ( <b>Pr70</b> ). or any selected R-O parameter value.
Tripped	Trip Code( flashing), refer to Chapter 6 page 23.


**DISPLAY FLASHING**

The display flashes when one of the following conditions is present —

- The drive has tripped. A Trip Code is displayed.
- All unused decimal points flash to indicate when the drive output has entered the I x t overload region.
- During installation and commissioning a flashing display may indicate that the feedback encoder connections are incorrect relative to the direction of rotation of the motor.

**5.3 Security Code**

To assign or to change a code number, select **b21** and change to **b21 = 0**. Press **MODE**. This permits access to write a code number. Select **Pr25**. Enter any number from 100 to 9999. Set **b26 = 0** to store (save) the code number.



## 6 Commissioning

### 6.1 Commissioning — Safety

Before proceeding with commissioning of the drive, the user **MUST...**

- ENSURE THAT mechanical installation is complete.
- ENSURE THAT electrical installation is complete.
- ENSURE THAT the motor is of the correct size and rating, and is securely fixed on its mountings.
- ENSURE THAT the feedback encoder connections are correct.
- ENSURE THAT the 'Drive Enable' control connection, terminal B1, is disconnected at this stage, Figs. 7 and 8, AND that the motor is **disconnected and isolated**.

### 6.2 The Motor Map

Before a VECTOR Drive can be used, values must be assigned to the five parameters of the Motor Map, **Pr41, Pr42, Pr43, Pr44 and Pr45**. These are the parameters that programme the drive to know the fundamental characteristics of the motor it will operate. This information must be entered, and should be accurate to 10% or better, otherwise the power control will be inappropriate and the motor response may be affected adversely.

**Motor full load current (FLC), Pr41**, is obtained from the motor rating plate. It is the vector sum of the fixed magnetising current and the variable, torque-producing active current.

**Motor magnetising current, Pr42**, is the current drawn by the motor for excitation of the field. If the value entered is not correct, the motor will either be wastefully over-excited or, if under-excited, will be unable to produce full torque. The magnetising current value is best obtained from the manufacturer of the motor. Alternatively, it is possible to measure it directly if the motor can be mechanically disconnected and run at no load and at the voltage and frequency stated on the rating plate.

As a first estimate, the magnetising current can be derived from the motor power factor,  $\cos\phi$ , using the formula —

$$I_m = I_{FLC} \times \sqrt{[1 - (\cos\phi)^2]}$$

where  $I_m$  = motor magnetising current  
and  $I_{FLC}$  = motor full load current

**Base frequency, Pr43**, is the frequency at which full (rated) voltage is delivered to the motor. In a conventional installation without a variable speed drive this is the frequency of the supply for which the motor was designed.

**Motor full load slip, Pr44**, in radians per second, is calculated from the full-load speed and the no-load speed. It is recommended that the manufacturer of the motor should supply the figures, but measured

## 6 - Commissioning

VECTOR

values can be used if the measurements can be made with reasonable accuracy. The value of Pr44 is calculated from —

$$\text{Pr44} = 0.0525p (N_o - N_f)$$

where  $N_o$  = motor speed at no load  
 $N_f$  = motor speed at full load  
 and  $p$  = number of poles

**Number of motor poles, Pr45**, allows for the operation of motors of two, four, six, and eight-pole construction. A default value, 4-pole, is installed in the software.

### IMPORTANT NOTE

To implement (save) new or changed values written for parameters Pr41, Pr42, Pr43, Pr44 and Pr45, set b26 = 0.

### EXAMPLE

#### Calculation of values for the Motor Map

NOTE — ANY INTENDED EXTERNAL 'ENABLE' CONTROL CIRCUIT MUST BE DISCONNECTED FROM TERMINAL B1, Figs. 7 and 8.

Power the drive up. Set Keypad Display Mode Selector Pr49 = 1 to enable the Motor Map parameters to be displayed and accessed.

For this example, the following are assumed to be the operational data —

- Power supply 415V
- Motor data as shown in the typical rating plate below

**Pr41 Motor Full Load Current**  
 From rating plate, 380V delta connection,  
 FLC = 9.1A  
Scroll to 9.1

**Pr42 Motor Magnetising Current**  
 Using the formula —

$$\begin{aligned} I_m &= I_{FLC} \times \sqrt{1 - (\cos\phi)^2} \\ I_{FLC} &= 9.1A \\ I_m &= 9.1 \times \sqrt{1 - (0.90)^2} \\ &= 9.1 \times 0.4395 \\ &= 4.0A \end{aligned}$$


Scroll to 4.0

**Pr43 Motor Base Frequency**

The drive is to be supplied at 415V, but the motor is rated 380V. To avoid over-fluxing the motor the V/f ratio must be adjusted to compensate.

$$\begin{aligned} \text{Pr43} &= \frac{\text{Supply Voltage}}{\text{Motor Voltage}} \times \text{Motor Base Frequency} \\ &= \frac{415}{380} \times 50 \\ &= 54.6\text{Hz} \end{aligned}$$

Scroll to 54.6

MOTOR 3~		50Hz	IEC 34-1
		No.	
		4kW	3000/2910 r/min
		CL.F	cosφ = 0.90
			380 V
			9.1 A

Rating plate (typical) showing essential data for the Motor Map.



**Pr44 Motor Full Load Slip**

The slip frequency is given by —

$$N_s = N_o - N_f$$

where  $N_o$  = base speed

and  $N_f$  = full load speed

From the motor rating plate,  $N_o = 3000\text{rpm}$ ,  $N_f = 2910\text{rpm}$ , so that:

$$N_s = 90\text{rpm}$$

The value must be entered in radians per second. Using the expression—

$$\text{Pr44} = 0.0525 \cdot p \cdot N_s$$

$$\text{Pr44} = 0.0525 \times 2 \times 90$$

$$= 9.45 \text{ rad s}^{-1}$$

Scroll to 9.45

**Pr45 Number of Motor Poles**

Typically — 2-pole machines run at	3000rpm 50Hz	3600rpm 60Hz
4-pole machines run at	1500rpm 50Hz	1800rpm 60Hz
6-pole machines run at	1000rpm 50Hz	1200rpm 60Hz
8-pole machines run at	750rpm 50Hz	900rpm 60Hz

Scroll to 2 (for this example)

**SAVE** and implement the Motor Map parameters entered by setting **b26** = 0.

This completes the Motor Map settings. The further procedures required are —

- To verify the encoder connections
- To verify the direction of rotation of the motor shaft

**VERIFICATION PROCEDURES**

**To CHECK the encoder connections —**


- ENSURE that the 'enable' circuit is disconnected at terminal B1 **AND** that the motor terminals are **disconnected and isolated** so that there is no possibility that the drive can turn the motor.
- Power-on the drive.
- *Slowly* rotate the motor shaft *clockwise* by hand and watch for a positive count on the display.
- *If the display reads negative*, exchange the leads to terminals B22 and B26, and also exchange leads B25 and B21. Rotate the motor shaft again to prove a positive reading.
- *If there is a null display*, suspect lack of encoder power. Check across terminals B23 AND B24; there should be a +5V reading.
- *Before proceeding*, power-off the drive and ISOLATE THE POWER SUPPLY (in accordance with any specified safety procedures as appropriate).
- WAIT TWO MINUTES to ensure that capacitive circuits are discharged.

**To CHECK the direction of rotation of the motor —**

- ENSURE that there is no risk of injury or damage when the motor shaft rotates.
- Reconnect the motor cables from the drive, observing safety procedures.
- Connect the 'enable' circuit at terminal B1.

conyinurd...

- Power-on the drive.
- Set **b22** = 0. This enables the drive to run an *unloaded* motor without encoder feedback.
- If the motor speed is too great for accurate observation, set **Pr01** to a low value, eg 10rpm, temporarily.
- The direction of rotation should be *clockwise* as viewed from the drive end of the motor. If incorrect, power-off the drive and **ISOLATE THE POWER SUPPLY** (in accordance with any specified safety procedures as appropriate).
- **WAIT TWO MINUTES** to ensure that capacitive circuits are discharged.
- Exchange any two motor phase connections.
- Set **b22** = 1.



Front view (at drive shaft end)  
clockwise rotation.

### TEST RUN

The drive is now ready to be test-run at 100rpm (default speed reference).

Make the following parameter settings —

- b02** = 0 — drive enable
- Pr06** = 50 — torque limit, motoring
- Pr07** = 50 — torque limit, regenerating

Also, connect the external 'Drive Enable' circuit to terminal B1 (refer to Figs. 7 and 8).

The motor should now run at 100rpm in clockwise rotation.

If the motor does not turn, or turns at a very slow speed, then either—

the motor phase connections are incorrect

or —

the encoder A and B connections are incorrect.

The final preparation is to set other drive parameters as appropriate to the application and duty of the motor and drive. Note that **Pr49**, Keypad Display Mode, is at present set to 1; it may be necessary or convenient to choose a different setting.

A number of parameters may now be monitored, for example —

Speed reference	<b>Pr01</b>
Motor speed	<b>Pr70</b>
Line Current	<b>Pr82</b>
Active current	<b>Pr75</b>
etc...	

The user may also wish to try the effect of adjusting certain parameters, for example —

Acceleration Rates	<b>Pr09, Pr10</b>
Deceleration Rates	<b>Pr11, Pr12</b>
Torque Limits	<b>Pr06, Pr07</b>

By setting **b07** = 0, the drive speed can be controlled by the analog speed reference potentiometer.

The remaining procedures are, if necessary, the fine tuning of the functioning of the motor and its driven load, by adjustment of the PID parameters of the *VECTOR*. The procedures are explained on the following pages.


### 6.3 Fine Tuning

The VECTOR drive employs a forward-compensation speed loop. The response of the speed loop can therefore be optimised to a high degree. To achieve this, the user has control of proportional, integral and derivative (PID) shaping of the speed loop output.


#### PID Parameters

The characteristics and effects of these three gains is summarised as follows —


**Proportional Gain** The greater the value of the proportional gain, the smaller will be the instantaneous speed error (overshoot) in response to a step change of load. (This, however, shows poor derivative effect.)



**Integral Gain** The greater the value, the quicker the speed recovers from the effect of a step change of load, and is necessary to eliminate speed-following error. Will tend to cause instability if set too high.



**Derivative Gain** This gain can, in some circumstances, reduce speed response overshoot at the expense of smoothness of operation. Excessively high values result in over-damping and sluggish response.




In general, the higher the *inertia* of the system (motor and load combined), the greater are the levels of proportional and integral gain required. The default values assigned to these parameters (Pr13 = 3, Pr14 = 2) relate to an unloaded motor. Doubling the inertia of the system would require the values of the P and I parameters to be doubled.

**Stability** A system is inherently more stable with lower values of integral gain.

With systems of low inertia, too high an integral gain will result in high-frequency instability. This can be corrected by reducing the I-term.

With high-inertia systems, a high integral gain can result in low-frequency high-amplitude oscillation, which can only be corrected by reducing the I-term or increasing the P-term.



The response of the drive to step changes can be monitored via the speed output on analog output Channel 1, terminal B11. This facilitates the adjustment of the PID parameters to achieve the ideal response, with minimum overshoot and quickness of response together with stability.

The benefits of the PID gains cannot be fully realised if the mechanical installation of the motor and its load allows any free movement between the two. It is important that couplings should not be slack, and that any provisions for preventing relative motion, such as tensioners, should be properly adjusted and maintained.

## 6.4 Protection

The VECTOR drive software incorporates protection logic to inhibit output in the event of —

- Motor and cable short circuit or earth fault
- Motor over-temperature
- IGBT stack or heatsink over-temperature
- DC bus over-voltage
- Supply under-voltage
- Loss of one phase of the supply

Any fault that causes the drive to trip produces a signal to indicate the cause. Refer to the information under Diagnostics.

Automatic protection requires two parameters to be set by the user — **Pr41** and **Pr55**.

**Pr41** Motor full load current (FLC). Enter the appropriate value from the motor rating plate. The software logic limits the drive output current to 150% of FLC.

**Pr55** Peak current time limit. This provides an overload trip integrating overload with time. The value is adjustable between zero and 60 seconds. What value is chosen will depend mainly on the application and the type of load being driven. The choice may also be affected by the characteristics of the motor.

Over-temperature protection of the motor requires a hard-wired input from a motor thermistor to terminal B13. Also, parameter **b16** must be set to 1. The voltage of the thermistor output is read by parameter **Pr88**. If the voltage exceeds 2.0V, the drive trip operates.

## 6.5 Diagnostics — Fault Finding

### SAFETY FIRST

#### *Electric Shock Risk*

Work on the drive and associated equipment and wiring should be undertaken only by suitably-qualified competent personnel. If the protective cover of the drive is to be removed, or if any external terminals are to be worked on, it is essential to WAIT TWO MINUTES after the drive has been disconnected at the main supply switchgear, to allow internal devices to discharge.

#### FAULT CHARACTERISTIC

#### ACTION

**Display does not illuminate and drive does not run.**

Check that Control Pod is connected.

Check mains supply, fuses, circuit breaker.

**NOTE** — If blown fuses blow again, or breaker trips again, contact the supplier of the drive.

Check control fuses.

**Display shows rdY, motor does not start.**

Drive is not enabled. Check **b02**, **b15**, and terminal B1.

**Display shows 0, motor does not start.**

Incorrect encoder or motor phase connections.

Check wiring of speed reference.

Check that **b02** = 0

Check the control wiring.

*continued...*

## FAULT CHARACTERISTIC

## ACTION

**Display shows Trip Code.**

Refer to Trip Codes for cause.

## NOTES —

- Thermal trip devices should never be continually tripped and reset.
- OC trip can be caused by cable or motor insulation faults.
- OU trips may be caused by decelerating too rapidly. Increase the value of the decelerating parameters **Pr11** or **Pr12** as appropriate or decrease the value of **Pr07**.
- If **Err...** trip is displayed, try disconnecting the drive from the supply, wait 2 minutes, reconnect and run the drive. If the fault persists, consult the supplier of the drive.

**Drive does not respond to serial communications.**

## Check —

Serial link parity enable **b18**

Serial link BCC enable **b19**

Serial link address **Pr22**

Baud rate **Pr23**

Check the wiring and terminations of the serial link cabling.

**If after performing any of the above actions the drive still malfunctions,  
consult the supplier of the drive for assistance.**

## GENERAL NOTES

- Any trip, internal or external, immediately inhibits the drive power output bridge. The motor coasts to rest.
- Internal protection trips are always active and cannot be disabled.

## 6.6 Healthy Indications













Motor stopped, drive energised, ready to run on command.



Numerical value on display —  
Motor running speed, in rpm.


## 6.7 Trip Codes

- Any trip, internal or external, immediately inhibits the drive power output bridge. The motor coasts to rest.
- Internal protection trips are always active and cannot be disabled (except th trip, by b16).
- An external trip Et can be applied at terminal CON2-10.

	dOC b81	DC overcurrent trip caused by excess current flowing in the inverter bridge.
	Et b87	External trip has been applied at terminal B2 or by b10.
	Unused decimals flashing	Ixt alarm, time-dependent overload. Drive has entered the Ixt region, leading to a trip if the load is not reduced.
	It b86	Integrating overload (Ixt) trip. The output current as defined by Pr41 and Pr55 has reached the allowable limit.
	OC b80	Instantaneous overcurrent trip. Excess current flowing in the IGBT inverter bridge, caused by short-circuit or low-impedance earth fault.
	Oh b85	Heat sink over-temperature. The heat sink has reached its upper safe working limit due to loss of ambient air or ambient air too hot.
	OU b82	DC bus over-voltage. Caused by mains supply overvoltage (even if momentary), or high-impedance earth fault, or excessive regeneration due to a high rate of deceleration, or insufficient braking resistance.
	St b88	Software trip.
	th b84	Motor thermistor (if fitted and connected) impedance high due to sensing excess temperature.
	UU b83	Under-voltage caused by loss of mains supply or low mains supply voltage (even if momentary).

## 6.8 Error Codes

**NOTE!** Err... trips may require expert attention. Please consult the supplier of the drive.

	Err...	Alternating with error code number (b90)
	b90	Err codes indicate a hardware fault within the drive. Occurs only at power-up. Is a lockout condition — refer to Note 4 below.

### Error Codes

Err	1	RAM check failure at power-on
Err	2	NVRAM data parity failure at power-on
Err	3	NVRAM data save timeout error
Err	4	MD21 DPRAM check failure at power-on
Err	5	Reference encoder input frequency overflow
Err	6	CPU to drive EPROM software mismatch
Err	7	4-20mA mode set-up failure
Err	8	Overspeed trip

### NOTES

- 1 In the event of an Err 2 or Err 3 trip, the Drive parameters (Motor Map, page 23) should be checked and re-stored before running.
- 2 Err 5 trip will occur if reference encoder input frequency >100kHz.
- 3 Err 8 is caused by motor shaft speed overshoot, in excess of the value of Pr35 above the limits set by Pr03 and Pr04. Systems experiencing this fault should either remove the cause of the excess overshoot or increase the value of Pr03 and/or Pr04, or more than 10 rpm in the opposite direction if both Pr03 and Pr04 are in the same direction.
- 4 Err codes are normally reset by disconnecting and reconnecting the power supply. If this is not successful, disconnect the supply, depress simultaneously the UP and DOWN keys at the keypad, and reconnect whilst holding the UP and DOWN keys.

## 7 Parameters

### 7.1 Parameters, Values and Functions

In the *VECTOR* digital drive, **parameters** take the place of the adjustable potentiometers and the movable links of an analog drive. Parameters are of two basic classes; some are adjustable over a range of **real** numerical values and correspond to a potentiometer. These are distinguished by the initial letters **Pr** before the parameter number, eg **Pr12**. The other class is the **bit** parameter, corresponding to adjustable links. Bit parameters are distinguished by the initial letter **b** before the number, eg **b21**.

Real parameter values range from -9999 to +9999 with a floating decimal point, eg 1.25, 12.5, 125 or 1250. The decimal is dependent on parameter resolution.

#### Bit Values

Bit values are 0 or 1. Bit parameters represent status variables, which adopt one of two possible states — for example, enabled or disabled, on or off, forward or reverse, etc.

Both classes of parameter also belong in one of two other sub-classes—

#### Read-Only (R-O)

These are the parameters which are set by the drive logic. The operator can monitor R-O parameters by means of the keypad and display or the serial communications link to verify status, but cannot make any adjustment to them.

#### Read-Write (R/W)

Read-write parameters are those which the operator can set by keypad entry or through the serial link; they can also be set by background programme execution — by a process controller for example. Their purpose is to optimise the *VECTOR* drive performance for a given application. Like R-O parameters, R/W parameters can be monitored by means of the keypad and display or through the serial link to verify performance, but unlike R-O parameters they can be adjusted.

#### Default Values of Parameters

Most R/W parameters have 'default' values, set during manufacture. New R/W parameter values selected during operation are stored in the non-volatile memory. Whatever values are last assigned to them remain after power-down, but the values assigned during manufacture can be recalled by parameter **b10**. Exceptionally, the four parameters of the Motor Map have no default value. Values assigned to the Motor Map parameters remain unless changed by the operator.

#### Access and Security

Parameters and their values are accessible through the keypad. The software is equipped with a Security Code (for the user to write as required) which, unless entered first, prevents access to parameters for the purpose of writing. All parameters can be read without use of the Security Code. The procedure for assigning and changing the Security Code are on page 21.

Additionally, parameters can be accessed, read, and changed by signals through a serial communications link from a host computer, a terminal, a process controller, or other communicating device.

## 7.2 Numerical Parameters — R/W

- When the MODE key is pressed, the display will show the number of the parameter last read or changed.
- Parameters are listed in the sequence in which they appear in the Keypad Display when the UP key is operated.
- The symbol » beside a parameter number, eg **Pr05»** indicates that the drive must be reset by setting **b26 = 0** to make a change of value effective. All other R/W parameter values become effective as soon as they are changed.

<b>Pr00</b>	<u>Null Parameter</u>	Used as a destination for programmable analog inputs. Always reads 00.
<b>Pr01</b>	<u>Speed Reference 1</u>	Digital speed reference 1, forward or reverse. Functional when drive is enabled. Motor speed may be limited by Minimum and Maximum Speed Limits <b>Pr03</b> and <b>Pr04</b> .
	Type	R/W, real values
	Units	Revolutions per minute (rpm)
	Range	+6000rpm to -6000rpm
	Default	+100rpm
	Related parameters <b>Pr02 Pr03 Pr04 b06</b>	
<b>Pr02</b>	<u>Speed Reference 2</u>	Digital speed reference 2, forward or reverse. Functional when drive is enabled. Motor speed may be limited by Minimum and Maximum Speed Limits <b>Pr03</b> and <b>Pr04</b> .
	Type	R/W, real values
	Units	Revolutions per minute (rpm)
	Range	+6000rpm to -6000rpm
	Default	+100rpm
	Related parameters <b>Pr01 Pr03 Pr04 b06</b>	
<b>Pr03</b>	<u>Minimum Speed Limit</u>	Sets the lower limit of speed. If <b>Pr03</b> is given a positive value, the drive will operate the motor at speeds between <b>Pr03</b> and <b>Pr04</b> in the forward direction only. If <b>Pr03</b> is given a negative value, the value becomes the maximum speed in reverse. Also sets a lower base level for the overspeed trip, <b>Pr35</b> . Limitation: <b>Pr03 &lt; Pr04</b> .
	Type	R/W, real values
	Units	Revolutions per minute (rpm)
	Range	+6000rpm to -6000rpm
	Default	-1500 rpm
	Related parameters <b>Pr01 Pr04</b>	
<b>Pr04</b>	<u>Maximum Speed Limit</u>	Sets a maximum above which the speed references are not effective. Also sets a higher base level for the overspeed trip, <b>Pr35</b> . Limitation: <b>Pr04 &gt; Pr03</b>
	Type	R/W, real values
	Units	Revolutions per minute (rpm)
	Range	-6000rpm to +6000rpm
	Default	+1500 rpm
	Related parameters <b>Pr00 Pr01 Pr03</b>	



- Pr05» Analog Speed Reference Filter** Determines the response time of the analog input.
- |            |                         |      |   |   |   |    |    |    |     |
|------------|-------------------------|------|---|---|---|----|----|----|-----|
| Type       | R/W, real values        |      |   |   |   |    |    |    |     |
| Units      | Milliseconds (ms)       |      |   |   |   |    |    |    |     |
| Range      | Select one of 6 values* | (ms) | 2 | 4 | 8 | 16 | 32 | 64 | 128 |
|            | Programming code number |      | 0 | 1 | 2 | 3  | 4  | 5  | 6   |
| Default    | 8ms                     |      |   |   |   |    |    |    |     |
| Resolution | 2.44mV                  |      |   |   |   |    |    |    |     |
- \* Values as utilised at the keypad.
- When selecting a value of **Pr05** through the Serial Link, send 0, 1, 2, 3, 4, or 5, where 0 = 2ms, 1 = 4ms ... 5 = 128ms.
- When reading parameters through the Serial Link, values are shown in ms.
- Pr06 Torque Limit: Motoring** Determines maximum available torque when the drive is operating in the motoring mode.
- |            |                             |  |
|------------|-----------------------------|--|
| Type       | R/W, real values            |  |
| Units      | % of full load torque (FLT) |  |
| Range      | 1% to 150%FLT               |  |
| Default    | 150%FLT                     |  |
| Resolution | 0.5% steps                  |  |
- Pr07 Torque Limit: Regenerating** Determines maximum available torque when the drive is operating in the generating mode.
- |            |                             |  |
|------------|-----------------------------|--|
| Type       | R/W, real values            |  |
| Units      | % of full load torque (FLT) |  |
| Range      | 1% to 150%FLT               |  |
| Default    | 150%FLT                     |  |
| Resolution | 0.5% steps                  |  |
- Pr08 Internal Torque Reference** Sets a digital value for torque reference, or torque feed forward.
- |         |                             |  |
|---------|-----------------------------|--|
| Type    | R/W, real values            |  |
| Units   | % of full load torque (FLT) |  |
| Range   | +150% to -150%FLT           |  |
| Default | Zero                        |  |
- Related parameters  
**b04 b05 Pr06 Pr07**
- Pr09 Forward Acceleration Rate** Sets the rate at which the drive accelerates the motor in a forward direction, and is in effect an acceleration ramp.
- |         |  |  |
|---------|--|--|
| Type    | R/W, real values                       |  |
| Units   | milliseconds per revolution per minute |  |
| Range   | +0.01 to +99.99ms (rpm) <sup>-1</sup>  |  |
| Default | 1.0ms rpm <sup>-1</sup>                |  |
- Related parameters  
**Pr10 Pr11 Pr12**
- Pr10 Reverse Acceleration Rate** Sets the rate at which the drive accelerates the motor in the reverse direction, and is in effect an acceleration ramp.
- |         |  |  |
|---------|--|--|
| Type    | R/W, real values                       |  |
| Units   | milliseconds per revolution per minute |  |
| Range   | +0.01 to +99.99ms (rpm) <sup>-1</sup>  |  |
| Default | 1.0ms rpm <sup>-1</sup>                |  |
- Related parameters  
**Pr09 Pr11 Pr12**
- Pr11 Forward Deceleration Rate** Sets the rate at which the drive decelerates the motor in a forward direction, and is in effect a deceleration ramp.
- |         |  |  |
|---------|--|--|
| Type    | R/W, real values                       |  |
| Units   | milliseconds per revolution per minute |  |
| Range   | +0.01 to +99.99ms (rpm) <sup>-1</sup>  |  |
| Default | 1.0ms rpm <sup>-1</sup>                |  |
- Related parameters  
**Pr09 Pr10 Pr12**

Pr12	<b><u>Reverse Deceleration Rate</u></b>	Sets the rate at which the drive decelerates the motor in the reverse direction, and is in effect a deceleration ramp.	
	Type	R/W, real values	
	Units	milliseconds per revolution per minute	
	Range	+0.01 to +99.99ms (rpm) <sup>-1</sup>	
	Default	1.0ms rpm <sup>-1</sup>	
		Related parameters <b>Pr09 Pr10 Pr11</b>	
Pr13	<b><u>Speed Loop Proportional Gain</u></b>	Sets the value of the proportional gain compensation. The greater the proportional term, the smaller will be the instantaneous speed error in response to a step change of load. If set too high, Pr13 will cause the speed to overshoot and oscillate.	
	Type	R/W, real values	
	Units	per unit (pu)	
	Range	0.1 to 8.0pu	
	Default	3pu	
		Related parameters <b>Pr14 Pr15</b>	
Pr14	<b><u>Speed Loop Integral Gain</u></b>	Sets the value of the integral gain compensation. The greater the integral term, the quicker the speed recovers from a step-change of load. Pr14 provides 'stiffness' in the system. If set too high, Pr14 will cause instability in the speed response.	
	Type	R/W, real values	
	Units	per unit (pu)	
	Range	0.0 to 8.0pu	
	Default	2pu	
		Related parameters <b>Pr13 Pr15</b>	
Pr15	<b><u>Speed Loop Derivative Gain</u></b>	Sets the value of the derivative (differential) gain compensation. The derivative term can reduce the speed-response overshoot in some circumstances. If set too high, Pr14 will cause instability in the speed response.	
	Type	R/W, real values	
	Units	per unit (pu)	
	Range	0.0 to 8.0pu	
	Default	zero	
		Related parameters <b>Pr13 Pr14</b>	
Pr16	<b><u>Hard Speed Reference</u></b>	A digital speed reference added to the the post-ramp speed reference before subtraction of the speed (encoder) feedback. Disabled when the drive receives a 'Stop' command.	
		<b>NOTE!</b> Pr16 is applied after the speed limits (Pr03, Pr04) and after the ramps (Pr09 — Pr12) and should be used with care.	
	Type	R/W, real values	
	Units	revolutions per minute (rpm)	
	Range	-250.00rpm to +250.00 rpm	
	Default	zero	
	Resolution	0.25 rpm (actual; displays 0.1 rpm)	
		Related parameter <b>b11 (Bypasses Pr16)</b>	
Pr17	<b><u>Scaling of Analog Speed Input</u></b>		
	Type	R/W, real values	
	Units	revolutions per volt (rpm V <sup>-1</sup> )	
	Range	-600.0 to +600.0 rpm V <sup>-1</sup>	
	Default	+150.0	
		Related parameters <b>Pr18 Pr72 Pr84</b>	

- Pr18**    Speed Reference Offset    Reference offset added to the scaled analog speed input **Pr17**.  
*NOTE* A 2-volt offset applied to a full 10-volt input reference may cause **Err5** overflow tripping.
- |                |                  |
|----------------|------------------|
| <i>Type</i>    | R/W, real values |
| <i>Units</i>   | Volts            |
| <i>Range</i>   | -10.0 to +10.0V  |
| <i>Default</i> | zero             |
- Related parameters  
**Pr17 Pr72 Pr84**
- Pr19**    Scaling of Analog Input Channel 3, Terminal B14
- |                |                  |
|----------------|------------------|
| <i>Type</i>    | R/W, real values |
| <i>Range</i>   | -999.9 to +999.9 |
| <i>Default</i> | 0                |
- Related parameters  
**Pr20 Pr21 Pr74 Pr86**
- Pr20**    Offset of Analog Input Channel 3, Terminal B14
- |                |                  |
|----------------|------------------|
| <i>Type</i>    | R/W, real values |
| <i>Units</i>   | unitary          |
| <i>Range</i>   | -10.0 to +10.0V  |
| <i>Default</i> | 0                |
- Related parameters  
**Pr19 Pr21 Pr74 Pr86**
- Pr21»**    Destination of Analog Input Channel 3    Selects which parameter is controlled by Channel 3 input at Terminal B14.
- |                |  |
|----------------|--|
| <i>Type</i>    | R/W, real values                                       |
| <i>Range</i>   | All parameters from <b>Pr00</b> through to <b>Pr69</b> |
| <i>Default</i> | <b>Pr00</b>  |
- Pr22**    Serial Link — Address    Defines the unique address of the drive.
- |                |                  |
|----------------|------------------|
| <i>Type</i>    | R/W, real values |
| <i>Range</i>   | 00 to 32         |
| <i>Default</i> | 01               |
- Pr23»**    Serial Link — Baud Rate    Permits the drive Baud rate to be set to correspond with that of the communicating device.  
When **READING**, the actual value of the Baud rate is displayed.  
When **WRITING**, integers 0 to 6 represent Baud rates as below —
- |                               |   |
|-------------------------------|---|
| <i>Type</i>                   | R/W, real values                                    |
| <i>Range</i>                  |   |
| Select one of 7 values (Baud) | 300    600    1200    2400    4800    9600    19.2k |
| Programming code number       | 0      1      2      3      4      5      6         |
| <i>Default</i>                | 9600Baud  |
- Pr24**    Factory-set Security Key    For factory test use only
- Pr25**    Security Code    When a Security Code has been applied (refer to page 21) to a drive, R/W parameters cannot be changed unless the correct code is entered, but all parameters can be read without hindrance. Drives can be given unique codes.
- |                |                     |
|----------------|---------------------|
| <i>Type</i>    | R/W, integer values |
| <i>Range</i>   | 100 to 9999         |
| <i>Default</i> | zero                |
- Related parameters  
**b21**

<b>Pr26»</b>	<b><u>Destination of Logic Input Channel 0</u></b>	Selects which bit parameter is controlled by logic input Channel 0, Terminal B4.
	<i>Type</i>	R/W, real values
	<i>Range</i>	All parameters from <b>b00</b> through to <b>b63</b>
	<i>Default</i>	<b>b05</b>
<b>Pr27»</b>	<b><u>Destination of Logic Input Channel 1</u></b>	Selects which bit parameter is controlled by logic input Channel 1, Terminal B3.
	<i>Type</i>	R/W, real values
	<i>Range</i>	All parameters from <b>b00</b> through to <b>b63</b>
	<i>Default</i>	<b>b00</b>
<b>Pr28»</b>	<b><u>Programmable Output F2 Source</u></b>	Selects which bit parameter controls the state of logic output Channel 0, Terminal B7.
	<i>Type</i>	R/W, real values
	<i>Range</i>	00 to 99
	<i>Default</i>	<b>b72</b> (at zero speed)
<b>Pr29»</b>	<b><u>Programmable Output F1 Source</u></b>	Selects which bit parameter controls the state of logic output Channel 1, Terminal B6.
	<i>Type</i>	R/W, real values
	<i>Range</i>	00 to 99
	<i>Default</i>	<b>b73</b> (at speed)
<b>Pr30</b>	<b><u>Offset of Analog Input Channel 2</u></b>	Reference offset added to the scaled analog input Channel 2, Terminal B16.
	<i>Type</i>	R/W, real values
	<i>Range</i>	-10.0V to +10.0V
	<i>Default</i>	0.0V
	Related parameters <b>Pr31 Pr32 Pr87 Pr90</b>	
<b>Pr31</b>	<b><u>Scaling of Analog Input Channel 2 (Terminal B16)</u></b>	
	<i>Type</i>	R/W, real values
	<i>Range</i>	-999.9 to +999.9
	<i>Default</i>	0.0
	Related parameters <b>Pr30 Pr32 Pr87 Pr90</b>	
<b>Pr32»</b>	<b><u>Destination of Analog Input Channel 2</u></b>	Selects which parameter is controlled by analog input Channel 2, Terminal B16.
	<i>Type</i>	R/W, real values
	<i>Range</i>	All parameters from <b>Pr00</b> to <b>Pr63</b>
	<i>Default</i>	<b>Pr00</b>
	Related parameters <b>Pr30 Pr31 Pr87 Pr90</b>	
<b>Pr33»</b>	<b><u>Programmable Output F2 Source</u></b>	Selects which bit parameter controls the state of logic output Channel 2, Terminal B5.
	<i>Type</i>	R/W, real values
	<i>Range</i>	00 to 99
	<i>Default</i>	<b>b64</b> (drive healthy)
<b>Pr34</b>	<b><u>Torque Output Scaling (Terminal B10)</u></b>	Provides a means to attain a full-scale (10V) output at Terminal 10 to agree with a required value of Active Current ( <b>Pr75</b> ).
	<i>Type</i>	R/W, real values
	<i>Range</i>	0 to 600
	<i>Default</i>	150
	Related parameter <b>Pr75</b>	

Pr35	<u>Overspeed Trip Threshold</u>	Sets the threshold of the Overspeed Trip ( <b>Err8</b> ). Expressed in rpm above speed limits <b>Pr03</b> and <b>Pr04</b> .																	
		NOTE! If <b>Pr03</b> and <b>Pr04</b> are set in the <i>same direction</i> , the threshold is 10 rpm in the opposite direction. Refer also to <b>Pr03</b> page 32, and Note 3 page 30.																	
	Type	R/W, real values																	
	Range	0 to 600																	
	Default	150																	
Pr36»	<u>Programmable Logic Input F2 Destination</u>	Defines the parameter to which the F2 logic input is destined.																	
		NOTE! As standard, logic input F2 default to <b>Et</b> . To enable F2 to be directed to a parameter, and to disable the default <b>Et</b> , links LK27 and LK28 must be moved to the right, <i>ie</i> towards the terminal block.																	
	Type	R/W, real values																	
	Range	0 to 63																	
	Default	0 (default action is <b>Et</b> trip)																	
Pr37 through to Pr39	<i>Reserved for MD21 Applications</i>																		
Pr40	<u>Drive Model</u>	<i>Adjusted during manufacture, and not adjustable thereafter.</i>																	
	Type	Preset																	
Pr41»	<u>Motor Full Load Current (FLC)</u>	Rated FLC of the driven motor must be entered before the drive is operated. The available range of values is dependent on the drive model.																	
	Type	R/W, real values																	
	Units	Amps																	
	Range	<table><tr><td>VB75</td><td>1.5A to 2.1A</td><td>VB400</td><td>3.8A to 9.5A</td></tr><tr><td>VB110</td><td>1.5A to 2.8A</td><td>VB550</td><td>5.6A to 12A</td></tr><tr><td>VB150</td><td>2.1A to 3.8A</td><td>VB750</td><td>9.5A to 16A</td></tr><tr><td>VB220</td><td>2.8A to 5.6A</td><td>VB1100S</td><td>12A to 22A</td></tr></table>		VB75	1.5A to 2.1A	VB400	3.8A to 9.5A	VB110	1.5A to 2.8A	VB550	5.6A to 12A	VB150	2.1A to 3.8A	VB750	9.5A to 16A	VB220	2.8A to 5.6A	VB1100S	12A to 22A
VB75	1.5A to 2.1A	VB400	3.8A to 9.5A																
VB110	1.5A to 2.8A	VB550	5.6A to 12A																
VB150	2.1A to 3.8A	VB750	9.5A to 16A																
VB220	2.8A to 5.6A	VB1100S	12A to 22A																
	Default	Parameter <b>b10</b> 'Reset to Default' DOES NOT AFFECT <b>Pr41</b>																	
Pr42»	<u>Motor Magnetising Current</u>	The value should preferably be obtained from the manufacturer of the motor. Alternatively, it can be measured by operating the motor without load and at rated frequency and voltage.																	
	Type	R/W, real values																	
	Units	Amps																	
	Range	25% to 85% of Full Load Current setting																	
	Default	Parameter <b>b10</b> 'Reset to Default' DOES NOT AFFECT <b>Pr42</b>																	
Pr43»	<u>Motor Base Frequency</u>	Motor base frequency is the output frequency at which the drive delivers the (motor) rated operating voltage.																	
	Type	R/W, real values																	
	Units	Hz																	
	Default	Parameter <b>b10</b> 'Reset to Default' DOES NOT AFFECT <b>Pr43</b>																	
Pr44»	<u>Motor Full Load Slip</u>	The value should preferably be obtained from the manufacturer of the motor. Alternatively, it can be measured by operating the motor at rated frequency, voltage and load.																	
		$\text{Pr44} = 0.0525p(n_o - n_f)$ <p>where — <math>p</math> = number of poles <math>n_o</math> = no-load speed, and <math>n_f</math> = full-load speed</p>																	
	Type	R/W, real values																	
	Units	radian per second																	
	Range	3.5 to 31.99 rad s <sup>-1</sup>																	
	Default	Parameter <b>b10</b> 'Reset to Default' DOES NOT AFFECT <b>Pr44</b>																	

## 7 - Parameters

## VECTOR

<b>Pr45»</b>	<b><u>Motor Poles</u></b>	Sets the drive to correspond with the number of poles of the motor.				
	Type	R/W, real values				
	Range	2, 4, 6 or 8				
	Default	Parameter <b>b10</b> 'Reset to Default' DOES NOT AFFECT Pr45				
<b>Pr46»</b>	<b><u>Inverter Switching Frequency</u></b>	Sets the frequency at which the inverter generates the PWM output waveform. Higher values produce less acoustic noise but increase the inverter heat losses.				
		NOTE! Drive modules VB1100S requires derating at 9kHz and 12kHz. Please refer to Section 2.3 page 7.				
	Type	R/W, real values				
	Units	kHz				
	Range	Select value in kHz	3kHz	6kHz	9kHz	12kHz
		Programming code number	0	1	2	3
	Default	3kHz				
<b>Pr47</b>	<b><u>Torque Demand Slew Rate</u></b>	Limits the rate-of-rise of torque, thus limiting the mechanical impulse fed into the system. Too high a value can cause oscillation				
	Type	R/W, real values				
	Units	ms. % <sup>-1</sup>				
	Range	0 to 5.0				
	Default	0				
<b>Pr48</b>	<b>RESERVED</b>					
<b>Pr49</b>	<b><u>Keypad Display Mode Selector</u></b>					
	Programming code number	Display mode...				
	0	Display the full menu of parameters				
	1	Display all except <b>b80</b> to <b>b91</b>				
	2	Display a mini-menu — <b>b00</b> to <b>b17</b> , <b>Pr00</b> to <b>Pr20</b> , <b>Pr49</b> to <b>Pr52</b> , and <b>Pr70</b> to <b>Pr89</b> .				
	Default	2				
<b>Pr50</b>	<b><u>Scaling of Programmable Analog Output Channel 1. Terminal B11</u></b>					
	Type	R/W, real values				
	Range	-999.9 to +999.9				
	Default	150.0				
		Related parameters <b>Pr51</b>				
<b>Pr51»</b>	<b><u>Source of Analog Output Channel 1</u></b>	Selects which real parameter controls the output of analog output Channel 1, Terminal B11.				
	Type	R/W, real values				
	Range	All parameters from <b>Pr00</b> through to <b>Pr99</b>				
	Default	<b>Pr70</b>				
		Related parameters <b>Pr50</b>				
<b>Pr52</b>	<b><u>Speed Reference Percentage Trim</u></b>	Adds a trim to the final speed reference. For example, if the selected speed reference is <b>Pr01</b> , the trim applied is —				
		$\text{Pr01} \times \left(1 + \frac{\text{Pr52}}{100}\right)$				
	Type	R/W, real values				
	Range	- 50.0 to + 50.0 per cent				
	Default	zero				

Pr53	<u>I x t Threshold Current</u>	Sets the value of current above which the I x t protection will begin to integrate.
	<i>Type</i>	R/W, real values
	<i>Units</i>	Amps
	<i>Range</i>	as Pr41
	<i>Default</i>	as Pr41
Pr54	<u>Zero Speed Window</u>	Defines the limits between which the 'zero speed' relay operates.
		NOTE! If Pr54 = 0, the relay may oscillate.
	<i>Type</i>	R/W, real values
	<i>Units</i>	rpm
	<i>Range</i>	zero to 50rpm
	<i>Default</i>	6rpm
Pr55	<u>Current x Time Limit (I x t)</u>	Defines the time for which the peak current is permitted, and thus sets the I x t overload trip.
	<i>Type</i>	R/W, real values
	<i>Units</i>	seconds
	<i>Range</i>	0.5 to 30s in steps of 0.5s
	<i>Default</i>	30
		Related parameters Pr53
Pr56	<u>At-Speed Window</u>	Defines limits between which the 'at speed' relay operates.
	<i>Type</i>	R/W, real values
	<i>Units</i>	rpm
	<i>Range</i>	zero to 50rpm
	<i>Default</i>	6rpm
		NOTE — If Pr56 = 0, the relay may oscillate.
Pr57	<u>Last Trip</u>	Holds the Trip Code of the last malfunction causing a trip. This data is stored in non-volatile memory and is not destroyed by loss of supply power.
	<i>Type</i>	R-O, real values
		Related parameters b80 b81 b82 b83 b84 b85 b86 b87 b88 b89
Pr58	<b>RESERVED</b>	
Pr59	<b>RESERVED</b>	
Pr60 to Pr69		Reserved for MD21 applications.

## 7.3 Numerical Parameters — R-O

Pr70	<u>Motor Speed</u>	Monitors motor actual speed in rpm. This is the value normally displayed at the keypad when the drive is running.
	Type	R-O, integer values
	Units	rpm
	Range	+6000 to -6000
Pr71	<u>Motor Frequency</u>	Monitors actual frequency delivered to the motor.
	Type	R-O, integer values
	Units	Hz
	Range	0 to 400Hz
Pr72	<u>Analog Speed Reference</u>	Monitors analog speed reference.
	Type	R-O, integer values
	Units	rpm
	Range	+6000 to -6000
Pr73	<u>Shaft Revolutions Counter</u>	Monitors shaft revolutions after each power-up. Each complete forward revolution is recorded as one positive integer. If the maximum is reached, the counter continues from zero.
	Type	R-O, integer values
	Units	One unit per complete revolution
	Range	+8191 to -8192
Pr74	<u>Analog Input Channel 3 Monitor</u>	Monitors the Channel 3 (terminal B14) input after scaling.
	Type	R-O, real values
	Units	Volts
	Range	±10 V
Pr75	<u>Active Current</u>	Monitors the active current supplied to the motor as a proportion of full load active current, and is therefore a measure of the ratio of torque applied to maximum torque.
	Type	R-O, integer values
	Units	per cent
	Range	- 150% to +150%
Pr76	<u>Speed Reference — pre-Ramp</u>	Value of the speed reference before the ramp generator.
Pr77	<u>Speed Reference — post-Ramp</u>	Value of the speed reference after the ramp generator. Ramp can be bypassed by b14.
Pr78	<u>DC Bus Voltage</u>	Monitors the actual voltage of the DC bus link, within the operating range.
	Type	R-O, real values
	Units	Volts
	Range	400V to 800V
Pr79	RESERVED	
Pr80	<u>I x t Accumulator</u>	Monitors the percentage of I x t accumulated when the drive is above the overload threshold, indicating how close to trip. Trip at 100%. Time to trip ( $t_{trip}$ in seconds) is calculated from —
		$t_{trip} = \frac{1.04 \times Pr53^2}{Pr82^2 - (Pr53 + 10\%)^2} \times Pr55$
	Type	R-O, integer values
	Units	per cent
	Range	0 to 100%



Pr81	<u>Speed Error</u>	Monitors the speed error, ie the difference between the set speed (reference) and actual motor shaft speed.
	Type	R-O, real values
	Units	rpm
	Range	± 930 rpm
Pr82	<u>Motor Line Current</u>	Monitors the total current delivered to the motor.
	Type	R-O, integer values
	Units	amps
	Range	0 to 150% FLC of motor
Pr83	<u>Relative Shaft Position</u>	Monitors the angular displacement of the motor shaft relative to the position it held on each occasion when the drive is powered-up, or relative to the encoder marker pulse if used.
	Type	R-O, integer values
	Units	Degrees of rotation
	Range	0 to 360° Resolution 0.1°
Pr84	<u>Analog Input Channel 1 Conversion Value</u>	
	Units	Volts, -10.00 to +10.00
	Resolution	0.01 V
	Accuracy	10-bit
Pr85	<u>Analog Input Channel 2 Conversion Value</u>	
	Units	Volts, -10.00 to +10.00
	Resolution	0.01 V
	Accuracy	10-bit
Pr86	<u>Analog Input Channel 3 Conversion Value</u>	
	Units	Volts, -10.00 to +10.00
	Resolution	0.01 V
	Accuracy	10-bit
Pr87	<u>Monitor Analog Input Channel 2 after Offset and before Scaling</u>	
	Units	Volts, -10.00 to +10.00
	Resolution	0.01 V
	Accuracy	10-bit
Pr88	<u>Analog Input Channel 4 Conversion Value</u>	
	Units	Volts, 0 to +10.00
Pr89	<u>Value Presented to Analog Output Channel 1, Terminal B11</u>	
	Units	Volts, -10.00 to +10.00
	Resolution	0.01 V
	Accuracy	12-bit
Pr90	<u>Monitor — Analog Input Channel 2</u>	
	Type	R-O, integer values
	Units	Volts
	Range	-10.0V to +10.0V
	Default	0.0V
		Related parameters Pr30 Pr31 Pr32 Pr87
Pr91	<u>Speed Loop Output</u>	Monitors the value of compensated speed loop demand. Normally, this parameter is configured as a torque demand for the torque loop.
	Range	-150 to +150 per cent
Pr94 to Pr98		Reserved for MD21 applications
Pr99	<u>Software Version Number</u>	

## 7.4 Bit Parameters — R/W

<b>b00</b>	<u>Null Parameter</u>	Used as a destination for programmable digital outputs. Always reads A0.
<b>b01</b>	<u>Software Trip</u>	The function of this parameter is to perform a trip only. It does not have the effect of a 'Power-off Reset', for which function <b>b26</b> must be used.
	Type Function	R/W, digital <b>b01</b> = 0 Trip the drive
<b>b02</b>	<u>Drive Enable</u>	Enables or disables the drive after power-up. Normally, when the drive is powered-down, <b>b02</b> remains as set. To enable the drive, <b>b02</b> must be set to 0 and a (negative logic) signal is also required at terminal B1. (If <b>b15</b> = 0, <b>b02</b> resets to default on power-off — refer to <b>b15</b> .)
	Type Default Function	R/W, digital 1 <b>b02</b> = 0 Enable <b>b02</b> = 1 Disable
		Related parameters <b>b15 b67 b68</b> Refer also to Control Terminal B1
<b>b03</b>	<u>Drive Reset</u>	Resets the drive to operational status after a trip, provided that the cause of the trip has been corrected or removed.
	Type Default Function	R/W, digital 1 <b>b03</b> = 0 Reset <b>b03</b> = 1 Normal status
		Related parameters <b>b64 b80 b81 b82 b83 b84 b85 b86 b89 b90</b>
<b>b04</b>	<u>Control Mode — torque demand</u>	Selects control by speed error with torque demand or by speed error only. Effectively bypasses the internal torque reference <b>Pr08</b> .
	Type Default Function	R/W, digital 1 <b>b04</b> = 0 Torque control <b>b04</b> = 1 Speed control
		Related parameters <b>b05 Pr08</b>
<b>b05</b>	<u>Zero Torque Reference</u>	Applies a zero torque demand.
	Type Default Function	R/W, digital 1 <b>b05</b> = 0 Zero torque demand <b>b05</b> = 1 Speed reference
		Related parameters <b>b06 Pr02 Pr05 Pr08 Pr17</b> NOTE! — Default is controlled by logic input F0.
<b>b06</b>	<u>Speed Reference Selector</u>	Provides the choice of external digital speed references.
	Type Default Function	R/W, digital 1 <b>b06</b> = 0 Speed reference 2 <b>b06</b> = 1 Speed reference 1
		Related parameters <b>Pr01 Pr02</b>

<b>b07</b>	<b><u>A/D Speed Reference Selector</u></b>	Selects either analog or digital internal speed reference input.
	Type	R/W, digital
	Default	1
	Function	<b>b07 = 0</b> Analog speed reference <b>b07 = 1</b> Digital speed reference Related parameters <b>Pr01 Pr02 Pr16 Pr72</b>
<b>b08</b>	<b><u>Stop</u></b>	Sets a zero speed reference either pre- or post-ramp, dependent on the setting of <b>b20</b> .  When <b>b08 = 0</b> , the drive is <b>DISABLED</b> when motor speed reaches zero. If the motor speed does not reach zero, due to there being a value in <b>Pr16</b> or due to an over-running load, the drive does not disable.
	Type	R/W, digital
	Default	1
	Function	<b>b08 = 0</b> Decelerate to zero speed <b>b08 = 1</b> Normal status
<b>b09</b>	<b><u>Speed Reference Invert</u></b>	Permits digital or analog external speed reference signal to be inverted.
	Type	R/W, digital
	Default	1
	Function	<b>b09 = 0</b> Invert speed reference <b>b09 = 1</b> Normal status
<b>b10»</b>	<b><u>Reset Parameters to Default</u></b>	Enables all parameters to be returned to their default setting simultaneously.
	NOTES —	
	1 No effect on <b>Pr41, Pr42, Pr43, Pr44, and Pr45</b> .	
	2 After reset, a 'store' must be performed — refer to <b>b26</b> . Default values are assumed on next power-up.	
	Type	R/W, digital
	Default	1
	Function	<b>b10 = 0</b> Reset to default values <b>b10 = 1</b> Normal status
<b>b11</b>	<b><u>Bypass for Hard Speed Reference</u></b>	
	Type	R/W, digital
	Default	0
	Function	<b>b11 = 0</b> Normal <b>b11 = 1</b> Bypass active
<b>b12</b>	<b><u>Shaft Encoder Revolutions Counter Reset</u></b>	
	Type	R/W, digital
	Default	1
	Function	<b>b12 = 0</b> Continuously reset <b>b12 = 1</b> No action Related parameters <b>Pr73</b>
<b>b13</b>	<b><u>Power-up in Last Trip state</u></b>	Enables the drive, after being powered-down in a tripped state, to be returned to that same state after the next power-up. The drive is then unhealthy, requiring the correction or removal of the cause of the trip, if it still remains, before applying the reset, <b>b03</b> . NOTE! — does not apply in the case of under-voltage trip <b>UU</b> .
	Type	R/W, digital
	Default	1
	Function	<b>b13 = 0</b> Power-up in Last Trip State <b>b13 = 1</b> Normal status

- b14**    Ramp Bypass    Enables the acceleration and deceleration ramps to be bypassed and thereby disabled as a group.
- Type            R/W, digital  
    Default        1  
    Function       b14 = 0 Ramps bypassed  
                    b14 = 1 Normal status
- b15**    Auto or Manual Start Mode    By setting parameter **b15** = 0, **b02** is forced to default on power-down so that, on power-up, the drive is disabled, requiring **b02** to be set to 0 to enable. (An enable signal must also be applied at terminal B1.) After the first power-up, **b02** must be set to zero to run the drive. The drive will subsequently start automatically unless **b15** is set to 0.
- Type            R/W, digital  
    Default        1  
    Function       b15 = 0 Causes **b02** = 1 (Disable) on power-up  
                    b15 = 1 Normal status of **b02**  
                    Related parameters  
                    **b02 b67 b68**  
                    Refer also to Control Terminal B1
- b16**    Motor Thermistor enable    Enables the motor thermistor sensing circuitry.
- Type            R/W, digital  
    Default        1  
    Function       b16 = 0 Sensing circuit disabled  
                    b16 = 1 Normal status
- b17**    RESERVED
- b18**    Serial Link Parity enable    Selects whether or not a parity bit is included in Serial Link transmissions.
- Type            R/W, digital  
    Default        1  
    Function       b18 = 0 No parity bit  
                    b18 = 1 Include parity bit
- b19**    Serial Link Block Checksum Enable    Selects whether or not a block checksum (BCC) error check is included in a Serial Link communication.
- NOTE! After a Serial Comms message, a rogue character must be included. If **b19** = 0 the rogue character is ignored.
- Type            R/W, digital  
    Default        1  
    Function       b19 = 0 No BCC  
                    b19 = 1 BCC
- b20**    Ramp to Stop or Hard Stop    Selects a zero speed reference *before* or *after* the Ramp function. Hard stop provides full-torque deceleration, which may not be desirable in some applications.
- Type            R/W, digital  
    Default        1  
    Function       b20 = 0 Hard stop  
                    b20 = 1 Ramp to stop
- b21**    Security Code Key Enable    Locks the Security Code **Pr25** against accidental or unauthorised alteration of the code. The current code must be entered to enable **b21** to be changed. (This is not required until a code is assigned.)
- Type            R/W, digital  
    Default        1  
    Function       b21 = 0 **Pr25** can be changed  
                    b21 = 1 **Pr25** cannot be changed

<b>b22</b>	<b><u>Open-Loop Mode</u></b>	Selects open or closed loop operation. Provides a crude open-loop control mode to turn and <b>unloaded</b> motor. May be convenient to use during commissioning, but <b>must not</b> be used continuously, ie in normal operation.
	Type	R/W, digital
	Default	1
	Function	<b>b22 = 0</b> Open loop (no encoder) <b>b22 = 1</b> Closed loop (encoder feedback normal)
<b>b23</b>	<b>RESERVED</b>	
<b>b24</b>	<b><u>Logic Outputs Inversion</u></b>	If <b>b24 = 0</b> , the logic of all three logic outputs, F0 to F2, is inverted. Outputs will be <i>activated</i> (+24V) for a logic 0.
	Type	R/W, digital
	Default	1
	Function	<b>b24 = 0</b> Logic inverted <b>b24 = 1</b> Not inverted
<b>b25</b>	<b><u>Logic Inputs Inversion</u></b>	If <b>b25 = 0</b> , the logic of all three logic inputs, F0 to F2, is inverted. Zero volts will equal logic 1.
	Type	R/W, digital
	Default	1
	Function	<b>b25 = 0</b> Logic inverted <b>b25 = 1</b> Not inverted
<b>b26</b>	<b><u>Hard Reset</u></b>	Provides an effective 'Power-off Reset'. It is necessary to use this function in order to save certain parameters, eg the Motor Map parameters <b>Pr41</b> to <b>Pr45</b> .
	Type	R/W, digital
	Default	1
	Function	<b>b26 = 0</b> Hard reset performed <b>b26 = 1</b> Normal status
<b>b27</b>	<b><u>Common Torque Limit</u></b>	The two available torque limits, <b>Pr06</b> and <b>Pr07</b> , can be separately active, or the <b>Pr06</b> value can be applied to both.
	Type	R/W, digital
	Default	1
	Function	<b>b27 = 0</b> <b>Pr07</b> will be set to the value of <b>Pr06</b> <b>b27 = 1</b> <b>Pr06</b> and <b>Pr07</b> torque limits are separate
<b>b28</b>	<b><u>Ramp Hold</u></b>	Stops the advance of the ramp when activated. When de-activated, allows the ramp to advance.
	Type	R/W, digital
	Default	1
	Function	<b>b28 = 0</b> Ramp value hold <b>b28 = 1</b> Normal ramp
<b>b29</b>	<b>RESERVED</b>	
<b>b30</b>	<b><u>Torque Mode Selection</u></b>	Controls the manner in which torque is applied in relation to direction (sense) of speed demand; speed override control depends on torque mode.
	Type	R/W, digital
	Default	1
	Function	<b>b30 = 0</b> Torque applied in either direction dependent on the sign (+ or -) of the torque reference parameter <b>Pr08</b> . Speed override limited only by speed clamps <b>Pr03</b> and <b>Pr04</b> . <b>b30 = 1</b> Torque applied if the sense of the speed and torque demands are the same. Speed override set by speed reference.
<b>b31 to b61</b>	<i>Reserved for MD21 applications</i>	

## 7.5 Bit Parameters — R-O

b64	<u>Drive Healthy</u>	Indicates that the drive is in a healthy state, ie it is powered-up and no faults are detected.	
	Type	R-O, digital	
	Function	b64 = 0 Drive not healthy	
		b64 = 1 Drive healthy	
b65	<u>Logic Function F0 Status</u>	Indicates the status of input terminal B4.	
	Type	R-O, digital	
	Function	b65 = 0 Logic level 'low'	
		b65 = 1 Logic level 'high'	
b66	<u>Logic Function F1 Status</u>	Indicates the status of input terminal B3.	
	Type	R-O, digital	
	Function	b66 = 0 Logic level 'low'	
		b66 = 1 Logic level 'high'	
b67	<u>Drive Enable Input Status</u>	Indicates the status of input terminal B1, drive enable signal.	
	Type	R-O, digital	
	Function	b67 = 0 Logic level 'low'	
		b67 = 1 Logic level 'high'	
		Related parameters	
		b02 b08 b15 b68	
b68	<u>Drive Enabled Status</u>	Indicates the condition of the drive, whether enabled or disabled.	
	Type	R-O, digital	
	Function	b68 = 0 Drive disabled	
		b68 = 1 Drive enabled	
		Related parameters	
		b02 b08 b15 b67	
b69	<u>Forward or Reverse Rotation</u>	Indicates the condition of the motor — whether rotating forward or reverse.	
	Type	R-O, digital	
	Function	b69 = 0 Motor running in reverse	
		b69 = 1 Motor running forward	
b70	<u>Logic Function F2 Status</u>	Indicates the status of input terminal B10.	
	Type	R-O, digital	
	Function	b70 = 0 Logic level 'low'	
		b70 = 1 Logic level 'high'	
		Related parameter	
		Pr36	
b71	RESERVED		
b72	<u>Drive at Zero Speed</u>	Indicates a condition of the drive — whether speed < Pr54.	
	Type	R-O, digital	
	Function	b72 = 0 Drive running	
		b72 = 1 Drive at zero speed	
b73	<u>Drive at Speed</u>	Indicates a condition of the drive — whether speed < Set Speed ± Pr56.	
	Type	R-O, digital	
	Function	b73 = 0 Drive not at set speed	
		b73 = 1 Drive at set speed	

b74	<u>Torque Limit Indicator</u>	Indicates that the torque limit has been reached. Also indicated at the Control Pod display (decimal points flashing).
	Type Function	R-O, digital b74 = 0 Drive within torque limit b74 = 1 Drive at torque limit
b75	<u>Motor Thermistor Alarm</u>	Indicates that the motor thermistor has operated due to high temperature. Does NOT trip the drive. (Only when b16 = 1, circuit enabled.)
	Type Function	R-O, digital b74 = 0 Motor overtemperature b74 = 1 Motor temperature within limit
b80	<u>Over-current Trip (OC)</u>	Indicates that an over-current trip condition exists — output current has exceeded upper limit programmed for the motor. May indicate a motor earth fault or short circuit, but the cause may be incorrect setting of the Motor Map parameters Pr41 to Pr45 inclusive.
	Type Function	R-O, digital b80 = 0 Trip inactive b80 = 1 Trip active
b81	<u>DC Link Current Trip (dOC)</u>	Indicates that the drive has tripped because the DC link current has exceeded the permitted maximum. May indicate a motor earth fault, short circuit or power semiconductor device failure.
	Type Function	R-O, digital b81 = 0 Trip inactive b81 = 1 Trip active
b82	<u>Over-voltage Trip (OU)</u>	Indicates that the drive has tripped because the DC link voltage has exceeded the permitted maximum.
	Type Function	R-O, digital b82 = 0 Trip inactive b82 = 1 Trip active
b83	<u>Under-voltage Trip (UU)</u>	Indicates that the drive has tripped because the DC link voltage has fallen below the permitted minimum. The cause may be a disturbance in the power supply to the drive.
	Type Function	R-O, digital b83 = 0 Trip inactive b83 = 1 Trip active
b84	<u>Motor Over-temperature Trip (th)</u>	Indicates that the drive has tripped because the motor temperature sensor has operated (terminal B13).
	Type Function	R-O digital b84 = 0 Trip inactive b84 = 1 Trip active
b85	<u>Drive IGBT Stack Over-temperature Trip (Oh)</u>	Indicates that the drive has tripped because the inverter stack has exceeded the maximum permitted operating temperature.
	Type Function	R-O digital b85 = 0 Trip inactive b85 = 1 Trip active
b86	<u>Lx t Trip (It)</u>	Indicates that the drive has exceeded the maximum permitted time on overload.
	Type Function	R-O digital b86 = 0 Trip inactive b86 = 1 Trip active

**VECTOR**

- 48



## 7.6 Parameters Index

### Numerical Parameters

#### READ-WRITE (R/W)

Pr00	Null parameter
Pr01	Speed reference 1
Pr02	Speed reference 2
Pr03	Minimum speed limit
Pr04	Maximum speed limit
Pr05»	Analog Speed Reference filter
Pr06	Torque limit — motoring
Pr07	Torque limit — regenerating
Pr08	Internal Torque Reference
Pr09	Forward acceleration rate
Pr10	Reverse acceleration rate
Pr11	Forward deceleration rate
Pr12	Reverse deceleration rate
Pr13	Proportional gain
Pr14	Integral gain
Pr15	Derivative gain
Pr16	Hard speed reference
Pr17	Analog speed input scaling
Pr18	Speed reference offset
Pr19	Channel 3 input scaling
Pr20	Channel 3 offset
Pr21»	Destination of Channel 3
Pr22	Serial link address
Pr23»	Serial link Baud rate
Pr24	Factory set security key
Pr25	Security code
Pr26»	Destination, programmable input F0
Pr27»	Destination, programmable input F1
Pr28»	Source, programmable output F2
Pr29»	Source, programmable output F1
Pr30	Analog input channel 2 offset
Pr31	Analog input channel 2 scaling
Pr32»	Analog input channel 2 destination
Pr33»	Source, programmable output F0
Pr34	Torque output scaling (Terminal B10)
Pr35	Overspeed trip threshold
Pr36»	Destination, programmable input F2
Pr37 to Pr39 <i>Reserved for MD21</i>	
Pr40	Drive model
Pr41»	Full load current
Pr42»	Magnetising current
Pr43»	Base frequency
Pr44»	Full load slip
Pr45»	Motor pole count
Pr46»	Inverter switching frequency
Pr47	Torque demand slew rate
Pr48	<i>Reserved</i>
Pr49	Keypad display mode selector
Pr50	Scaling anal. output 1


Pr51»	Source analog output 1
Pr52	Speed reference trim
Pr53	I x t threshold current
Pr54	Zero speed window
Pr55	I x t time limit
Pr56	At-speed window
Pr57	Last trip
Pr58, Pr59 <i>Reserved</i>	
Pr60 to Pr69 <i>Reserved for MD21</i>	

#### READ ONLY (RO)

Pr70	Motor speed
Pr71	Motor frequency
Pr72	Analog speed reference
Pr73	Shaft revolutions counter
Pr74	Analog input channel 3 monitor
Pr75	Active current
Pr76	Speed reference — pre-ramp
Pr77	Speed reference — post-ramp
Pr78	DC bus voltage
Pr79	<i>Reserved</i>
Pr80	I x t accumulator
Pr81	Speed error
Pr82	Motor line current
Pr83	Relative shaft position
Pr84	Analog input channel 1 conversion
Pr85	Analog input channel 2 conversion
Pr86	Analog input channel 3 conversion
Pr87	Analog input channel 2 post-offset
Pr88	Analog input channel 4 conversion
Pr89	Analog output channel 1 value
Pr90	Analog input channel 2 monitor
Pr91	Speed loop output
Pr94 to Pr98 <i>Reserved for MD21</i>	
Pr99	Software version number

## Bit Parameters

<i>READ-WRITE (R/W)</i>		<i>READ ONLY (RO)</i>	
b00	Null parameter	b64	Drive healthy
b01	Software trip	b65	Function status F0
b02	Drive enable	b66	Function status F1
b03	Drive reset	b67	'Drive enable' Input status
b04	Control mode — torque	b68	Drive enabled/disabled status
b05	Zero torque reference	b69	Forward or reverse rotation
b06	Speed reference selector	b70	Function status F2
b07	A/D Speed reference selector	b71	<i>Reserved</i>
b08	Stop	b72	Drive at zero speed
b09	Speed reference invert	b73	Drive at speed
b10»	Reset parameters to default	b74	Torque limit indicator
b11	Hard speed reference bypass	b75	Motor thermistor alarm
b12	Shaft encoder revs counter reset	b80	Trip (OC)
b13	Power-up in Last Trip state	b81	Trip (dOC)
b14	Ramp bypass	b82	Trip (OU)
b15	Auto or Manual Start mode	b83	Trip (UU)
b16	Motor thermistor enable	b84	Trip (motor) (th)
b17	<i>Reserved</i>	b85	Trip(inverter) (Oh)
b18	Serial Link parity enable	b86	Trip (It)
b19	Serial Link BCC enable	b87	External trip (Et)
b20	Ramp to stop or 'Hard stop'	b88	Software trip (St)
b21	Security code key enable	b89	I x t alarm (...)
b22	Open-loop mode	b90	Hardware fault (Err...)
b23	<i>Reserved</i>		
b24	Inversion, logic outputs	b91 to b99	<i>Reserved for MD21</i>
b25	Inversion, logic inputs		
b26	Hard Reset		
b27	Common torque limit		
b28	Ramp hold		
b29	<i>Reserved</i>		
b30	Torque mode selector		
b31 to b61	<i>Reserved for MD21</i>		



## 8 Serial Communications

A communications link is standard in all *VECTOR* drives. It is a machine-machine link, enabling one or more drives to be used in systems controlled by a host such as a process logic controller (PLC) or computer. *VECTOR* drives can be directly controlled, their operating configuration can be altered, and their status can be interrogated by such a host, and continuously monitored by data logging equipment. A host can operate up to thirty-two *VECTOR* drives, Fig. 13, and up to 99 if line buffers are used.

The communication port of the drive module is the terminal block 'C', Fig. 8. The standard connection is the RS485, Fig. 14, or RS422 4-wire link; 3-wire RS232 can be connected also, Fig. 15. Protocol is ANSI x 3.28 - 2.5 - A4, as standard for industrial interfaces.

### 8.1 Fundamentals


Logic processors, such as computers, PLCs, and the communications system of *VECTOR* drives communicate by means of binary logic. Binary logic is 'two state', and is readily implemented by an electrical circuit which is either on or off. In *VECTOR* drives, the on-state is represented by a positive voltage, and the off-state by zero volts. The two voltages thus represent two distinct units of data, each being a binary digit ('bit') — either 0 or 1.

By fixing a time duration for each bit, a series of bits transmitted can be recognised by a receiver. If, also, a series or group always contains the same number of bits it becomes possible to construct a variety of different 'characters' that the receiver can recognise and decode. A group of four bits has sixteen possible variants — 0000, 0001, 0010, and so on to 1111. Each of the sixteen variants represents one 'hexadecimal' character-unit — the decimal numerals 0 to 9 followed by the six letters A to F — making 16 different and distinct characters.

The scope of the data that can be represented is much increased if two hexadecimal characters are combined to make a simple code. Since there are 16 hex characters, two in combination will produce  $16 \times 16 = 256$  possible different characters. Using this as the basis of a code, it becomes possible to represent a large number of symbols, or units of data, by means of only two hex characters, each of four bits, making eight bits in all and known as a 'byte'.


Early in the development of computer technology it was recognised that a long stream of bits without, so to speak, any punctuation marks would be unmanageable and at risk of transmission errors passing unrecognised. The byte was adopted as a standard unit. To ensure that each byte is distinct, a start bit and a stop bit are added. The convention is that the start bit is a 0 and the stop bit a 1.

Each byte, therefore, occupies a finite time in transmission, but the interval between successive bytes is of no importance. Only the structure — the 'framing' or 'character format' — of the byte is significant. There is more than one convention for 'framing' the character. The format in *VECTOR* drives is ten bits as shown diagrammatically on the following page.




*The parity bit is used by the receiver of the message to check the integrity of the data byte.*


The character set used in *VECTOR* drives is the 'low' American Standard Code for Information Interchange (ASCII), comprising 128 characters, decimally numbered 0 to 127. In the low ASCII set, the first hex character extends only from decimal 0 to 7, binary 0000, 0001 etc to 0111. This being so, the



13 Serial address Pr22. Unique identity code for up to 32 drives per communications port at the host.



14 RS485 or RS422 serial communications link connections. Cable must be screened.



15 Connections for RS232 link.

first bit is always 0 and can be the start bit. The remaining three bits of the first hex character and the four bits of the second hex character are available to denote any of the 128 characters in the low ASCII set. The parity bit, and the stop bit, 1, are attached at the end.

The first 32 characters in the ASCII set (hex 00 to 1F and the 'space' character, hex 20, decimal 32) are used to represent special codes. These are the Control Codes, each of which has a particular meaning. For example, 'start of text' is STX, and, from a keyboard, is made by holding down the Control key and striking B once (Control-B). This is hex 02, and the actual transmission is the binary byte 0000 0010. The drive is programmed to know that this character signals that a command will follow, whereas EOT (Control-D) will be followed by information or a request. If a host has a vdu screen, control characters appear on it in their ASCII format— ETX, EOT etc.

The components of all messages between the host and a *VECTOR* drive are formed of ASCII characters. The format of a message, ie the sequence in which the characters appear, is standardised for messages of each different kind, and is explained under Structure of Messages, below.

### Preliminary Adjustment of the Drive

Each drive requires a unique identity number, or serial address, set by parameter **Pr22**. The baud rate, **Pr23**, and the parity enable bit, **b18**, require to be set to match the host. Data, drive status and the parameter set-up can be read from the drive in any mode, provided only that the drive is energised, and that the serial address, Baud rate and parity bit parameters are correctly set.

## 8.2 Components of Messages

### Control Characters

To conform to the standard structure of a message, the stages of a message are signalled by control characters. Each character has a specific meaning, a standard abbreviation, and is transmitted and received in ASCII code. If a message is initiated from a keyboard, the control characters are keyed by holding the Control key down while making a single-letter keystroke. Of the 32 control characters in the ASCII set, the six in the following table are used in *VECTOR* serial communications.

**CONTROL CHARACTERS in VECTOR VB75-1100 DRIVES**

Character	Meaning	ASCII code HEX	Keyed as Control...
EOT	Reset, or 'Now hear this' or End of Transmission	04	D
ENQ	Enquiry, interrogating the drive	05	E
STX	Start of text	02	B
ETX	End of text	03	C
ACK	Acknowledge (message accepted)	06	F
BS	Backspace (go to previous parameter)	08	H
NAK	Negative acknowledge (message not understood)	15	U

### Serial Address

Each drive is given an identity or address (**Pr22**, Fig.13) so that only the drive that is concerned will respond. For security, the format is that each digit of the two-digit drive address is repeated, thus the address of drive number 23 is sent as four characters—

2	2	3	3
---	---	---	---

The serial address follows immediately after the first control character of the message.

## Parameter Identification

For transmission by serial link, parameters are identified by a number. The serial identities of parameters **Pr00** through to **Pr99** are 0 to 99. For example the identity for **Pr 23** is 23.

The serial identities of bit parameters **b00** through to **b99** are 100 to 199. Thus, the identity for parameter **b23** is 123.

Each numerical parameter writes and reads a variable numerical value within its range, whatever the value happens to be at the time, with three exceptions — **Pr05**, **Pr23**, and **Pr49**. Each of these can hold one of a group of fixed values. Their programming code numbers and the values corresponding to them are —

Pr05		Pr23		Pr49	
WRITE	READ (ms)	WRITE	READ (Baud)	WRITE	READ
0	2	0	300	0	<i>Preselection of menu display</i>
1	4	1	600	1	
2	8	2	1200	2	
3	16	3	2400		
4	32	4	9600		
5	128	5	19.2		

## Data

Data to be sent or requested occupies the next six characters after the parameter number. Data is handled as a floating point signed decimal number. All of the operating parameters of the drive are **numerical** values, such as frequency, load, current, etc. For example, speed is given by the range +6000 to -6000, the value being in rpm. The value '95rpm in a reverse direction' may be sent as —

-	0	9	5	.	0
---	---	---	---	---	---

— but different formats are valid so long as there are up to six characters preceded by a space or by a sign, + or -. A single space is treated as a '+' sign. For example, for the value of 60, all of the following are valid —

+	6	0	.	0	0	=	60
	6	0				=	60
-	6	0	.	0		=	-60
-	0	0	6	0	.	=	-60

The state of **bit-parameters** is transmitted and received as real-value data, of value 0 or 1. Again, the format is flexible so long as no more than 5 characters are comprised, and not more than one space-character is used, for example —

	1			
+	0	0	0	1

— and so on.

**Block Checksum (BCC)**

To permit the drive and the host to ensure that messages from one to the other have not become corrupted in transmission, all communications other than interrogatives and acknowledgement may be terminated by a block checksum character (BCC, page 57) if selected. BCC is selected by **b19** = 1. If not selected (**b19** = 0), BCC is ignored on reception, but a random character must be attached at the end of the string. A Carriage Return (ODH = Control-M) is sent on transmit.

**8.3 Structure of Messages****Host to Drive**

Messages from the host to the drive are of two kinds —

- a request for information, or —
- a command

Both kinds must start with the control character EOT (Control-D) to indicate that a message is being sent. This is followed by the serial address of the drive receiving the message. The format of the data and the choice of control character to terminate the message is different for the two kinds.

For an **information request**, sending the parameter number instructs the particular drive addressed to supply data relating to that parameter. A data request message is terminated by the control character ENQ to indicate that the host is ready to receive data in reply.

For a **command**, a control character after the serial address tells the drive that the message is to be an instruction concerning its operational parameters, and that the next part of the message will be the instruction data. The instruction data occupies six characters. An instruction message is terminated by control character ETX followed by a block checksum (BCC, page 57).

**Drive to Host**

Messages from the drive to the host are of two kinds —

- a reply to a data request, or —
- acknowledgement of a message.

In **reply** to a data request, the start control character is STX, and is followed by the parameter number to confirm the request from the host, and then the six characters of data. The message is terminated by the control character ETX and a block checksum (BCC).

A message is **acknowledged** by the control character ACK if understood, or NAK if invalid, wrongly formatted or corrupt.

**Multiple Drives**

A message can be sent to two or more more addresses simultaneously. If several drives are always to respond to the same request or instruction, all must be given the address 0 (zero).



## 8.4 Sending Data

Host command —

reset - address - start of text - parameter - 6 characters - end - BCC

For example, the message to the drive —

"change set speed of drive number 14 to 476rpm in reverse"  
would be sent as —

CONTROL	ADDRESS				CONTROL	PARAM			DATA						CONTROL	
EOT Control-D	1	1	4	4	STX Control-B	0	0	1	-	4	7	6	.	0	ETX Control-C	# BCC

*Send again, with different parameter and/or data*

The drive will respond with an acknowledgement, either —

ACK if the message is understood *and* implemented, or —

NAK if the message is invalid, the data is too long, or the BCC is incorrect.

If a value sent is outside the limits for a parameter, the drive will respond with NAK.

## 8.5 Reading Data

The drive will send any data to the host, provided that the request is valid. The format of a data request message is —

Host request —

reset - address - parameter - end

For example, to find the speed set point **Pr01** of drive number 12, send —

CONTROL	ADDRESS				PARAM			CONTROL
EOT Control-D	1	1	2	2	0	0	1	ENQ Control-E

The drive replies in the following form —

start - parameter - 6 characters of data - end - BCC

For example —

CONTROL	PARAM				DATA						CONTROL	
STX Control-B	0	0	1	+	4	7	6	.	0	ETX Control-C	,	BCC

The reply first confirms that the data sent is the speed set point, **Pr01**; the six characters immediately following give the present setting in rpm. The first character is either + or -, to indicate direction of rotation; the remainder is the numerical value —

"forward at 476rpm" in this example.

**Repeat Enquiry**

The negative acknowledgement NAK (Control-U) can be used at a keyboard to cause the drive to send data repeatedly for the same parameter. It saves time when wanting to know if or how a value is changing over a period.

**Next Parameter**

To obtain data from the same drive for the next parameter in numerical order, send the positive acknowledgement ACK (Control-F). The drive will respond by transmitting the data relating to the next parameter in sequence.

**Previous Parameter**

To obtain data from the same drive for the previous parameter in numerical order, send backspace BS (Control-H).

**Invalid Parameter Number**

If the host sends a parameter number which the drive does not recognise, eg 223, the drive will respond with NAK.

**8.6 Block Checksum (BCC)**

To ensure that data received can be verified, a block checksum is attached to the end of each command or data response. The BCC is automatically calculated by the sending logic and is derived in the following manner.

First, a binary exclusive-OR (XOR) is performed on all nine characters of the message after the start-of-text command.

For example if the the message to be sent to drive number 14 is —

“set speed to 476rpm in reverse”

it is sent as --

Reset	EOT (Control-D)
Serial address	1 1 4 4
Start of text	STX (Control-B)
<i>Not included in BCC calculation</i>	
<hr/>	
Parameter:	<i>BCC calculation starts here</i>
Reverse	Parameter number
476	- (a minus sign)
End of message	476
finally,	ETX (Control-C)
	BCC, calculated as shown

Each of the separate digits,

, - 4 7 6 and Control-C

is represented by a hexadecimal character and calculated in binary as shown in the table on the following page. The XOR is the final summation.

Character	Binary Code	
(Pr01) 1	0011	0001
- (minus)	0010	1101
4	0011	0100
7	0011	0111
6	0011	0110
ETX (Control-C)	0000	0011
XOR	0010	1010

The final XOR is 00101010 = 2A (hex) = 42 (decimal) — which is represented by the character \*.

Thus the complete message to set the speed of drive number 14, say, to 476rpm in reverse is —

CONTROL	ADDRESS				CONTROL	PARAM			DATA						CONTROL	
EOT Control-D	1	1	4	4	STX Control-B	0	0	1	-	4	7	6	.	0	ETX Control-C	* BCC

NOTE — The ASCII characters from 00 to 1F (hex), plus 'space', are used only for control codes. The transmitted BCC must therefore exceed the value of 32 (decimal). Whenever the XOR produces a (decimal) number not greater than 32, it is necessary to add 32 to it to avoid confusion with the control characters.

## 9 Braking

### 8.1 Introduction

When an AC motor is mechanically driven, it operates as a generator provided that a voltage is applied at its terminals. When torque is provided by the inertia of the driven load rather than by the electrical power supply, the motor delivers power.

During deceleration of an AC motor and its load, a proportion of the stored kinetic energy can be converted by the motor into electrical energy and returned to the inverter. When a high-inertia load is decelerated in a short time the energy delivered can be too great for the DC link capacitance to absorb alone. The effect is to increase the voltage of the DC link and a DC overvoltage trip may occur as a result.

As industrial inverter drives are able to absorb in the DC link capacitor only a small proportion of the energy stored in the driven load when it is at full speed, greater dynamic braking torque can be applied to a motor only if an electrical load, ie a resistor, can be switched into the DC link to absorb stored energy. Excess voltage in the DC link is prevented by the switching of the braking unit under the control of a dedicated braking control circuit. The duty of the braking control unit during regeneration is to prevent the DC voltage rising above maximum and to prevent overcharging of the DC bus capacitor.

Inherent in the characteristic of this type of inverter drive is the constant V/f ratio of the output (constant torque) below base frequency, and constant voltage (constant power) above base frequency.

Because of the constant-V/f characteristic, regenerated power declines towards zero speed. When coasting to a stop, the drive system is ordinarily brought finally to rest by its fixed losses which are mostly friction.

As regenerated power is maximum and constant at any speed above base frequency, this is where the braking resistor does most of its work. The maximum braking torque is a function of the regenerated current, which is inversely proportional to resistor value at constant voltage. Choice of resistor value determines the braking torque.

The power rating of the resistor, on the other hand, depends upon the braking duty cycle — the braking time and the repetition time — and on the cooling available for the resistor. Data for the calculation of resistor values and ratings are given below, with an example.

Separately, the resistor must be protected against continuous overload by a thermal trip relay, as shown in Fig. 16.

### 8.2 Braking Resistors


<i>Module type</i>	<i>Resistor size</i>	<i>Maximum regenerative power</i>
VB75 VB110 VB150	80Ω, 150W	1.5kW for 10s, continuous rating, with a minimum cooling time of 90s.
VB220 VB400 VB550 VB750 VB1100S	40Ω, 300W	3.0kW for 10s, continuous rating, with a minimum cooling time of 90s.

#### External Braking Resistor Connections

Refer to Fig. 16.

ON the larger VECTOR drives, (VB400, VB550, VB750 and VB1100S), provision is made to fit an external resistor of higher rating than the standard on-board resistor for increased dynamic braking performance. To protect the installation from the risk of damage it is essential that —

- The internal resistor is disconnected. For this it is essential to consult the supplier of the drive.
- The external resistor is fitted with a thermal protection relay, wired to trip the supply contactor.



#### APPLICATION of the BRAKING RESISTOR

##### IMPORTANT NOTE

*The application of an external braking resistor absolutely requires that the internal resistors are first disconnected.*

Maximum DC link voltage is 70V above normal DC bus voltage, **Pr78**. The resistor, cabling and insulation must be suitable for this operating voltage.

Install the braking resistor in accordance with instructions provided by its supplier or manufacturer. The braking resistor **MUST** incorporate a thermal trip device, which **MUST** be connected to a trip release mechanism on the supply-side contactor or circuit breaker, Fig. 16.

The following notes are for guidance in the selection of resistors. In case of uncertainty, the supplier of the drive should be asked for advice. In any case, when ordering resistors, complete data about the installation and the application should be made available to the resistor supplier, who should be asked to provide appropriate overload-factor and cooling curves.

The size and rating of the resistor are calculated with respect to the power to be absorbed, the rate at which power will be delivered, and the time-lapse between successive decelerations.

Kinetic energy of the motor and load =  $0.5 J \omega^2$

where  $J$  = total moment of inertia ( $\text{kg m}^2$ ) of the motor and driven machine.

**NOTE** If there is gearing between the motor and the driven machine,  $J$  is the value reflected at the motor shaft.

$\omega$  = angular velocity ( $\text{radians s}^{-1}$ ), or, alternatively, use  $\frac{2\pi \times n}{60}$

As the energy is proportional to the square of the angular velocity, most of the energy in the system is concentrated at the higher operating speeds, and is initially delivered to the resistor at the start of the deceleration. If the motor is operated at speeds above base frequency, the energy delivered to the resistor is constant until the speed falls below base frequency.

Resistors intended for braking duty should be capable of tolerating thermal shock. 'Pulse rated' resistors are recommended.

**Terms**

The *value* of a resistor is its resistance in ohms. Note that a resistor of *low* value will draw a *high* current.

The *rating* of a resistor is the measure of the power (kW) that it is designed to absorb continuously.

**Recommended values —**

Module type	Resistance value $\Omega$	Rating W	Short-time rating 10s	Cooling time s
VB75 to VB220	80	150	1.5kW	90
VB400 to VB1100S	40	300	3.0kW	90

If an external braking resistor is used, the maximum braking currents are —

Module type	Max braking current A rms
VB75 to VB220	2
VB400 to VB1100S	20

**EXAMPLE**

A load inertia of  $0.5\text{kg m}^2$  is to be decelerated from 1500rpm to rest. Calculate the braking resistor value ( $\Omega$ ) and power rating (kW).

**DATA**

Drive type VB750	7.5kW
Motor	7.5kW
Motor nominal torque rating	47Nm
Decelerating time	to be determined
Repeat cycle time	30 seconds
Load inertia (J)	$0.5\text{kg m}^2$
Resistor value (R)	to be calculated
Resistor rating ( $P_r$ )	to be calculated
Resistor operating voltage (V)	660V (Pr78 + 70V)

The first essential step is to determine the *minimum decelerating time*,  $t_b$ .

$$t_b = \frac{2\pi \times J \times n}{60 \times M_{b \max}}$$

Maximum deceleration occurs at 150% of motor nominal torque. The value to apply for  $M_{b \max}$  is therefore  $1.5 \times 47 = 70.5$ , and the *decelerating time* is —

$$t_b = \frac{2\pi \times 0.5 \times 1500}{60 \times 70.5}$$

$$= 1.11 \text{ seconds}$$

A *practical* deceleration time  $t_d$  can now be decided. For this example, let  $t_d = 2\text{s}$ .

Calculate the *actual braking torque*  $M_b$  required to decelerate the load in 2s —

$$M_b = \frac{2\pi \times J \times n}{60 \times t_d}$$

$$= \frac{2\pi \times 0.5 \times 1500}{60 \times 2}$$

$$= 39 \text{ Nm}$$

Braking power is —

$$P_b = \frac{2\pi \times M_b \times 1500}{60 \times 10^3} \quad \text{in kW}$$

$$P_b = \frac{2\pi \times 39 \times 1500}{60 \times 10^3}$$

$$= 6\text{kW}$$

#### Resistor value R

The VB750 drive is capable of regenerating up to 150% of rated current (11.25kW) for up to 30 seconds maximum. This is in excess of the 6kW required for this application.


The value of the resistor is —

$$R = \frac{V^2}{P_b} = \frac{660^2}{6 \times 10^3}$$

$$= 72.6\Omega$$

#### Resistor power rating $P_r$

As the braking resistor operates intermittently, its power rating is 'intermittent' rather than 'continuous'. Advantage can be taken of the overload rating of the resistor by applying an overload factor, which will be derived from a set of cooling curves which can be obtained from the manufacturer or supplier of the resistor.



17 Typical cooling curves for power resistor overload factors. These curves are typical examples only. For practical application use curves supplied by the resistor manufacturer.

In this example, deceleration time is taken as 7s, repeat cycle time 30 seconds. From Fig.17, reading from 7s on the horizontal axis and vertically to the 30-second curve, the overload factor is 2.

The power rating of the chosen resistor is —

$$\begin{aligned} P_r &= \frac{P_b}{\text{O/L factor}} \\ &= \frac{6\text{kW}}{2} \\ &= 3\text{kW} \end{aligned}$$

For practical purposes, it can be assumed that 15% to 20% of energy dissipated during regenerative braking are due to electrical losses in the motor and drive, and mechanical losses in the motor and load, all of which which would assist braking.

In practice, using the recommended resistor value will result in extra braking torque being available. However, the rate of energy feedback from the load inertia is determined by the rate of deceleration.

If the rate of deceleration is unchanged, the *VECTOR* drive will compensate the duty cycle of the braking transistor so that the average power-absorption remains constant.

#### **CAUTIONARY NOTES**

The installation **MUST** be equipped with a thermal protection relay operating a trip release on the supply switchgear (Fig. 16).

The resistors fitted internal to the drive **MUST** be disconnected.



## 10

# Electromagnetic Compatibility

### IMMUNITY

If the instructions in this guide are observed, *VECTOR* drives exhibit excellent immunity to interference from external sources. In accordance with normal good practice, relays, contactors and switches in power circuits adjacent to the drive should be fitted with suppressors if they control inductive loads.

Additionally, the *VECTOR* drive has been subjected to noise-level tests in accordance with IEC 801 pt. 4, without adverse result.

### EMISSIONS

Because of the fast semi-conductor switches used to ensure high electrical efficiency, PWM drives emit some radio-frequency energy, mainly by conduction through the input supply and the motor cables. It is possible for this energy to disturb nearby communications or measuring systems if they are sensitive in the frequency range 100kHz to 10MHz.

Emission can be minimised by using the lowest switching frequency selectable for the drive.

#### Motor Chokes

Motor chokes can be of service if long cable runs — in excess of 200m — are necessary. The chokes will also assist in the reduction of radiated radio-frequency interference (RFI) from the cables between the drive and the motor, by limiting the rate-of-rise of voltage in the cables.

Using inductors of increased size can also assist in the reduction of motor noise, but this will be at the expense of high-speed torque.

In either case, the supplier of the drive should be asked for advice.

#### Motor Cable

The motor cable carries the highest radio-frequency voltage and current. The electric and magnetic fields associated with the cable diminish rapidly with increasing distance, and sufficient attenuation can usually be achieved by ensuring the segregation of signal cables to a separation distance of at least 0.3m from the motor cable. Parallel runs exceeding about 10m should be avoided if possible.

Emission from the motor cable can be greatly reduced by using a screened or armoured cable. The best effect is obtained if the screening is earthed at both ends — to the motor frame and to the drive earth terminal.

#### Supply Cable

If emission into the supply causes trouble, a suitable filter must be installed. The supplier of the drive should be asked to advise.

## ARGENTINA - Buenos Aires

**Euro Techniques SA**  
Peru 359 6to OF. 603 - 1067  
Buenos Aires

Tel & Fax: [54] 1 331 7820

## CYPRUS - Nicosia

**Phasarias Industrial Auto Centre**  
18-5 Makarios Avenue  
CY 1065 Nicosia

Tel: [357] 2361918  
Fax: [357] 2363268  
After Hours: [357] 2368324

## AUSTRALIA - Melbourne Drive Centre



**Control Techniques Australia Pty Ltd**  
106 Drummond Street  
Oakleigh  
Victoria 3166

Tel: [61] 3 9563 4550  
Fax: [61] 3 9563 4545

## CZECH REPUBLIC - Brno Drive Centre



**Control Techniques - VUES s.r.o**  
Mostecka 26  
61400 Brno

Tel: [420] 545 321112  
Fax: [420] 545 213896  
After Hours: [42] 545 321112

## AUSTRALIA - Sydney Drive Centre



**Control Techniques Australia Pty Ltd**  
16-18 Tucks Road  
Seven Hills  
(Sydney)  
NSW 2147

Tel: [61] 2 9838 7222  
Fax: [61] 2 9838 7764  
After Hours: [61] 2 9963 5271

## DENMARK - Copenhagen Drive Centre



**Control Techniques A.S.**  
Elektronvej 1  
2670 Greve

Tel: [45] 4369 6100  
Fax: [45] 4369 6101  
After Hours: [45] 4369 6100

## AUSTRIA - Linz Drive Centre



**Control Techniques GesmbH**  
Traunferstraße 109  
A-4052 Ansfelden

Tel: [43] 7229 789480  
Fax: [43] 7229 7894810  
After Hours: [43] 7215 3502

## DENMARK - Århus (Mid Jylland) Sales Office



**Control Techniques A.S**  
Elkærvej 30  
8230 Åbyhøj

Tel: [45] 8625 5755  
Fax: [45] 8625 1755  
After Hours: [45] 4369 6100

## BELGIUM - Brussels Drive Centre



**Control Techniques NV/SA**  
Hoge Wei 1  
1930 ZAVENTEM

Tel: [32] 2725 2721  
Fax: [32] 2725 4940

## EGYPT - Cairo

**Samiram**  
7 El Shahid Abdel Moneim Riad St  
El Mohandessin  
Cairo

Tel: [202] 360 5950  
Fax: [202] 360 8019

## BRAZIL - Sao Paulo

**ACIEL Comercio e Servicos Ltda**  
Rua Nazare Rezak Farah 51  
CEP 04367-050 Vila Santa Catarina  
Sao Paulo - SP

Tel & Fax: [55] 11 5565 5798

## FINLAND - Helsinki Drive Centre



**SKS-Control Techniques**  
Martinkyläntie 50  
P O Box 122  
FIN-01721 VANTAA

Tel: [358] 985 2661  
Fax: [358] 985 26823  
After Hours: [358] 500 423271

## CANADA - Toronto Drive Centre



**Control Techniques Canada Ltd**  
9999 Highway 48  
Markham  
Ontario L3P 3J3

Tel: [1] 905 475 4699  
Fax: [1] 905 475 4694

## FRANCE - Angouleme Drive Centre



**Leroy Somer**  
Usine des Agriers  
16015 Angouleme Cedex

Tel: [33] 54564 5454  
Fax: [33] 54564 5400

## CHILE - Santiago

**Comercial Leroy Somer Ltda**  
Avenida Providencia 1387  
Piso 5 - Oficina 7  
Providencia  
Santiago 9

Tel: [56] 2 2360001  
Fax: [56] 2 2363414

## GERMANY - Stuttgart Drive Centre



**Control Techniques GmbH**  
Max-Eyth-Straße 23  
D-71254 Ditzingen-Hirschlanden

Tel: [49] 7156 95560  
Fax: [49] 7156 955698

## CHINA - Shanghai Drive Centre



**Emerson Engineering Systems Shanghai (Co) Ltd**  
Control Techniques China  
227 Caobao Road  
Shanghai 200233

Tel: [86] 21 64085747  
Fax: [86] 21 64083282

## GERMANY - Bonn Drive Centre



**Control Techniques GmbH**  
Meysstrasse 20  
D53773 Hennef

Tel: [49] 2242 8770  
Fax: [49] 2242 877277

### GERMANY - Darmstadt Drive Centre



**Control Techniques GmbH**  
Rodensteinstr. 19  
D 64625 Bensheim

Tel: [49] 6251 1770-0  
Fax: [49] 6251 1770-98

### GERMANY - Chemnitz Drive Centre



**Control Techniques GmbH**  
Röhrsdorfer Allee 14  
D 09247 Röhrsdorf

Tel: [49] 3722 5203-0  
Fax: [49] 3722 5203-30

### GREECE - Athens

**Leroy Somer Ltd**  
Vasiladiou 2  
18540 Piraeus

Tel: [30] 1 42 25 815/816  
Fax: [30] 1 42 25 817

### HOLLAND - Rotterdam Drive Centre



**Control Techniques BV**  
P.O. Box 300  
3360 AH Sliedrecht

Tel: [31] 1844 20555  
Fax: [31] 1844 20721  
After Hours: [31] 1844 20555

### HONG KONG Sales Office



**Control Techniques China (Hong Kong)**  
20/F., Sing Pao Building  
101 King's Road  
North Point

Tel: [852] 2979 5271  
Fax: [852] 2979 5220

### HUNGARY - Budapest Drive Centre



**Control Technika Hungary Kft**  
H1108 Budapest, X. Veresegyház V3  
Budapest

Tel: [361] 265 7262  
Fax: [361] 260 5483

### ICELAND - Reykjavik

**Samey**  
Grandagandur 11  
101 Reykjavik

Tel: [354] 5623311  
Fax: [354] 5623356  
After Hours: [354] 5544318

### INDIA - Madras Drive Centre



**Control Techniques India Ltd**  
117B Developed Plot  
Industrial Estate  
Chennai 600-096  
Madras

Tel: [91] 44 4961123 / 4961130  
4961083  
Fax: [91] 44 4961602

### INDIA - Bombay Drive Centre



**Control Techniques Elpro Automation Ltd**  
Chinchwad Gaon  
Pune 411 033

Tel: [91] 212 751201 / 751202  
750930  
Fax: [91] 212 750105

### INDONESIA - Jakarta Drive Centre



**P.T. Kontroltek Indopratama**  
Jl. Kelapa Hibrida Raya  
Blok PD14 No 14-15  
Kelapa Gading Permai  
Jakarta Utara 14250

Tel: [62] 21 4525146  
Fax: [62] 21 4525142  
After Hours: [62] 81 6870443

### INDONESIA - Surabaya Drive Centre



**P.T. Kontroltek Indopratama**  
J.L. Mayjen Sungkono  
Korpus Wonokiri Indah  
Blok S-16  
Surabaya 60224

Tel: [62] 31 5682775 / 5623565  
Fax: [62] 31 5622402

### IRELAND - Dublin Drive Centre



**Electric Drives Ltd**  
Newbridge Industrial Estate  
Newbridge  
Co. Kildare

Tel: [353] (0) 45 433044  
Fax: [353] (0) 45 433622

### ISRAEL - Jerusalem

**DOR Drives Systems Ltd**  
Talpat Industrial Zone  
PO Box 10542  
Jerusalem 91102

Tel: [972] 2678 0984  
Fax: [972] 2678 2457

### ITALY - Milan Drive Centre



**Control Techniques SpA**  
Via Brodolini 7  
20069 Rozzano  
Milan

Tel: [39] 2575 751  
Fax: [39] 2575 12858  
After Hours: [39] 2575 751

### ITALY - Vicenza Drive Centre



**Control Techniques SpA**  
Via Ortigara 13  
36051 Creazzo (Vicenza)

Tel: [39] 444 396200  
Fax: [39] 444 341317

### KOREA - Seoul Drive Centre



**Control Techniques Korea**  
4 Floor, Sehwa Building  
66-9 Nonhyun-Dong  
Kangnam-Ku  
Seoul

Tel: [82] 2 344 56183/84/85  
Fax: [82] 2 344 56181  
After Hours: [82] 17 345 6183

### MALAYSIA - Kuala Lumpur Drive Centre



**Control Techniques Drives (Malaysia) Sdn Bhd**  
11 Jalan PJS 11/18  
Bandar Sunway  
46150 Petaling Jaya, Selangor Darul Ehsan

Tel: [60] 3734 9776  
Fax: [60] 3733 9592

### MOROCCO - Casablanca

**Leroy Somer Maroc**  
Angle Rue El Gara & Rue El Haouza  
Oukacha  
Roches Noires  
Casablanca

Tel: [212] 2 354948 / 354772  
359677 / 359680  
Fax: [212] 2 354956

## NEW ZEALAND - Napier

**Vectron Technologies Ltd** Tel: [64] 6843 1400  
PO Box 342 Fax: [64] 6843 0398  
Napier

## NORWAY - Oslo Drive Centre

**ASI Control Techniques A.S.** Tel: [47] 32 23 5100  
Ingv. Ludvigsensgt 23 Fax: [47] 32 23 5101  
P.O. Box 7044 After Hours: [47] 96 71 7412  
N-3007 Drammen

## PAKISTAN - Lahore

**Arden Engineering & Automation** Tel: [92] 42 5710811/873429  
11, Canal Park Fax: [92] 42 5712798/7235360  
Gulberg 11,  
Lahore 54660

## PHILIPPINES

**Ampere Technology Inc** Tel: [63] 2 893 3483 / 894 5816  
Suite 181, Cityland X Fax: [63] 2 894 5401  
Tower II, 6817 Ayala Ave  
Makati, Metro Manila

## POLAND - Warszawa

**SELS s.c.** Tel: [48] 22 480842  
ul. Malawskiego 5a Fax: [48] 22 481648  
02-641 Warszawa After Hours: [48] 22 481648

## PORTUGAL - Porto

**Harker Sumner S.A.** Tel: [351] 2200 7054  
Rua de Ceuta 38/48 Fax: [351] 2320510  
Apartado 4075  
4001 Porto Codex

## REP. OF S. AFRICA - Johannesburg Drive Centre

**Siliconics (Pty) Ltd** Tel: [27] 11 462 1740  
PO Box 3215 Fax: [27] 11 462 1941  
Honeydew 2040  
Johannesburg

## SAUDI ARABIA

**A.Abunayyan Elec. Corp** Tel: [966] 1 47 79 111  
PO Box 321 Fax: [966] 1 47 93 312  
Riyadh 11411

## SINGAPORE Drive Centre

**Control Techniques Singapore Pte Ltd** Tel: [65] 271 6377  
#11-01 Henderson Industrial Park Fax: [65] 272 1302  
219 Henderson Road After Hours: [65] 709 9512  
Singapore 159556

## SLOVENIA - Ljubljana

**PS Logatec** Tel: [386] 61 742016  
podjetje za projektiranje Fax: [386] 61 743487  
in izdelavo strojev, d.o.o.  
SI-1370 Logatec  
Trzaska 87b

## SPAIN - Barcelona Drive Centre

**Control Techniques Iberia S.A.** Tel: [34] 3 680 1661  
Carrer de Llobregat, Nave 8 Fax: [34] 3 680 0903  
Poligono Industrial El Pla After Hours: [34] 3 238 0581  
08750 Molins de Rei  
(Barcelona)

## SRI LANKA - Colombo

**Harvest Engineering (Pvt) Ltd** Tel: [941] 686040  
28 W.A.D. Ramanayake Mawatha Fax: [941] 686693 / 573104 / 693272  
Colombo After Hours: [941] 503283

## SWEDEN - Stockholm Drive Centre

**Styrkonsult - Control Techniques** Tel: [46] 8 58 352045  
Box 2125, Fabriksvagen 5-7 Fax: [46] 8 58 353223  
Kallhall S-17602 Jarfalla

## SWITZERLAND - Zurich Drive Centre

**CTS Control Techniques GmbH** Tel: [41] 56 493 0036  
Im Langacker 31 Fax: [41] 56 493 0068  
5405 Baden-Dattwil After Hours: [41] 21 634 0408

## TAIWAN - Taipei Sales Office

**Control Techniques Taiwan** Tel: [886] 2 3259555  
6 Floor, No. 2 Jen Ai Road Fax: [886] 2 7029630  
Section 4  
Taipei

## TAIWAN - Taipei

**Scientrade Enterprise Co Ltd** Tel: [886] 2 753100 1 to 9  
7F-2 No.123 Section 4 Fax: [886] 2 7470464  
Pa The Road, Taipei  
Taiwan  
Republic of China

## THAILAND - Bangkok Drive Centre

**Control Techniques Thailand Ltd** Tel: 66 2580 7644  
99/77-72 Prachachuen Road Fax: 66 2591 4559  
Ladyao, Jattujak After Hours: 66 2591 4559  
Bangkok 10900

## TURKEY - Istanbul Drive Centre

**Control Techniques Endustriyel Kontrol Sistemleri** Tel: [90] 216 4182420  
Sanayii Ve Ticaret A. S. Fax: [90] 216 4182423  
Kayisdagi Cad, Poyraz Sok, Er Togay Is Merkezi 4/24  
81040 Kadikoy, Istanbul

## U.A.E. - Dubai

**Leroy Somer Middle East**  
Division of Emerson M.E. Inc.  
PO Box 17034 Jebel Ali  
Dubai

Tel: [971] 4 838 650  
Fax: [971] 4 838 651

## U.K. - Leeds Drive Centre

**Control Techniques**  
Latchmore Industrial Park  
Howfields Road  
Leeds, West Yorkshire  
LS12 6DN

Tel: [44] 113 2423400  
Fax: [44] 113 2423892  
After Hours: [44] 113 2423400

## U.K. - Birmingham Drive Centre

**Control Techniques**  
Junction 2 Industrial Estate  
Dermuth Way  
Oldbury, Warley  
West Midlands, B69 4 1

Tel: [44] 121 544 5595  
Fax: [44] 121 544 5204  
After Hours: [44] 121 544 5595

## U.K. - Luton Drive Centre

**Control Techniques**  
Unit 26 North Luton Industrial Estate  
Sedgwick Road  
Luton  
Bedfordshire LU4 9DT

Tel: [44] 1582 583322  
Fax: [44] 1582 575156  
After Hours: [44] 1582 583322

## U.K. - Northampton

**Control Techniques Precision Systems Ltd**  
81-83 Tenter Road  
Moulton Park, Northampton  
Northants NN3 6AX

Tel: [44] 1604 646333  
Fax: [44] 1604 642225  
After Hours: [44] 1604 491700

## URUGUAY - Montevideo

**Secoin S.A.**  
Grafi Aguilar 1270 Bis  
C.P. 11800  
Montevideo

Tel: [5982] 293815 / 230850  
Fax: [5982] 292584

## U.S.A. - Providence Drive Centre

**Control Techniques Drives Inc**  
4 Blackstone Valley Place  
Lincoln  
Rhode Island 02865

Tel: [1] 401 333 3331  
Fax: [1] 401 333 6330  
After Hours: [1] 401 333 0080

## U.S.A. - Charlotte Drive Centre

**Control Techniques Drives Inc**  
2716 Interstate Street  
Charlotte  
North Carolina 28208

Tel: [1] 704 393 3366  
Fax: [1] 704 393 0900  
After Hours: [1] 716 692 2442

## U.S.A. - Dallas Drive Centre

**Control Techniques Drives Inc**  
1226 Exchange Drive  
Richardson  
Texas 75081

Tel: [1] 972 783 1831  
Fax: [1] 972 783 9978  
After Hours: [1] 800 459 0664

## U.S.A. - Cleveland Drive Centre

**Control Techniques Drives Inc**  
6892 West Snowville Road  
Brecksville  
Cleveland  
Ohio 44141

Tel: [1] 216 717 0123  
Fax: [1] 216 717 0133

## U.S.A. - Chicago Drive Centre

**Control Techniques Drives Inc**  
95 Brandon Court  
Glendale Heights  
Illinois 60139

Tel: [1] 630 893 5249  
Fax: [1] 630 893 4156

## U.S.A. - Cincinnati Drive Centre

**Control Techniques Drives Inc**  
1125 Petersburg Road  
Hebron, KY 41048

Tel: [1] (606) 689 4900  
Fax: [1] (606) 689 5344

## U.S.A. - San Francisco Drive Centre

**ADI - Control Techniques Inc**  
2512 Tripaldi Way  
Hayward  
California 94545

Tel: [1] 510 264 4940  
Fax: [1] 510 264 4949

## U.S.A. - Los Angeles Sales Office

**Control Techniques Drives Inc**  
12222 Bell Ranch Drive  
Santa Fe Springs  
CA 90670

Tel: [1] 310 906 3945  
Fax: [1] 310 941 3529

## VIETNAM - Hanoi Drive Centre

**Control Techniques Vietnam (Hanoi)**  
52/40 Nghia Tan Tu Liem  
Hanoi

Tel: [84] 4 834 5349  
Fax: [84] 4 836 4981  
After Hours: [84] 4 8346 914

## VIETNAM - Ho Chi Minh Drive Centre

**Control Techniques Vietnam Co Ltd**  
(Ho Chi Minh)  
70A Truong Cong Dinh St  
Tan Binh District, Ho Chi Minh City

Tel/Fax: [84] 8 8425157

## YUGOSLAVIA

**Sever**  
24000 Subotica  
Magneta Polja 6

Tel: [381] 24 45333 / 24 42705  
Fax: [381] 24 41941

