



EMERSON[™]
Industrial Automation



User Guide

Unidrive **SP**

Elevator Solution

Universal Variable Speed AC
Drive for induction and servo
motors

Part Number: 0471-0073-02
Issue: 2



www.controltechniques.com

General Information

The manufacturer accepts no liability for any consequences resulting from inappropriate, negligent or incorrect installation or adjustment of the optional operating parameters of the equipment or from mismatching the variable speed drive with the motor.

The contents of this guide are believed to be correct at the time of printing. In the interests of a commitment to a policy of continuous development and improvement, the manufacturer reserves the right to change the specification of the product or its performance, or the contents of the guide, without notice.

All rights reserved. No parts of this guide may be reproduced or transmitted in any form or by any means, electrical or mechanical including photocopying, recording or by an information storage or retrieval system, without permission in writing from the publisher.

Drives

Software version

This product is supplied with the latest software version. If this drive is to be connected to an existing system or machine, all drive software versions should be verified to confirm the same functionality as drives of the same model already present. This may also apply to drives returned from a Control Techniques Service Centre or Repair Centre.

The software version of the drive can be checked by looking at Pr **11.29** and Pr **11.34**. i.e. for software version 01.01.00, Pr **11.29** = 1.01 and Pr **11.34** displays 0. The software version takes the form of xx.yy.zz where Pr **11.29** displays xx.yy and Pr **11.34** displays zz. If there is any doubt please contact the supplier of the product.

Elevator Solution Software version

The Elevator Solution Software version and identity number for the Solutions Module can be viewed in Pr **0.28 [1]**, Pr **20.01 Software version** and Pr **0.29 [1]**, Pr **20.02 Software identity number**.

If there is any doubt, contact a Control Techniques Drive Centre.

Environmental statement

Control Techniques is committed to minimising the environmental impacts of its manufacturing operations and of its products throughout their life cycle. To this end, we operate an Environmental Management System (EMS) which is certified to the International Standard ISO 14001. Further information on the EMS, our Environmental Policy and other relevant information is available on request, or can be found at www.greendrives.com.

The electronic variable-speed drives manufactured by Control Techniques have the potential to save energy and (through increased machine/process efficiency) reduce raw material consumption and scrap throughout their long working lifetime. In typical applications, these positive environmental effects far outweigh the negative impacts of product manufacture and end-of-life disposal.

Nevertheless, when the products eventually reach the end of their useful life, they can very easily be dismantled into their major component parts for efficient recycling. Many parts snap together and can be separated without the use of tools, while other parts are secured with conventional screws. Virtually all parts of the product are suitable for recycling.

Product packaging is of good quality and can be re-used. Large products are packed in wooden crates, while smaller products come in strong cardboard cartons which themselves have a high recycled fibre content. If not re-used, these containers can be recycled. Polythene, used on the protective film and bags for wrapping product, can be recycled in the same way. Control Techniques' packaging strategy favours easily-recyclable materials of low environmental impact, and regular reviews identify opportunities for improvement.

When preparing to recycle or dispose of any product or packaging, please observe local legislation and best practice.

REACH legislation

EC Regulation 1907/2006 on the Registration, Evaluation, Authorisation and restriction of Chemicals (REACH) requires the supplier of an article to inform the recipient if it contains more than a specified proportion of any substance which is considered by the European Chemicals Agency (ECHA) to be a Substance of Very High Concern (SVHC) and is therefore listed by them as a candidate for compulsory authorisation.

For current information on how this requirement applies in relation to specific Control Techniques products, please approach your usual contact in the first instance. Control Techniques position statement can be viewed at:

<http://www.controltechniques.com/REACH>

How to use this guide

This user guide provides detailed information on the Elevator Solution Software used with Unidrive SP with the SM-Applications / SM-Applications Lite.

The information is in logical order, taking the user through the features of the software to set-up and optimization.

NOTE

There are specific safety warnings in Chapter 1 *Safety information* . It is essential that the warnings are observed and the information considered when working with or designing a system using the Unidrive SP.

NOTE

This manual should be read in line with the *Unidrive SP User Guide*.

The following map of the user guide helps in finding the correct sections for the task you wish to complete:

	Familiarization	Configuration	Programming and commissioning	Optimization	Troubleshooting
1 Safety information	●	●	●		●
2 General	●	●			
3 Installation		●			
4 Elevator Solution Software	●		●		●
5 I/O configuration	●	●	●		●
6 Basic operation	●				
7 Parameters	●	●	●	●	●
8 Set-up			●		
9 Optimization				●	●
10 SMARTCARD operation					
11 Commissioning software tools	●		●		
12 Diagnostics					●

Contents

1	Safety information	5	5	I/O configuration	53
1.1	Warnings, cautions and notes	5	5.1	Unidrive SP control terminals	53
1.2	Electrical safety - general warning	5	5.2	Motor thermistor input	54
1.3	System design and safety of personnel	5	5.3	Speed selection	55
1.4	Environmental limits	5	5.4	Control terminal status	56
1.5	Compliance with regulations	5	5.5	Logic diagrams	57
1.6	Motor	5	6	Basic operation	60
1.7	Adjusting parameters	5	6.1	Understanding the display	60
1.8	Warnings	5	6.2	Keypad operation	60
1.9	Caution	7	6.3	SM-Keypad Plus	62
2	General	8	6.4	Operation	62
2.1	Elevator system - Unidrive SP and elevator controller	8	6.5	Menu structure	64
2.2	Elevator Solution Software	9	6.6	Menu 0	64
2.3	Set-up and commissioning tools	10	6.7	Advanced menus	65
2.4	Identification	11	6.8	Programming parameters from the SMARTCARD	66
2.5	Unidrive SP options	11	6.9	Transferring data	66
3	Installation	14	6.10	Changing the operating mode	67
3.1	Installation of Solutions Modules	14	6.11	Saving parameters	67
3.2	Control connections	15	6.12	Restoring parameter defaults	68
3.3	Encoder support	16	6.13	Restoring Elevator Solution Software defaults	68
3.4	Position feedback devices and installation	17	6.14	Parameter access level and security	68
3.5	Configuring the feedback device (Closed loop)	20	6.15	Displaying parameters with non-default values only	68
4	Elevator Solution Software	22	6.16	Displaying destination parameters only	68
4.1	Positioning profile	22	6.17	Serial communications	68
4.2	Positioning mode	22	6.18	Setting of motor and elevator parameters	70
4.3	Features	22	7	Parameters	72
4.4	Creep-to-floor operation	24	7.1	Parameter access / security code	72
4.5	Direct-to-floor operation	26	7.2	Elevator Solution Software status	72
4.6	Start optimization	27	7.3	Advanced parameters	72
4.7	Floor sensor correction (Closed loop)	28	7.4	Defaults	72
4.8	Peak curve operation (Closed loop)	31	7.5	Drive mode change	72
4.9	Short floor landing (Creep-to-floor)	31	7.6	Menu 0 parameter structure	73
4.10	Fast stop	31	7.7	Elevator drive F menu parameters	78
4.11	Fast start function (Closed loop)	32	7.8	Menu 18 parameters	81
4.12	Nominal elevator rpm calculation	32	7.9	Menu 19 parameters	97
4.13	Load measurement (Closed loop)	33	7.10	Menu 20 parameters	114
4.14	Load cell compensation	34	7.11	Menu 21 parameters	127
4.15	Inertia compensation	34	8	Set-up	131
4.16	Variable speed loop gains, current loop gains, current loop filters (Closed loop)	35	8.1	Autotune	131
4.17	Variable stator resistance control (Open loop)	40	8.2	First start with empty car	134
4.18	Brake control	41	9	Optimization	136
4.19	Advanced door opening	43	9.1	Open loop vector	136
4.20	Motor contactor control	43	9.2	Closed loop vector	137
4.21	Blocked elevator releasing	45			
4.22	Emergency evacuation operation	46			

10	SMARTCARD operation	139
10.1	Introduction	139
10.2	Transferring data	140
10.3	Data block header information	141
10.4	SMARTCARD parameters	142
10.5	SMARTCARD trips	143
11	Commissioning software tools	145
11.1	CTSoft	145
11.2	CTScope	145
11.3	Elevator-SP	146
12	Diagnostics	148
12.1	Display	148
12.2	Elevator specific diagnostics	149
12.3	Error detection	149
12.4	Unidrive SP trip codes	153
12.5	Alarm indications	167
12.6	Status indications	168
12.7	Displaying the trip history	168
	Index	169

1 Safety information

1.1 Warnings, cautions and notes



A Warning contains information which is essential for avoiding a safety hazard.

WARNING



A Caution contains information which is necessary for avoiding a risk of damage to the product or other equipment.

CAUTION

NOTE

A Note contains information which helps to ensure correct operation of the product.

1.2 Electrical safety - general warning

The voltages used in the drive can cause severe electrical shock and/or burns, and could be lethal. Extreme care is necessary at all times when working with or adjacent to the drive.

Specific warnings are given at the relevant places in this User Guide.

1.3 System design and safety of personnel

The drive is intended as a component for professional incorporation into complete equipment or a system. If installed incorrectly, the drive may present a safety hazard.

The drive uses high voltages and currents, carries a high level of stored electrical energy, and is used to control equipment which can cause injury.

Close attention is required to the electrical installation and the system design to avoid hazards either in normal operation or in the event of equipment malfunction. System design, installation, commissioning/start-up and maintenance must be carried out by personnel who have the necessary training and experience. They must read this safety information and this User Guide carefully.

The STOP and SAFE TORQUE OFF (SECURE DISABLE) functions of the drive do not isolate dangerous voltages from the output of the drive or from any external option unit. The supply must be disconnected by an approved electrical isolation device before gaining access to the electrical connections.

With the sole exception of the SAFE TORQUE OFF (SECURE DISABLE) function, none of the drive functions must be used to ensure safety of personnel, i.e. they must not be used for safety related functions.

Careful consideration must be given to the functions of the drive which might result in a hazard, either through their intended behavior or through incorrect operation due to a fault. In any application where a malfunction of the drive or its control system could lead to or allow damage, loss or injury, a risk analysis must be carried out, and where necessary, further measures taken to reduce the risk - for example, an over-speed protection device in case of failure of the speed control, or a fail-safe mechanical brake in case of loss of motor braking.

The SAFE TORQUE OFF (SECURE DISABLE) function has been approved¹ as meeting the requirements of EN954-1 category 3 for the prevention of unexpected starting of the drive. It may be used in a safety-related application. **The system designer is responsible for ensuring that the complete system is safe and designed correctly according to the relevant safety standards.**

¹Independent approval by BGIA has been given.

1.4 Environmental limits

Instructions in the *Unidrive SP User Guide* regarding transport, storage, installation and use of the drive must be complied with, including the specified environmental limits. Drives must not be subjected to excessive physical force.

1.5 Compliance with regulations

The installer is responsible for complying with all relevant regulations, such as national wiring regulations, accident prevention regulations and electromagnetic compatibility (EMC) regulations. Particular attention must be given to the cross-sectional areas of conductors, the selection of fuses or other protection, and protective earth (ground) connections.

Within the European Union, all machinery in which this product is used must comply with the following directives:

98/37/EC: Safety of machinery.

2004/108/EC: Electromagnetic Compatibility.

95/16/EC: Elevators Directive.

1.6 Motor

Ensure the motor is installed in accordance with the manufacturer's recommendations. Ensure the motor shaft is not exposed.

Standard squirrel cage induction motors are designed for single speed operation. If it is intended to use the capability of the drive to run a motor at speeds above its designed maximum, it is strongly recommended that the manufacturer is consulted first.

Low speeds may cause the motor to overheat because the cooling fan becomes less effective. The motor should be installed with a protection thermistor. If necessary, an electric forced vent fan should be used.

The values of the motor parameters set in the drive affect the protection of the motor. The default values in the drive should not be relied upon.

It is essential that the correct value is entered in parameter **0.46** motor rated current. This affects the thermal protection of the motor.

1.7 Adjusting parameters

Some parameters have a profound effect on the operation of the drive. They must not be altered without careful consideration of the impact on the controlled system. Measures must be taken to prevent unwanted changes due to error or tampering.

1.8 Warnings



Competence of the installer
The drive must be installed by professional assemblers who are familiar with the requirements for safety and EMC. The assembler is responsible for ensuring that the end product or system complies with all the relevant laws in the country where it is to be used.

WARNING



Follow the instructions
The **mechanical and electrical installation** instructions in the *Unidrive SP User Guide* must be adhered to. Any questions or doubt should be referred to the supplier of the equipment. It is the responsibility of the owner or user to ensure that the installation of the drive and any external option unit, and the way in which they are operated and maintained, comply with the requirements of the Health and Safety at Work Act in the United Kingdom or applicable legislation and regulations and codes of practice in the country in which the equipment is used.

WARNING



Fuses

The AC supply to the drive must be installed with suitable protection against overload and short-circuits. The *Unidrive SP User Guide* shows recommended fuse ratings. Failure to observe this requirement will cause risk of fire.



The **ground loop impedance** must conform to the requirements of local safety regulations.
The drive must be grounded by a connection capable of carrying the prospective fault current until the protective device (fuse, etc.) disconnects the AC supply.
The ground connections must be inspected and tested at appropriate intervals.



Only **type B ELCB / RCD** are suitable for use with 3 phase inverter drives.



A **fuse** or other over-current protection should be installed to the relay circuit.



Electric shock risk

The voltages present in the following locations can cause severe electric shock and may be lethal:

- AC supply cables and connections
 - DC and brake cables, and connections
 - Output cables and connections
 - Many internal parts of the drive, and external option units
- Unless otherwise indicated, control terminals are single insulated and must not be touched.



Stored charge

The drive contains capacitors that remain charged to a potentially lethal voltage after the AC supply has been disconnected. If the drive has been energized, the AC supply must be isolated at least ten minutes before work may continue.

Normally, the capacitors are discharged by an internal resistor. Under certain, unusual fault conditions, it is possible that the capacitors may fail to discharge, or be prevented from being discharged by a voltage applied to the output terminals. If the drive has failed in a manner that causes the display to go blank immediately, it is possible the capacitors will not be discharged. In this case, consult Control Techniques or their authorized distributor.



Isolation device

The AC supply must be disconnected from the drive using an approved isolation device before any cover is removed from the drive or before any servicing work is performed.



Users must not attempt to repair a drive if it is faulty, nor carry out fault diagnosis other than through the use of the diagnostic features described in Chapter 12 *Diagnostics*. If a drive is faulty, it must be returned to an authorized Control Techniques distributor for repair.



Do not change **parameter values** without careful consideration; incorrect values may cause damage or result in a safety hazard.



If the drive has been used at high load levels for a period of time, the heatsink can reach **temperatures in excess of 70°C (158°F)**. Human contact with the heatsink should be prevented.



STOP function SAFE TORQUE OFF (SECURE DISABLE) function

The STOP function does not remove dangerous voltages from the drive, the motor or any external option units.



Pr **0.46 Motor rated current** must be set correctly to avoid a risk of fire in the event of motor overload.



If the cable between the drive and the motor is to be **interrupted by a contactor or circuit breaker**, ensure that the drive is disabled before the contactor or circuit breaker is opened or closed. Severe arcing may occur if this circuit is interrupted with the motor running at high current and low speed, and result in possible drive failure if repeatedly carried out.



Permanent magnet motors

Permanent magnet motors generate electrical power if they are rotated, even when the supply to the drive is disconnected. If that happens then the drive will become energized through its motor terminals.
If the motor load is capable of rotating the motor when the supply is disconnected, then the motor must be isolated from the drive before gaining access to any live parts.



SAFE TORQUE OFF (SECURE DISABLE) inhibits the operation of the drive, this includes inhibiting braking. If the drive is required to provide both braking and SAFE TORQUE OFF (SECURE DISABLE) in the same operation (e.g. for emergency stop) then a safety timer relay or similar device must be used to ensure that the drive is disabled a suitable time after braking. The braking function in the drive is provided by an electronic circuit which is not fail-safe. If braking is a safety requirement, it must be supplemented by an independent fail-safe braking mechanism.



A **rotating autotune** in closed loop mode will cause the motor to accelerate up to $\frac{2}{3}$ base speed in the direction selected regardless of the reference provided. Once complete the motor will coast to a stop. The run signal must be removed before the drive can be made to run at the required reference. The drive can be stopped at any time by removing the run signal or removing the drive enable.



The short low speed and normal low speed autotune tests in servo mode will rotate the motor by up to 2 revolutions in the direction selected, regardless of the reference provided. The minimal movement test will move the motor through an angle defined by Pr **5.38**.
Once complete the motor will come to a standstill. The run signal must be removed before the drive can be made to run at the required reference.
The drive can be stopped at any time by removing the run signal or removing the Drive Enable.



Encoder phase angle (servo mode only)

With drive software version V01.08.00 onwards, the encoder phase angles in Pr **3.25** and Pr **21.20** are copied to the SMARTCARD when using any of the SMARTCARD transfer methods.

With drive software version V01.05.00 to V01.07.01, the encoder phase angles in Pr **3.25** and Pr **21.20** are only copied to the SMARTCARD when using either Pr **0.30** set to Prog (2) or Pr **xx.00** set to 3yyy.

This is useful when the SMARTCARD is used to back-up the parameter set of a drive but caution should be used if the SMARTCARD is used to transfer parameter sets between drives. Unless the encoder phase angle of the servo motor connected to the destination drive is known to be the same as the servo motor connected to the source drive, an autotune should be performed or the encoder phase angle should be entered manually into Pr **3.25** (or Pr **21.20**). If the encoder phase angle is incorrect the drive may lose control of the motor resulting in an O.SPd or Enc10 trip when the drive is enabled.

With drive software version V01.04.00 and earlier, or when using software version V01.05.00 to V01.07.01 and Pr **xx.00** set to 4yyy is used, then the encoder phase angles in Pr **3.25** and Pr **21.20** are not copied to the SMARTCARD. Therefore, Pr **3.25** and Pr **21.20** in the destination would not be changed during a transfer of this data block from the SMARTCARD.



The control circuits are isolated from the power circuits in the drive by basic insulation (single insulation) only. The installer must ensure that the external control circuits are insulated from human contact by at least one layer of insulation (supplementary insulation) rated for use at the AC supply voltage.



If the **control circuits** are to be connected to other circuits classified as Safety Extra Low Voltage (SELV) (e.g. to a personal computer), an additional isolating barrier must be included in order to maintain the SELV classification.



To avoid the **risk of fire** when the drive is surface mounted with the braking resistor installed, the back plate should be a non-flammable material.



Overload protection

When an external braking resistor is used, it is essential that an overload protection device is incorporated in the braking resistor circuit to prevent the risk of fire; this is described in the *Unidrive SP User Guide*.

1.9 Caution



This is a product of the restricted distribution class according to **IEC 61800-3**

In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.



The **second environment** typically includes an industrial low-voltage power supply network which does not supply buildings used for domestic purposes. Operating the drive in this environment without an external EMC filter may cause interference to nearby electronic equipment whose sensitivity has not been appreciated. The user must take remedial measures if this situation arises. If the consequences of unexpected disturbances are severe, it is recommended that the guidelines in the *Unidrive SP User Guide* are adhered to.




Power down the drive before **fitting / removing Solutions Modules**. Failure to do so may result in damage to the product.

2 General

Unidrive SP is a high performance drive which can operate in open loop, closed loop vector and servo modes making it an excellent choice for elevator applications. It is compatible with a wide range of feedback devices including encoders, and resolvers. The drive also supports a wide range of communications including RS485 (DCP3 and DCP4) and CanOpen. In addition the standard I/O on the drive can be expanded using one of the range of I/O Solutions Modules. The Unidrive SP has three Solutions Modules slots available to further expand the standard drives capabilities.

Figure 2-1 shows the Unidrive SP incorporated into an elevator system using the Solutions Module and Elevator Solution Software. In addition a resolver feedback Solutions Module and extended I/O Solutions Modules are also shown.

Figure 2-1 Elevator system



2.1 Elevator system - Unidrive SP and elevator controller

The Elevator Solution Software is introduced onto the Unidrive SP using either an SM-Applications or Applications Lite. The SM-Applications Lite is used for the standard Elevator Solution Software. The SM-Applications would be used where additional features are required in addition to the standard Elevator Solution Software, e.g. extended user memory, RS485 interface or DCP control.

The Unidrive SP Elevator Solution Software incorporates a travel profile calculator with a special operating level designed specifically for elevators. This has features allowing it to be used for both geared and gearless elevators with induction or permanent magnet motors. The default operating mode for the Unidrive SP Elevator Solution Software is open loop vector, however this can be re-configured for either closed loop vector or closed loop servo.

The Elevator Solution Software generates a velocity motion profile, which includes elevator application specific functions. The Unidrive SP is controlled via a digital interface from the elevator controller. The Elevator Solution Software receives control signals from the elevator controller, and derives both speed and direction signals along with brake control, motor contactor control and door opening signals. The elevator controller could control features such as the brake control, motor contactor control and door opening in place of the Unidrive SP if required.

NOTE

The Unidrive SP drive also has sensorless closed loop vector mode (RFC), which allows closed loop operation with no position feedback. RFC mode also allows a closed loop system to continue to operate under a fault condition i.e. loss of encoder feedback.

NOTE

The elevator controller provides all the safety related functions in the elevator system.

2.2 Elevator Solution Software

The Elevator Solution Software is programmed into either the SM-Applications or SM-Applications Lite and runs within the second processor. The software can be configured to operate in either creep-to-floor or direct-to-floor positioning modes. The default positioning mode and most commonly used is creep-to-floor Pr **0.16[3]**, Pr **20.13** = 0.

The elevator controller evaluates the elevator landing calls and shaft signals then generates the required control signals to the Unidrive SP and Elevator Solution Software. The Elevator Solution Software receives the travel commands and continually modifies the profile for the required travel and ride comfort.

The Elevator Solution Software generates the velocity motion profile including a number of additional features as listed in the following section:

Function	Description
Operating Mode	
Creep-to-floor	Default configuration creep-to-floor positioning.
Direct-to-floor	Optional configuration for high speed elevators using direct-to-floor positioning, reducing elevator journey times.
User Interface	
Text display (LCD Keypad)	Text strings allow commissioning and drive set-up without the need for a User Guide. Also provides additional help text.
Dedicated F Menu	Single menu can be used for set-up, commissioning and optimization.
Conventional units (mm/s, mm/s ²)	No conversion calculations required.
Digital signals	Digital I/O interface between elevator controller and Unidrive SP for direction and speed selection.
Analog signals	Analog input interface for control and external load cell connection, programmable outputs. No analog speed reference input is available with elevator software.
Speed Selection	
10 Binary speed selections	Flexible interface allowing for a range of speeds to be defined and selected.
6 Priority speed selections	
2 Speed thresholds	
Control	
Motor contactor control	Motor contactor control generated based on profile.
Brake control	Programmable brake control is available based on profile.
Advanced door opening	Advanced door opening is available which can reduce elevator journey times.
TUV approved SAFE TORQUE OFF (SECURE DISABLE)	TUV approval allows operation with dual single or zero motor contactors.

In addition to the standard features of the Elevator Solution Software there are also additional features that can be enabled expanding the functionality of the Elevator Solution Software further.

Function	Description
Advanced features	
Start locking position controller	Used for both geared and gearless systems to prevent movement of the motor during brake release at start.
Start optimizer	Used to overcome stiction from the elevator systems mechanical arrangement ensuring smooth starting.
Peak curve operation	Ensures constant stopping distance independent of when the stop signal is received
Floor sensor correction	Improved accurate distance correction available with floor sensor located around 50 to 500mm from floor level.
Short floor distance landing	Short floor landing should be used where floor distance is less than 0.7m.
Fast stop	Fast stop normally used for inspection and maintenance in manual operating mode.
Fast start	Allows a fast start by magnetizing the motor and controlling the brake during closing of the car doors.
Inertia compensation	Used to overcome system inertia.
Load compensation	A external load cell can be connected to Unidrive SP and Elevator Solution Software to be used for load compensation.
Load measurement	The load measurement feature measures the level of load and direction during every start, with this being used for rescue operation in the direction of least load.
Blocked car release	A function is available to detect a blocked car then to carry out release sequence on next start.
Emergency back-up operation	Back-up operation is available using a back-up power supply along with the load measurement feature available in the Elevator Solution Software.

Once the required Elevator Solution Software features have been enabled the performance can be optimized with the following features:

Function	Description
Optimization	
Separately adjustable jerks, acceleration and deceleration rates	All sections of the profile can be optimized individually.
Fixed and variable speed and current loop gains for Start, Travel and Positioning	Fixed or variable speed and current loop gains can be enabled. The variable gains being selected for systems with high levels of stiction, fast start and landing.
Multiple current loop filters for Start Travel and Positioning	With high Start and Stop gains acoustic noise could be generated from the motor dependant upon the feedback resolution. Multiple current loop filters can be introduced for each section of the elevator profile to minimise acoustic noise generated in these areas.

Diagnostics are also available within the Unidrive SP and Elevator Solution Software:

Function	Description
Diagnostics	
Speed error detection	Programmable speed error detection with trip.
Distance error detection	Programmable distance error detection with trip.
Thermal protection	Prevents operation below 0°C, provides warning with high motor temperatures.
Motor fluxed protection Motor contactor control	Motor fluxed detection, trip on under fluxed.
Motor phase loss detection	Motor phase loss, trip on detection.
SAFE TORQUE OFF (SECURE DISABLE) monitoring	Monitors the SAFE TORQUE OFF (SECURE DISABLE) input, trip if inoperative.
Fast disable monitoring	Monitors the fast disable input
Encoder connection reversed	Checks encoder direction with motor rotation.

2.3 Set-up and commissioning tools

The following options are available to assist with the set-up and commissioning of the Unidrive SP and Elevator Solution Software:

- CTSoft** This is a PC tool that interfaces to the Unidrive SP and allows all drive and Solutions Module parameters to be viewed. This allows parameters to be adjusted, uploaded and downloaded to the Unidrive SP and Elevator Solution Software whilst on-line, Parameter sets can also be saved.
- CTScope** This is a PC based oscilloscope that allows all parameters to be viewed in the drive and Solutions Modules. From this speed profiles, motor currents and control signals can be monitored during operation. Waveforms can be saved.
- Smartcard** The Unidrive SP uses a Smartcard that can copy and hold complete parameter sets from the drive and Elevator Solution Software. This option can be used for simple cloning from one elevator drive to another.
- LiftSP** This is a PC tool which has both an oscilloscope and profile / parameter set-up tool. Parameters can be monitored, modified and saved to file.

2.4 Identification

The SM-Applications or SM-Applications Lite for the elevator application must be programmed with the required Elevator Solution Software. The Elevator Solution Software version and identity number can be verified in the following parameters:

Elevator Solution Software version **F53**, Pr **0.28[1]**, Pr **20.01** software version in the form of xxx.


Elevator Solution Software identity **F54**, Pr **0.29[1]**, Pr **20.02** Software identity number in the form of xxxxx.

To verify the elevator software is running, monitor **F54**, Pr **0.29[1]**, Pr **20.02**. This should toggle every 1s between +10614 and -10614.

2.5 Unidrive SP options

Unidrive SP has a number of options that can be installed to further expand the flexibility of the drive. Various Solutions Modules are available and include Feedback, Fieldbus and Automation.

Figure 2-2 Unidrive SP options



* A SMARTCARD is provided with the Unidrive SP as standard.

All Unidrive SP Solutions Modules are color-coded in order to make identification easy. The following table shows the color-code key and gives further details on their function.

Table 2-1 Solutions Module identification

Type	Solutions Module	Colour	Name	Further Details
Feedback		Light Green	SM-Universal Encoder Plus	Universal Feedback interface Feedback interface for the following devices: Inputs <ul style="list-style-type: none"> • Incremental encoders • SinCos encoders • SSI encoders • EnDat encoders Outputs <ul style="list-style-type: none"> • Quadrature • Frequency and direction • SSI simulated outputs
		Light Blue	SM-Resolver	Resolver interface Feedback interface for resolvers. Simulated quadrature encoder outputs
		Dark Brown	SM-Encoder Output Plus	Incremental encoder interface Feedback interface for incremental encoders without commutation signals. Simulated encoder output for quadrature, frequency and direction signals
		N/A	15-way D-type converter	Drive encoder input converter Provides screw terminal interface for encoder wiring and spade terminal for shield
		N/A	Single ended encoder interface (15V or 24V)	Single ended encoder interface Provides an interface for single ended ABZ or UVW encoder signals, such as those from hall effect sensors. 15V and 24V versions are available.
		N/A	ERN1387 Encoder Interface Board	ERN1387 Encoder Provides support for SinCos encoders with an additional absolute track consisting of one sine, cosine signal per revolution like the ERN1387 or ERN487 encoders. The ERN1387 Encoder Interface board needs to be used in conjunction with the SM Universal Encoder Plus to allow full support.
Automation		Yellow	SM-I/O Plus	Extended I/O interface Increases the I/O capability by adding the following to the existing I/O in the drive: <ul style="list-style-type: none"> • Digital inputs x 3 • Digital I/O x 3 • Analog inputs (voltage) x 2 • Analog output (voltage) x 1 • Relay x 2
		Dark Green	SM-Applications	Applications Processor (with CTNet) 2 nd processor for running pre-defined and /or customer created application software with CTNet support
		White	SM-Applications Lite	Applications Processor 2 nd processor for running pre-defined and /or customer created application software
		Dark Yellow	SM-I/O Lite	Additional I/O 1 x Analog input (\pm 10V bi-polar or current modes) 1 x Analog output (0-10V or current modes) 3 x Digital input and 1 x Relay
Fieldbus		Pink	SM-CAN	CAN option CAN adapter for communications with the Unidrive SP
		Light Grey	SM-CANopen	CANopen option CANopen adapter for communications with the Unidrive SP
		Beige	SM-Ethernet	Ethernet option 10 base-T / 100 base-T; Supports web pages, SMTP mail and multiple protocols: DHCP IP addressing; Standard RJ45 connection

In addition to the Solutions Modules there are also two types of drive display, either LCD or LED, either of which can be selected for use with the Unidrive SP. It is recommended that the SM-Keypad Plus be used for the elevator drive where possible, as this provides both text strings and help data that simplifies set up and operation of the Unidrive SP with the Elevator Solution Software.

Table 2-2 Keypad identification

Type	Keypad	Name	Further Details
Keypad		SM-Keypad	LED keypad option Keypad with a LED display for size 1 and above
		SM-Keypad Plus	LCD keypad option Keypad with an alpha-numeric LCD display with Help function for size 1 and above (preferred option with additional keypad custom elevator text)
		SP0-Keypad	LED keypad option Keypad with a LED display for size 0 only

3 Installation

3.1 Installation of Solutions Modules



The Unidrive SP must be powered down before fitting or removing the SM-Applications or SM-Applications Lite with the Elevator Solution Software. In addition if an SM-Resolver, SM-I/O Plus or any other Solutions Modules are required, they also have to be installed while the Unidrive SP is powered down. Failure to do so may result in damage to the Unidrive SP or Solutions Module.

Figure 3-1 Unidrive SP Solution Module slots





Figure 3-2 Fitting and removal of Solutions Module



To fit the Solutions Module, press down in the direction shown above until it clicks into place.

To remove the Solutions Module, press inwards at the points shown (A) and pull in the direction shown (B).

The drive has the facility for all three Solutions Module slots to be used at the same time, as illustrated.

NOTE

It is recommended that the Solutions Module slots are used in the following order: slot 3, slot 2 and slot 1; this ensures maximum support for the Solutions Module when fitted.




Installation of the Unidrive SP drive should follow all recommendations detailed in the current *Unidrive SP User Guide*.

3.2 Control connections

The following diagram shows the control terminals for the Unidrive SP in its default configuration as a general purpose drive, and also when reconfigured as an elevator drive using the Solutions Module and Elevator Solution Software.

Figure 3-3 Control terminals



NOTE

The Unidrive SP drive operates in positive logic from default, negative logic control can be configured through Pr 8.29. The drives enable SAFE TORQUE OFF (SECURE DISABLE) input at control terminal T.31 cannot be reconfigured for negative logic and must always operate in positive logic.

3.3 Encoder support

Figure 3-4 Location of encoder connector




Table 3-1 Encoder types

Encoder Type (F03, Pr 3.38)		Description
Ab	0	Quadrature incremental encoder with or without a marker pulse.
Fd	1	Quadrature incremental encoder with frequency and direction pulses, with or without a marker pulse.
Fr	2	Quadrature incremental encoder with forward and reverse pulses, with or without a marker pulse.
Ab.SerVO	3	Quadrature incremental encoder with UVW commutation signals, with or without a marker pulse.
Fd.SerVO	4	Quadrature incremental encoder with frequency and direction pulses plus UVW commutation signals, with or without a marker pulse.
Fr.SerVO	5	Quadrature incremental encoder with forward and reverse pulses plus UVW commutation signals, with or without a marker pulse.
SC	6	SinCos encoder no marker pulse or serial communications
SC.HiPEr	7	SinCos encoder with HiPErface serial communications interface (Stegmann protocol)
EndAt	8	EndAt serial communications encoder (Heidenhain protocol)
SC.EndAt	9	SinCos encoder with EndAt serial communications interface (Heidenhain protocol)
SSI	10	SSI serial communications encoder
SC.SSI	11	SinCos encoder with SSI serial communications interface

Table 3-2 Additional encoder support

Encoder Type (F03, Pr 3.38)		Description
SerVO	N/A	Encoder with only UVW commutation signals. Set up requires Pr 3.38 = 3, 4 or 5, Pr 3.34 = 0 Drive Encoder Lines
SC.SerVO	N/A	SinCos encoder with UVW commutation signals. This encoder type is only supported on the SM-Universal Encoder Plus Solutions Modules.
SinCos + Reference Marker Signal	N/A	SinCos encoders like the ERN480 with a reference marker signal.
SinCos + additional absolute track	N/A	SinCos encoders like the ERN1387 or ERN487 with an additional absolute track.

Encoder types 0 through to 5 provide low-resolution feedback and should not be used for applications requiring high levels of performance.

When operating with a permanent magnet servo motor an absolute feedback device is required to derive position at power-up. Absolute feedback devices include the xx.SerVO, SC.xx, EndAt and SSI. If a standard incremental encoder Ab, Fd, Fr or SC is used when operating with a permanent magnet servo motor a phasing test is required at every power-up to derive the absolute position.

Table 3-3 Encoder connector details

Terminal	Encoder Type (F03, Pr 0.34[1], Pr 3.38)											
	Ab (0)	Fd (1)	Fr (2)	Ab.SERVO (3)	Fd.SERVO (4)	Fr.SERVO (5)	SC (6)	SC.HiPEr (7)	EndAt (8)	SC.EndAt (9)	SSI (10)	SC.SSI (11)
1	A	F	F	A	F	F	Cos			Cos		Cos
2	A\	F\	F\	A\	F\	F\	Cosref			Cosref		Cosref
3	B	D	R	B	D	R	Sin			Sin		Sin
4	B\	D\	R\	B\	D\	R\	Sinref			Sinref		Sinref
5	Z *							Encoder – Data (input/output)				
6	Z\ *							Encoder – Data\ (input/output)				
7	Simulated encoder A out, F out **			U			Simulated encoder A out, F out **					
8	Simulated encoder A\ out, F\ out **			U\			Simulated encoder A\ out, F\ out **					
9	Simulated encoder B out, D out **			V			Simulated encoder B out, D out **					
10	Simulated encoder B\ out, D\ out **			V\			Simulated encoder B\ out, D\ out **					
11							W		Encoder – Clock (output)			
12							W\		Encoder – Clock\ (output)			
13	+V ***											
14	0V common											
15	th ****											

* Marker pulse is optional

** Simulated encoder output (A, F, A\, F\ and B, D, B\, D\) only available in open loop mode

*** The encoder supply is selectable through parameter **F06**, Pr **0.33[1]**, **3.36** to 5, 8 or 15Vdc

**** Terminal 15 is a parallel connection to T.8 analog input 3 on the drives control connections. If this is to be used as a thermistor input, ensure that Pr **7.15** is set to 'th.sc' (7), 'th' (8) or 'th.diSP' (9).

NOTE

SSI encoders typically have maximum data rate of only 500k baud. When an SSI only encoder is used for speed feedback in closed loop operation, a speed feedback filter Pr **3.42** is required due to the time taken for the position information to be transferred from the encoder to the Unidrive SP. The addition of the speed feedback filter means that SSI only encoders are not suitable for speed feedback in applications that are dynamic or high-speed.

3.4 Position feedback devices and installation

This section covers the recommended shield and grounding connections for position feedback devices. These recommendations should be followed closely to prevent noise being induced onto the position feedback resulting in instability issues. Shielding considerations are important for PWM drive installations due to the high voltages and currents present in the output circuit with a very wide frequency spectrum, typically from 0 to 20 MHz. Position feedback devices and inputs are liable to be disturbed if careful attention is not given to managing the cable shields.

3.4.1 Cable shield requirements

- Feedback cable shields should be connected at drive terminal to 0V
- Feedback cable shield should be connected at encoder to 0V
- It is recommended that the shielded cable should be run in a continuous length to the terminal, to avoid the injection of noise at intermediate pigtailed and to maximize the shielding benefit.

NOTE

Due to emissions from high power cables (e.g. drive output) the feedback cable should not be run in parallel lengths with these for >1m at <300mm apart)

- The shield connections ("pigtailed") to the drive and encoder should be kept as short as possible




Connecting the cable shield to ground at both ends carries the risk that an electrical fault might cause excessive power current to flow in the cable shield and overheat the cable.

There must be an adequately rated safety ground connection between the motor / encoder and the drive.

Recommended cable

The recommended cable for feedback signals is a twisted pair, shielded with an overall shield as shown.


Figure 3-5 Feedback cable, twisted pair



Using this type of cable also allows for the connection of the outer shield to ground and the inner shields to 0V alone at both drive and encoder end, when required.

Figure 3-6 on page 18 shows the recommended arrangements for the cable shielding and grounding.

Figure 3-6 Feedback cable connections



In addition to the above connections shown, if it is found that there is still noise being passed to the encoder / resolver input it is possible to make a connection directly from 0V of the feedback device input at the drive to ground.

The ground connection can be connected directly to the grounding clamp / bracket as shown in the following.

3.4.2 Grounding hardware

The Unidrive SP is supplied with a grounding bracket, and sizes 0 to 3 with a grounding clamp, to facilitate EMC compliance. They provide a convenient method for direct grounding of cable shields without the use of "pig-tails". Cable shields can be bared and clamped to the grounding bracket using metal clips or clamps¹ (not supplied) or cable ties. Note that the shield must in all cases be continued through the clamp to the intended terminal at the drive, in accordance with the connection details for the specific signal.

¹ A suitable clamp is the Phoenix DIN rail mounted SK14 cable clamp (for cables with a maximum outer diameter of 14mm).

Figure 3-7 Use of the EMC bracket on size 0




Figure 3-8 Installation of grounding clamp (size 1 and 2)




Figure 3-9 Installation of grounding clamp (size 3)





Figure 3-10 Fitting of grounding bracket (sizes 1 to 6)



Loosen the ground connection nuts and slide the grounding bracket in the direction shown. Once in place, re-tighten the ground connection nuts.



On Unidrive SP size 1 and 2, the grounding bracket is secured using the power ground terminal of the drive. Ensure that the supply ground connection is secure after fitting / removing the grounding bracket. Failure to do so will result in the drive not being grounded.

A fastening tab is located on the grounding bracket for the purpose of connecting the drive 0V to ground should the user require to do so.

When a Unidrive SP size 4 or 5 is through-panel mounted, the grounding link bracket must be folded upwards. A screw can be used to secure the bracket or it can be located under the mounting bracket to ensure that a ground connection is made. This is required to provide a grounding point for the grounding bracket as shown Figure 3-11.

Figure 3-11 Size 4 and 5 grounding link bracket in its surface mount position (as supplied)





Figure 3-12 Size 4 and 5 grounding link bracket folded up into its through-panel mount position




Where the control wiring is required to exit the enclosure, it must be shielded and the shield(s) clamped to the drive using the grounding bracket as shown in Figure 3-13. Remove the outer insulating cover of the cable to ensure the shield(s) make contact with the bracket, but keep the shield(s) intact until as close as possible to the terminals

NOTE

Alternatively, wiring may be passed through a ferrite ring, part no. 3225-1004.

Figure 3-13 Grounding of signal cable shields using the grounding bracket



3.5 Configuring the feedback device (Closed loop)

It is possible to use different encoder types. The following settings must be performed and are dependent on the operating mode and encoder type.

3.5.1 Restrictions

Although Pr 3.34 can be set to any value from 0 to 50,000 there are restrictions on the values actually used by the drive. These restrictions are dependent on the Unidrive SP software version as follows:

Software version V01.06.01 and later

Table 3-4 Restrictions of drive encoder lines per revolution

Position feedback device	Equivalent lines per revolution used by the drive
Ab, Fd, Fr, Ab.SerVO, Fd.SerVO, Fr.SerVO, SC	The drive uses the value in Pr 3.34.
SC.HiPEr, SC.EndAt, SC.SSI (rotary encoders)	If Pr 3.34 ≤ 1 , the drive uses the value of 1. If $1 < \text{Pr } 3.34 < 32,768$, the drive uses the value in Pr 3.34 rounded down to nearest value that is a power of 2. If Pr 3.34 $\geq 32,768$, the drive uses the value of 32,768.
SC.HiPEr, SC.EndAt, SC.SSI (linear encoders)	The drive uses the value in Pr 3.34.

Software version V01.06.00 and earlier

Table 3-5 Restrictions of drive encoder lines per revolution

Position feedback device	Equivalent lines per revolution used by the drive
Ab, Fd, Fr	If Pr 3.34 < 2 , the drive uses the value of 2. If $2 \leq \text{Pr } 3.34 \leq 16,384$, the drive uses the value in Pr 3.34. If Pr 3.34 $> 16,384$, the drive uses the value in Pr 3.34 rounded down to nearest value divisible by 4.
Ab.SerVO, Fd.SerVO, Fr.SerVO	If Pr 3.34 ≤ 2 , the drive uses the value of 2. If $2 < \text{Pr } 3.34 < 16,384$, the drive uses the value in Pr 3.34 rounded down to nearest value that is a power of 2. If Pr 3.34 $\geq 16,384$, the drive uses the value of 16,384.
SC, SC.HiPEr, SC.EndAt, SC.SSI	If Pr 3.34 ≤ 2 , the drive uses the value of 2. If $2 < \text{Pr } 3.34 < 32,768$, the drive uses the value in Pr 3.34 rounded down to nearest value that is a power of 2. If Pr 3.34 $\geq 32,768$, the drive uses the value of 32,768.

3.5.2 Encoder initialization

At power-up Pr 3.48 is initially zero, but is set to one when the drive encoder and any encoders connected to any Solutions Modules have been initialized. The drive cannot be enabled until this parameter is set, Pr 3.48 = On.

Encoder initialization will occur as follows:

- At drive power-up
- When requested by the user via Pr 3.47
- When trips PS.24V, Enc1 to Enc8, or Enc11 to Enc17 are reset
- The encoder number of lines per revolution Pr 3.34 or the number of motor poles F09, Pr 0.29[0] Pr 5.11 are changed (software version V01.08.00 and later).

Initialization only affects encoder types with communications (SSI, EndAt or HiPEr) at power-up or when requested by setting Pr 3.47 = On. During initialization at power-up or following a re-initialization request, the encoder is restarted and the present absolute position is updated in the drive using the communications interface (SSI, EndAt or HiPEr) from the encoder to the drive.

3.5.3 Closed loop vector mode

Table 3-6 details the parameters required to configure both encoders and resolver feedback devices for operation in closed loop vector mode. For resolver feedback devices these must be connected to the Unidrive SP using an SM-Resolver.

If further detailed information is required on the encoder set-up and configuration refer to the *Unidrive SP User Guide*.

NOTE

When referring to parameters which are displayed as Pr MM.13 for example, the MM indicates which slot the Solutions Module being referred to is fitted in. Therefore MM = 15 (slot 1), MM = 16 (slot 2) or MM = 17 (slot 3).

NOTE

If a resolver is being used with the SM-Resolver, it is possible to generate an "EnC2" trip on the drive due to the wire break detection on the drives encoder port detecting no encoder connected. When using only a resolver ensure Pr 3.40 = 0, this disables the error detection on the drives main encoder input port.

Table 3-6 Closed loop vector feedback set-up

Feedback	Pr Setting	Default	Note
Encoder	Pr 3.26 = drv	drv	Speed feedback selector (drive)
	F05, Pr 0.29[0] Pr 3.34 = PPR	1024	Drive encoder lines per revolution
	F06, Pr 0.33[1], Pr 3.36 = 0, 1, 2	0	Drive encoder supply voltage: 5V(0) / 8V(1) / 15V(2)
	F03, Pr 0.34[1], Pr 3.38 = Ab	Ab	Drive encoder type
SinCos	Pr 3.39 = 0, 1, 2	1	Drive termination resistors. Encoder wire break disabled when termination resistors disabled
	Pr 3.26 = drv	drv	Speed feedback selector (drive)
	F05, Pr 0.29[0], Pr 3.34 = PPR	1024	Drive encoder lines per revolution
	F06, Pr 0.33[1] Pr 3.36 = 0, 1, 2	0	Drive encoder supply voltage: 5V(0) / 8V(1) / 15V(2)
Resolver	F03, Pr 0.34[1] Pr 3.38 = SC	SC	Drive encoder type
	Pr 3.26 = Slot2	drv	Speed feedback selector Slot2 = Solutions Module
	Pr 0.35[1] Pr 3.40 = 0	1	Disable drive encoder error detection
	Pr x.10	4096	Resolver feedback resolution
	Pr x.13	2:1 (1 or 2)	Resolver excitation - 2:1 (1 or 2) or 3:1 (0)

3.5.4 Servo mode

The following section covers the set-up of absolute feedback devices for closed loop servo applications. If the required feedback device is not covered in this section, refer to the *Unidrive SP User Guide* for further detailed information.

Table 3-7 Servo feedback set-up

Feedback	Pr Setting	Default	Note
Encoder	Pr 3.25 = 0	0	Phase offset value
	Pr 3.26 = drv	drv	Speed feedback selector (Drive)
	F05 , Pr 0.29[0] Pr 3.34 = PPR	1024	Drive encoder lines per revolution
	F06 , Pr 0.33[1], Pr 3.36 = 0, 1, 2	0	Drive encoder power supply 5V(0), 8V(1), 15V(2)
	F03 , Pr 0.34[1], Pr 3.38 = Ab.SErVo	Ab.SErVo	Drive encoder type
	Pr 3.39 = 0, 1, 2	1	Drive termination resistors. Encoder wire break disabled when termination resistors disabled
SinCos	Pr 3.25 = 0	0	Phase offset value
	Pr 3.26 = drv	drv	Speed feedback selector (Drive)
	Pr 3.33 = 16	16	Drive encoder turn bits
	F05 , Pr 0.29[0] Pr 3.34 = PPR	1024	Drive encoder lines per revolution
	Pr 3.35 = 0	0	Drive encoder single turn comms bits
	F06 , Pr 0.33[1], Pr 3.36 = 0, 1, 2	0	Drive encoder power supply 5V(0), 8V(1), 15V(2)
	Pr 3.37 = 0	0	Drive encoder comms baud rate (Not used with HiPEr encoders)
	F03 , Pr 0.34[1], Pr 3.38 = SC.Hiper SC.EndAt SC.SSI	Ab.SErVo	Drive encoder type
	Pr 0.35[0] Pr 3.40 = 0	1	Disable drive encoder error detection
F04 , Pr 0.36[1] Pr 3.41 = 0 or 1	0	Drive comms encoder auto configuration OR SSI format Binary / Gray code	
Resolver	Pr 3.25 = 0	0	Phase offset value
	Pr 3.26 = Slot2	drv	Speed feedback selector Slot2 = Solutions Module.
	Pr 0.35[0] Pr 3.40 = 0	1	Disable drive encoder error detection
	Pr x.10 = 4096	4096	Resolver feedback resolution
	Pr x.13 = 2	2:1 (1 or 2)	Resolver excitation – 2:1 (1 or 2) or 3:1 (0)

4 Elevator Solution Software

The Elevator Solution Software is configurable for operation in open loop, closed loop vector and servo modes. The Elevator Solution Software in the Unidrive SP generates a velocity profile for the control of the motor, whilst the elevator controller generates control signals for the Unidrive SP and Elevator Solution Software. Signals from the elevator shaft (floor levels, floor calls) go directly to the elevator controller and are used to generate and sequence the control signals to the Unidrive SP. The control signals to the Unidrive SP can include the drive enable, direction and speed selection, brake control and motor contactor control. The elevator controller, with signals from the elevator shaft determines the start, direction and operating speed selection, of the elevator along with safety related control functions.


NOTE

Additional control such as, motor contactors, brake control, pre-door opening can be configured in either by the elevator controller or the Unidrive SP and Elevator Solution Software. The safety requirements of the elevator are controlled through the elevator controller.

4.1 Positioning profile

There are two positioning profiles that can be selected when operating with the Unidrive SP and Elevator Solution Software, creep-to-floor positioning and direct-to-floor positioning.

Figure 4-1 Positioning profiles



Creep-to-floor positioning is the most commonly used operating mode for elevators and has therefore been selected as the default setting for the Elevator Solution Software through Pr 0.16[3], Pr 20.13 = 0. For some applications, especially high-speed elevators and long travel distance elevators, direct-to-floor positioning control can be used which overcomes inherent delays associated with the creep-to-floor.

4.2 Positioning mode

The creep-to-floor and direct-to-floor positioning modes are selected through Pr 0.16[3], Pr 20.13 as detailed in Table 4-1:

Table 4-1 Positioning modes

Parameter	Function
Pr 0.16[3], Pr 20.13 = 0	Direct-to-floor positioning disabled. Creep-to-floor active
Pr 0.16[3], Pr 20.13 = 1	Direct-to-floor with Stop signal via analog input 1 (T.5)
Pr 0.16[3], Pr 20.13 = 2	Direct-to-floor with Stop signal via analog input 2 (T.7)
Pr 0.16[3], Pr 20.13 = 3	Direct-to-floor with Stop signal via analog input 3 (T.8)
Pr 0.16[3], Pr 20.13 = 4	Direct-to-floor with disable speed signal control

Both the creep-to-floor and direct-to-floor positioning modes are covered in detail in section 4.4 *Creep-to-floor operation* on page 24 and section 4.5 *Direct-to-floor operation* on page 26.

4.3 Features

There are a number of features available within the Elevator Solution Software for both open loop and closed loop operation. Some of these features as listed are available through both the F Menu and advanced parameters, and some are only available through the advanced parameters in the Unidrive SP. The most common used features for creep-to-floor positioning mode (default) have been made available in the current F Menu.

Table 4-2 Elevator Solution Software features

Elevator Solution Software feature	Creep-to-floor	Direct-to-floor	F Menu	Advanced Menu	Drive Mode			Default
					OL	VT	SV	
Creep-to-floor	✓		✓	✓	✓	✓	✓	ON
Operational rpm configuration	✓	✓	✓	✓	✓	✓	✓	ON
Brake control	✓	✓	✓	✓	✓	✓	✓	ON
Start locking position control	✓	✓	✓*	✓		✓	✓	ON
Start optimizer	✓	✓	✓*	✓	✓	✓	✓	ON
Variable speed loop gains	✓	✓	✓*	✓		✓	✓	ON
Variable current loop gains	✓	✓	✓*	✓		✓	✓	OFF
Variable current loop filter	✓	✓	✓*	✓		✓	✓	ON
Advanced door opening	✓	✓	✓*	✓	✓	✓	✓	ON
Direct-to-floor		✓		✓		✓	✓	OFF
Floor sensor correction	✓	✓		✓		✓	✓	OFF
Peak curve operation	✓	✓		✓		✓	✓	OFF
Short floor landing	✓			✓	✓	✓	✓	OFF
Motor contactor control	✓	✓		✓	✓	✓	✓	OFF
Variable stator resistance	✓			✓	✓			OFF
Fast stop	✓	✓		✓	✓	✓	✓	OFF
Fast start	✓	✓		✓		✓	✓	OFF
Load measurement	✓	✓		✓		✓	✓	OFF
Inertia compensation	✓	✓		✓	✓	✓	✓	OFF
Load cell compensation	✓	✓		✓	✓	✓	✓	OFF
Releasing blocked elevator	✓	✓		✓	✓	✓	✓	OFF

✓ * Features are available in the F Menu but also have further adjustment in the advanced parameter menus. Refer to the relevant sections following for further detailed information.

Optimization of the different segments of the creep-to-floor and direct-to-floor positioning modes are available as detailed.

• **Operational rpm configuration**

The operational rpm configuration sets up the motor rated speed in rpm using the elevator parameters entered by the user e.g. elevator speed mm/s, roping, sheave diameter.

• **Brake control**

Brake control can be set-up to be controlled from the Unidrive SP and the Elevator Solution Software or from the elevator controller.

• **Start locking position control**

With both gearless elevators and planetary gears a position controller is particularly suitable for the start. This prevents any movement of the motor during brake opening.

• **Start optimizer**

This feature can be enabled to overcome such things as static friction in the elevator shaft and other general starting issues to ensure a smooth controlled start.

• **Fixed and variable speed and current loop gains for Start, Travel and Positioning**

Multiple gains are available which can be used to achieve high starting torque, speed holding during brake operation and high levels of ride comfort.

• **Multiple current loop filters for Start Travel and Positioning**

The multiple current loop filters can be implemented to reduce acoustic noise & instability generated for example by low resolution speed feedback high speed loop and/or current loop gains.

• **Advanced door opening**

Advanced door opening is available which allows the user to define a speed in mm/s at which door opening begins. This feature is used to reduce elevator journey times.

• **Floor sensor correction**

Independent of the selected profile (creep-to-floor or direct-to-floor), additional floor sensor correction can be implemented. This provides improved accurate distance correction if a floor sensor can be detected in the range of 50-500mm before the flush or level with floor target position. Floor sensor correction should be used with direct-to-floor positioning on elevators with speeds in excess of 1m/s. This ensures maximum accuracy.

• **Peak curve operation**

This function guarantees a constant stopping distance, independent of the moment when the signal to stop occurs. This allows the use of a single speed for different floor levelling distances.

• **Short distance landing**

If the floor distance is smaller than the braking time distance from the selected speed, then the peak curve operation cannot be used. This is the case if the floor distance is less than 0.7 m, the Elevator Solution Software provides the short distance landing with real distance control.

• **Motor contactor control**

Motor contactor control is available through the Unidrive SP and Elevator Solution Software with feedback monitoring to the drive.

• **Variable stator resistance**

For operation with creep-to-floor in open loop mode there is a variable stator resistance feature which allows both a start and stop stator resistance to be defined to ensure maximum torque on the motor.

• **Fast stop**

The fast stop is available mainly for commissioning and inspection of the elevator. This feature allows the User to define a fast stop deceleration rate that is greater than the standard stop rate.

• **Fast start**

The fast start allows the motor to be magnetized and the brake opened whilst the elevator car doors are closing.

• **Load measurement**

Load measurement and direction of load is implemented in the Elevator Solution Software. This feature measures the percentage load along with the direction of the load to allow rescue operation in the direction with least load.

• **Load cell – torque feed forward**

The Elevator Solution Software allows for load cell compensation to be connected to the Unidrive SP which can overcome starting issues inherent in the mechanical configuration.

• **Inertia compensation**

Inertia compensation can be implemented to overcome elevator system inertia. Without inertia compensation high speed loop gains may be required due to the inertia which can result in acoustic noise and reduced ride comfort.

• **Blocked elevator releasing function**

The blocked elevator releasing function allows for a blocked elevator (locked in mechanical brackets due to an overspeed) to be released. The Unidrive SP and Elevator Solution Software will attempt to release the elevator during the next start using creep speed and shaking the elevator whilst monitoring the blocked elevator enable Pr **19.45** = On.

4.4 Creep-to-floor operation

NOTE

Positioning with creep-to-floor positioning is the most commonly used operating mode and is therefore selected as the default setting for the Elevator Solution Software Pr **0.16[3]**, Pr **20.13** = 0.

For all sections of the velocity profile shown following there are independent parameters available for the jerks, acceleration and deceleration which allow the ride comfort of the elevator to be optimized. In addition to controlling the velocity profile the Elevator Solution Software also calculates the required deceleration distance in mm dependent upon the speed selected in **F50**, Pr **0.28[0]**, Pr **18.10** and the profile settings. The deceleration distance is calculated and displayed in Pr **0.14[3]**, Pr **19.08** for the activated speed. The measured deceleration distance is displayed after every travel in Pr **0.15[3]**, Pr **19.10** in mm. The measured creep distance is also available and displayed in Pr **0.13[3]**, Pr **20.21**.

NOTE

The deceleration distance is independent of the load assuming drive sizing is correct, as it is not possible to control the distance without considering this. From Elevator Solution Software version 1.12 onwards the deceleration distances for all speeds are displayed in the parameters as listed Table 4-3.

NOTE

The creep speed by default is set-up as parameter **F24**, Pr **0.15[0]**, Pr **18.11**. To change to another parameter refer to Pr **20.12** *Creep speed parameter number*.

Table 4-3 Operating speeds and deceleration distance

Speed selected		Deceleration distance (mm)
V1 Creep speed	F24 , Pr 0.15[0] , Pr 18.11	Pr 19.05
V2 Inspection speed	F25 , Pr 0.16[0] , Pr 18.12	Pr 2.13 , Pr 0.31[3]
V3 Nominal speed	F26 , Pr 0.17[0] , Pr 18.13	Pr 2.14 , Pr 0.32[3]
V4 Medium speed 1	F27 , Pr 0.18[0] , Pr 18.14	Pr 2.15 , Pr 0.33[3]
V5 Relevelling speed	F28 , Pr 0.19[0] , Pr 18.15	Pr 2.16 , Pr 0.34[3]
V6 Medium speed 2	F29 , Pr 0.20[0] , Pr 18.16	Pr 2.17 , Pr 0.35[3]
V7 Additional speed 1	F30 , Pr 0.21[0] , Pr 18.17	Pr 2.18 , Pr 0.36[3]
V8 Additional speed 1	Pr 20.22	Pr 2.23 , Pr 0.37[3]
V9 Additional speed 1	Pr 20.23	Pr 2.24 , Pr 0.51[3]
V10 Additional speed 1	Pr 20.24	Pr 2.25 , Pr 0.52[3]

For creep-to-floor operation the operating speed is selected according to the elevator landing distance. The operating speeds **V1** to **V10** are set-up in the Elevator Solution Software parameters as shown above and selected by the elevator controller via the control terminals on the Unidrive SP.

The real time demand on the elevator control system is low with creep-to-floor positioning being used. With a typical cycle time of the elevator controller of 5 ... 20ms and the Unidrive SP of 8ms the minimal positioning distance with creep-to-floor is calculated as follows:

The maximum creep speed distance =

$$\text{Positioning distance [mm]} \geq V_{\text{Nominal}} \text{ [m/s]} * 30\text{ms}$$

The stop accuracy =

$$\text{Accuracy [mm]} \leq V_{\text{creep speed}} \text{ [m/s]} * 30\text{ms}$$

The time required for the creep speed =

$$\text{Time creep speed [ms]} = \text{positioning distance [mm]} / V_{\text{creep speed}} \text{ [m/s]}$$

Figure 4-2 Velocity profile for creep-to-floor positioning





Figure 4-3 Creep-to-floor



Pr 0.29[2], Pr 18.23 is used to adjust the magnetization current threshold level for both open loop and closed loop vector operation.

For servo operation Pr 0.29[2], Pr 18.23 the magnetization current threshold is not required. This parameter in servo mode is therefore used to define the time taken to deflux the motor and reduce the current limits in Pr 4.05 and Pr 4.06.

4.5 Direct-to-floor operation

For some applications, especially high-speed elevators and long travel distance elevators, direct-to-floor positioning control is often used to overcome inherent delays associated with creep-to-floor elevators.

Direct-to-floor positioning alone should only be used on elevators up to 1m/s due to the accuracy and sampling of both the Unidrive SP and elevator controller, above 1m/s floor sensor correction should be enabled in addition.

For all sections of the velocity profile shown following there are independent parameters available for the acceleration and associated jerks, with which the performance of the direct-to-floor operation can be optimized. The relevant parameters are as shown below.

The direct-to-floor positioning speed is applied according to the selected floor distance. As a function of the distance to the desired final position the elevator controller will disable the speed signal on detection of the floor stop signal and then direct decelerate to the target position. Creep speed positioning is not executed nor required.

To go directly to the target position, the deceleration is dependent on the required stopping distance. The maximum deceleration is limited by Pr 0.04[0], Pr 2.21 deceleration. If the correction of the deceleration rate is not sufficient, it is possible that the car will stop too late and hence overshoot the floor level.

The direct-to-floor positioning mode uses as a reference the selected speed and profile settings to calculate and display the calculated deceleration distance in Pr 0.14[3], Pr 19.08 in mm. The deceleration distance is controlled to this value independent of the load.

4.5.1 Position accuracy


The final deceleration distance is calculated in the Elevator Solution Software from the activated speed. If the speed signal is deactivated (Pr 0.16[3], Pr 20.13 = 4 mode) or a stop input signal is activated (Pr 0.16[3], Pr 20.13 = 1...3 modes) the calculated deceleration distance will be controlled independent of the load level.

At higher travel speeds the actual position at which the car will stop is highly dependent on the time when deceleration begins. For example, if the I/O read cycle time of the drives inputs is 1ms, and if the cycle time of the elevator controller is 1ms the position accuracy is:

$$\text{Accuracy [mm]} = V_{\text{Nominal [mm/s]}} * 2 \text{ ms}$$

Because of this, the direct-to-floor positioning is limited to approximately 1m/s. At higher speeds, additional distance control for accurate stopping can be used, this being floor sensor correction which when implemented controls the final distance moved.

Figure 4-4 Velocity profile with direct-to-floor positioning




The actual distance moved is displayed in Pr 0.15[3], Pr 19.10 in mm reference deceleration distance.

From Elevator Solution Software version 1.12 onwards the deceleration distances for all speeds are displayed in the following parameters:

Table 4-4 Operating speeds and deceleration times

Speed selected	Deceleration distance (mm)
V1 Creep speed	N/A
V2 Inspection speed	F25, Pr 0.16[0], Pr 18.12 Pr 2.13, Pr 0.31[3]
V3 Nominal speed	F26, Pr 0.17[0], Pr 18.13 Pr 2.14, Pr 0.32[3]
V4 Medium speed 1	F27, Pr 0.18[0], Pr 18.14 Pr 2.15, Pr 0.33[3]
V5 Relevelling speed	F28, Pr 0.19[0], Pr 18.15 Pr 2.16, Pr 0.34[3]
V6 Medium speed 2	F29, Pr 0.20[0], Pr 18.16 Pr 2.17, Pr 0.35[3]
V7 Additional speed 1	F30, Pr 0.21[0], Pr 18.17 Pr 2.18, Pr 0.36[3]
V8 Additional speed 1	Pr 20.22 Pr 2.23, Pr 0.37[3]
V9 Additional speed 1	Pr 20.23 Pr 2.24, Pr 0.51[3]
V10 Additional speed 1	Pr 20.24 Pr 2.25, Pr 0.52[3]

Figure 4-5 Direct-to-floor



NOTE

Pr 0.29[2], Pr 18.23 is used to adjust the magnetization current threshold level for both open loop and closed loop vector operation. For servo operation Pr 0.29[2], Pr 18.23 the magnetization current threshold is not required. This parameter in servo mode is therefore used to define the time taken to deflux the motor and reduce the current limits in Pr 4.05 and Pr 4.06.

Both the start locking and Start gains can be implemented together or independently. To disable the start locking both the Kp proportional gain F47, Pr 0.19[2], Pr 19.20 and Kd derivative gain Pr 0.20[2], Pr 19.12 should be set to 0.

4.6 Start optimization

For both the creep-to-floor and direct-to-floor operation the velocity profile during start can be optimized with the additional features in the Elevator Solution Software. These features in addition to the standard speed loop gains and jerk overcome both rollback (start locking) and provide a smooth controlled start where high levels of stiction may exist due to the mechanical arrangement (start optimizer).

4.6.1 Start locking (Closed loop)

With both gearless elevators and planetary gears a position controller (start locking) can be set-up to prevent any movement of the motor during brake opening. The start locking feature in the Elevator Solution Software consists of both a proportional Kp and derivative Kd term.

NOTE


Under normal operating circumstances the variable gains alone should be sufficient to hold the motor and prevent rollback during opening of the brake.

NOTE

The start locking in the Elevator Solution Software is enabled at default with the settings of Kp proportional term F47, Pr 0.19[2], Pr 19.20 = 10 and Kd derivative term Pr 0.20[2], Pr 19.12 = 0.

The start locking provides a similar feature to the variable speed loop gains for the start ensuring the motor remains stationary and preventing rollback and positional errors. However the start locking feature is independent of the Start gains and may be required where increased Start gains are not achievable due to increased acoustic noise associated with low resolution speed feedback from the motor.

Figure 4-6 Start locking



The start locking will hold the car in position prior to and during opening of the brake. Setting the Kp proportional gain to >0 results in the car being held into position during opening of the brake. The maximum detectable position error is determined by the level of Kp proportional gain. Once the brake is open and the profile begins the start locking is disabled.

The speed loop gains in F43, Pr 0.25[2], Pr 18.27 and F44, Pr 0.26[2], Pr 18.28 are active during the start locking area.

Recommended settings for the Kp proportional gain ranges from 3 up to 30.

The Kd derivative gain, Pr **0.20[2]**, Pr **19.12** counteracts a detectable quick change of position. This helps the Kp proportional gain by introducing lower level compensation with slight deviations.

Recommended settings for the Kd derivative gain ranges from 10 up to 100.

NOTE

The maximum values for the start locking Kp and Kd gains will be limited by the stiffness of the start speed loop gains. The maximum level for the Start gains will be determined by the speed feedback device used, (SinCos encoders being far superior (higher resolution) to standard incremental encoders or resolvers).

NOTE

Start locking is active once the display on the Unidrive SP shows "run", and a speed has been selected. Speed selection is displayed in **F50**, Pr **0.28[0]**, Pr **18.10** >1810. If "STOP" is displayed, the position controller does not operate as no speed is selected and the motors brake is applied.

4.6.2 Start optimizer

The start optimizer is enabled at default to disable this feature set the time for the start optimizer **F31**, Pr **0.19[1]**, Pr **19.28** = 0.

The start optimizer feature is used to overcome starting issues with the elevator such as static friction or mechanical issues. The start optimizer has a jerk, speed and time setting as shown in Figure 4-7 that can be adjusted to achieve the required ride comfort during the start.

Once the start optimizer is enabled the standard start jerk **F34**, Pr **0.23[0]**, Pr **19.14** is disabled and the start optimizer jerk Pr **0.20[1]**, Pr **19.17** is used during the start. On completion of the start optimization defined by the time **F31**, Pr **0.19[1]**, Pr **19.28**, the elevator will continue a transition to the normal acceleration profile from the start optimizer speed Pr **0.18[1]**, Pr **18.18** using the standard start jerk **F34**, Pr **0.23[0]**, Pr **19.14**.


NOTE

If the target speed for the start optimizer set in Pr **0.18[1]**, Pr **18.18** is not reached during the start optimizer time defined in **F31**, Pr **0.19[1]**, Pr **19.28** there will be a continuous transition to the normal acceleration profile.

Table 4-5 Start optimizer parameters

Function	Parameter	Default	Detail
Start optimizer speed (mm/s)	Pr 0.18[1] , Pr 18.18	10	Setting between 5 to 15 mm/s are recommended.
Start optimizer time (ms)	F31 , Pr 0.19[1] , Pr 19.28	300	Setting between 100 to 600 ms is recommended.
Start optimizer jerk (mm/s ³)	Pr 0.20[1] , Pr 19.17	10	Setting from 10 (default) up to 20 are recommended. The value selected must be less than the acceleration jerk in F34 , Pr 0.23[0] , Pr 19.14 . Smaller values will provide smoother but slower acceleration.

Figure 4-7 Start optimization



4.7 Floor sensor correction (Closed loop)

Independent of the positioning profile selected (direct-to-floor or creep-to-floor), additional floor sensor correction can be implemented when operating in closed loop mode. This feature provides improved accuracy for the final positioning at the floor target position. The floor sensor correction is not available in open loop mode. When operating in open loop mode a standard deceleration with the programmed ramp is carried out.

Floor sensor correction allows:

- Rope slip to be compensated (as long as the normal stopping distance is short without the additional compensation provided by the direct-to-floor positioning mode).
- High levels of floor target position accuracy with elevator speeds in excess of 1m/s
- Quasi direct-to-floor positioning can be achieved if an additional sensor is detected before positioning at creep speed, creep-to-floor positioning mode (Pr **20.14** = 1, 2, 3). Creep speed is disabled when Pr **0.19[3]**, Pr **20.14** = 4.

The floor sensor correction requires a sensor that can be detected in the range of 50 to 500mm before the flush or level with floor target position. Floor sensor correction can be implemented if the sensor can be detected during deceleration or creep speed with creep-to-floor positioning.

NOTE

Floor sensor correction should be used with direct-to-floor positioning control on elevators with speeds in excess of 1m/s. This ensures maximum accuracy.

Table 4-6 Floor sensor correction parameters

Parameter	Description	Notes
Pr 0.17[3] , Pr 19.42	Enable	Enable floor sensor correction operation
Pr 0.19[3] , Pr 20.14	Input source	Control input on drive which floor sensor is connected
Pr 0.20[3] , Pr 18.19	Target distance	Target distance from floor sensor to floor level

Pr **0.19[3]**, Pr **20.14** = 4 Floor sensor correction is enabled when the creep speed is disabled and uses Pr **0.20[3]**, Pr **18.19** floor sensor target distance.

The source for the floor sensor correction must be set-up in the Elevator Solution Software in Pr **0.19[3]**, Pr **20.14** as shown in Table 4-7.

Table 4-7 Floor sensor correction source

Floor sensor correction source	Parameter	Notes
Disabled	Pr 0.19[3], Pr 20.14 = 0	No floor sensor correction
Analog input 1	Pr 0.19[3], Pr 20.14 = 1	Floor sensor correction active using floor sensor connected to drives analog input
Analog input 2	Pr 0.19[3], Pr 20.14 = 2	
Analog input 3	Pr 0.19[3], Pr 20.14 = 3	
Distance controlled stopping distance	Pr 0.19[3], Pr 20.14 = 4	Distance controlled using programmed deceleration ramps and jerk

Table 4-8 Floor sensor correction distance parameters

Parameter	Distance controlled creep speed	Direct-to-floor
Pr 0.21[3], Pr 18.09	Remaining floor sensor distance	
Pr 0.23[3], Pr 20.05	Time from floor sensor active	
Pr 0.22[3], Pr 19.09	N/A	Speed at floor sensor correction activation mm/s
Pr 0.29[3], Pr 19.05	Stopping distance in mm V_1 to V_0	Stopping distance in mm
Pr 0.14[3], Pr 19.08	Calculated deceleration distance in mm V_{SET} to V_1	Calculated deceleration distance in mm V_{SET} to V_0
Pr 0.15[3], Pr 19.10	Measured deceleration distance in mm V_{SET} to V_1	Measured deceleration distance in mm V_{SET} to V_0

4.7.1 Deceleration and stopping distance calculation

If the speed or profile parameters are changed both the deceleration and stopping distances will also change. The elevator controller can compensate for these changes by recalculating the final deceleration to achieve the floor sensor correction distance through a "learn" if this is possible. To change the parameters in the elevator controller correctly, the Elevator Solution Software calculates the deceleration and stop distances and displays them as shown in Table 4-8.

The Elevator Solution Software calculates the deceleration distance Pr 0.14[3], Pr 19.08 for the travel based upon the speed selected. On removal of the speed selection for deceleration and stop the measured deceleration distance Pr 0.15[3], Pr 19.10 begins to increment to the calculated deceleration distance in Pr 0.14[3], Pr 19.08.

To reach the target distance, profile parameters are limited for deceleration to $2 \times F33$, Pr 0.04[0], Pr 2.21 and the stop jerk to a maximum value of F36, Pr 0.25[0], Pr 19.16. If the stop distance is too low or the floor sensor signal was given at too high a speed the elevator may not be able to stop smoothly and therefore a hard stop will be implemented.

The floor sensor correction uses the floor sensor target distance defined by the user in Pr 0.20[3], Pr 18.19 (distance from floor sensor correction sensor to floor level). This target distance is controlled independent of the load. The point at which the floor sensor correction signal becomes active is between 50 and 500mm before the floor level. Settings above 500mm will reduce the accuracy at the floor level.

Once the floor sensor correction signal becomes active, the remaining floor sensor distance Pr 0.21[3], Pr 18.09 begins to decrease from the target distance Pr 0.20[3], Pr 18.19 to 0, which is the floor level. The remaining distance to the floor sensor from the point when the floor sensor correction input became active is continuously displayed in Pr 0.21[3], Pr 18.09 along with the speed in Pr 0.22[3], Pr 19.09. The time from the point where the floor sensor correction input became active to the stop is also displayed in Pr 0.23[3], Pr 20.05.

On completion the remaining floor sensor correction distance Pr 0.21[3], Pr 18.09 = 0 (± 1) and the reference selector F50, Pr 0.28[0], Pr 18.10 = 1810 indicating the floor sensor correction has completed and that no reference is now selected.

NOTE

If the floor sensor correction enable Pr 0.17[3], Pr 19.42 = 0 all values for the floor sensors can be used to check correct operation. All measured values which are required for the floor sensor correction for example the deceleration distance, time from the floor sensor and the speed at floor sensor correction are displayed and can be checked prior to the floor sensor correction being enabled.

4.7.2 Floor sensor correction, direct-to-floor, analog input


Conditions 1, 2, or 3: Pr 0.19[3], Pr 20.14 = 1, 2 or 3

When the floor sensor correction signal is activated, the floor sensor target distance is controlled independent of load. Because of direct deceleration from a higher speed, the real time demand on the control system is high, and dependent upon the parameter settings and I/O speed. For example, if the cycle time of the elevator controller is 1ms, and the drives inputs are also 1ms the position accuracy is:

$$\text{Accuracy [mm]} = V_{\text{speed at floor sensor active, Pr 0.22 [mm/s]}} \times 2 \text{ ms}$$

It should be noted that the floor sensor correction signal should be activated instantaneously at that position which is Pr 0.20[3], Pr 18.19 floor sensor target distance away from the floor sensor in mm. The stop signal can be used for all speeds.

Figure 4-8 Floor sensor correction, direct-to-floor



NOTE


If the stop distance is too low, or the floor sensor signal given at too high a speed, it is possible that the elevator may not stop smoothly and a hard stop will occur.

4.7.3 Floor sensor correction, distance controlled creep speed

Condition 4: Pr 0.19[3], Pr 20.14 = 4

When Pr 0.19[3], Pr 20.14 = 4 distance controlled creep speed is selected and the floor sensor correction is activated during the creep speed.

Figure 4-9 Floor sensor correction, distance controlled creep speed



If the creep speed signal is deactivated, the controlled stopping distance in Pr 0.20[3], Pr 18.19 will be active. The relevant profile parameters are Pr 0.22[0], Pr 19.13 deceleration, and F36, Pr 0.25[0], Pr 19.16 stop jerk (creep-to-floor). In this case, because the deceleration is from creep speed, the real time demand to the elevator controller is low. For example if the cycle time of the elevator controller is 10ms and the elevator drive 1ms, the accuracy can be calculated and the stop accuracy would be:

$$\text{Accuracy [mm]} \leq v_{\text{creep speed [mm/s]} * 11 \text{ ms}}$$

The profile parameters and the creep speed settings are used for calculating distances. At the default settings, the creep speed in

F24, Pr 0.15[0], Pr 18.11 is used. This assignment can be changed through Pr 20.12 creep speed parameter.

NOTE

If the stop distance is too low or the floor sensor signal given at too high a speed, it is possible that the elevator may not stop smoothly and a hard stop will occur.

NOTE

The creep speed signal can be deactivated at any time after the floor sensor correction signal is activated. If the creep speed signal is still active at standstill, the motor will accelerate to creep speed on completion of the floor sensor correction.

4.8 Peak curve operation (Closed loop)

Peak curve operation guarantees a constant stopping distance, independent of the moment when the signal to stop occurs. This feature allows the use of a single speed for different floor levelling distances. Peak curve operation modifies the maximum operating speed based upon when the signal to stop occurs ensuring that the required distance is achieved and floor level is reached.

Peak curve operation can be used during both creep-to-floor and direct-to-floor operation along with distance controlled creep speed (floor sensor correction mode). At default this feature is disabled.

Depending on the speed when the signal to stop occurs and the speed signal is disabled three different results can occur:

1. If the final speed is achieved prior to the signal to stop occurring there is no influence on the speed profile and deceleration to stop is carried out as normal.
2. If there is increasing or constant acceleration when the signal to stop occurs the maximum speed is modified, braking is carried out


- followed by deceleration to stop in the calculated peak curve operation distance.
3. As acceleration decreases, the signal to stop occurs, the profile deceleration parameters are automatically adjusted to the required distance to achieve the target floor level.

The reference speed before and after speed reduction is used as the calculation base for the controlled stopping distance. The set-point peak curve distance is calculated from the profile parameters and displayed in Pr 0.27[3], Pr 19.06. This value is equivalent to the deceleration distance for the applied speed. The deceleration distance is measured during peak curve operation and displayed in Pr 0.28[3], Pr 19.07.

Table 4-9 Peak curve operation parameters

Function	Parameter	Detail
Enable peak curve operation	Pr 0.27[1], Pr 18.47	Enable peak curve operation, default disabled = OFF
Distance for peak curve operation (mm)	Pr 0.27[3], Pr 19.06	Set-point distance calculated from the profile parameters and applied speed
Distance after peak curve operation (mm)	Pr 0.28[3], Pr 19.07	Measured peak curve distance
Calculated deceleration distance (mm)	Pr 0.14[3], Pr 19.08	Calculated peak curve distance

Figure 4-10 Standard and Peak curve operation



4.9 Short floor landing (Creep-to-floor)

If the short floor distance is smaller than the braking distance from the selected speed, then peak curve operation cannot be used. This is the case if the floor distance is less than 0.7 m for example. For such small floor distances the Elevator Solution Software provides the short floor landing with real distance control.


The short floor landing distance is defined in Pr 0.26[3], Pr 18.20 in mm and selected with a digital input from the elevator controller routed to Pr 18.35 at the floor level (less than 0.7m). The control signals for the creep speed and short floor landing must be applied simultaneously.

The speed profile is internally calculated so that the creep speed is reached after the short floor landing distance Pr 0.26[3], Pr 18.20. If the creep speed command is disabled the elevator drive stops the car with the set deceleration.

Table 4-10 Short floor landing parameters

Function	Parameter	Detail
Enable short floor landing	Pr 18.35	Enables the short floor landing function - digital input on drive routed from the elevator controller to Pr 18.35
Short floor landing distance	Pr 0.26[3], Pr 18.20	Defines the distance for the short floor landing

Figure 4-11 Short floor landing



4.10 Fast stop

A fast stop is available for commissioning and inspection of the elevator system. The fast stop allows the user to define a fast stop deceleration rate that is greater than the standard stop deceleration rate. The fast stop function has been introduced with Elevator Solution Software version 1.10 onwards and in default is disabled, to enable the fast stop set Pr 0.51[3], Pr 19.49 = On.

The fast stop feature allows:


- User defined fast stop deceleration rate
- Faster stopping available compared to the standard deceleration and jerk for commissioning and inspection.
- Can be used to overcome hard stops due to standard deceleration and jerk during commissioning and installation.

When the fast stop is enabled and a speed is selected of 0 mm/s for the deceleration, the deceleration rate in Pr **0.52[3]**, Pr **21.05** is active for the fast stop deceleration only (closed loop in m/s^2 /open loop in cm/s^2). The deceleration jerk **F36**, Pr **0.25[0]**, Pr **19.16** is no longer used, and a fixed time of 200 ms is used in order to run as smoothly as possible from inspection speed to deceleration, and deceleration to stop.

Table 4-11 Fast stop parameters

Function	Parameter	Detail
Enable fast stop	Pr 0.51[3] , Pr 19.49	Enables the fast stop function
Deceleration rate	Pr 0.52[3] , Pr 21.05	Fast stop deceleration rate active when Pr 19.49 = On and speed selected is 0 mm/s
Fast stop speed	F26 , Pr 0.17[0] , Pr 18.13	Speed selected for fast stop must be zero

Figure 4-12 Fast stop




Inspection speed deselected only, normal stop carried out. Inspection speed deselected and speed = 0 mm/s selected, fast stop carried out.

4.11 Fast start function (Closed loop)

The fast start function reduces the elevator start time by magnetizing the motor and releasing the brake whilst the elevator car doors are closing. For standard operation the magnetization of the motor and brake release are only carried out once the elevator car doors are closed. The fast start is enabled with Pr **19.46** = On using an additional digital input.

The fast start enable, Pr **19.46** should follow the standard enable input on control terminal 31 from the elevator controller. On enable of the drive Pr **19.46** = On, and on disable of the drive Pr **19.46** = Off.

Figure 4-13 Fast start



4.12 Nominal elevator rpm calculation

In order to set up the nominal elevator speed **F21**, Pr **0.13[0]**, Pr **18.29** in the Elevator Solution Software there is an operational rpm configuration, which uses the roping, sheave diameter and gearing data entered into the following parameters. The nominal elevator speed rpm in **F21**, Pr **0.13[0]**, Pr **18.29** is the final speed of the motor which must be set-up correctly to ensure the nominal elevator speed mm/s in **F19**, Pr **0.14[0]**, Pr **18.30** is achieved.

The following parameters for the elevator need to be entered to allow the operational rpm configuration to calculate the nominal elevator rpm **F21**, Pr **0.13[0]**, Pr **18.29**.

NOTE

Parameter **F20**, Pr **0.37[1]**, Pr **19.31** the operational rpm configuration by default is set to On. This can be disabled if required to manually adjust the nominal elevator speed rpm in parameter **F21**, Pr **0.13[0]**, Pr **18.29**.

Table 4-12 Nominal elevator parameters


Function	Parameter	Detail
Nominal elevator speed rpm n	F21 , Pr 0.13[0] , Pr 18.29	Calculated from operational rpm configuration
Nominal elevator speed mm/s V	F19 , Pr 0.14[0] , Pr 18.30	Final operating speed of elevator in mm/s
Roping Z	F16 , Pr 0.14[1] , Pr 20.10	Elevator roping 1:1, 2:1, 3:1, 4:1
Sheave D	F15 , Pr 0.15[1] , Pr 19.29	Sheave diameter in mm
Gearing iG	F17 , Pr 0.16[1] , Pr 19.30	Gear ratio numerator
Gearing GZ	F18 , Pr 0.17[1] , Pr 19.27	Gear ratio denominator

The nominal elevator rpm in **F21**, Pr **0.13[0]**, Pr **18.29** is calculated based upon the elevators mechanical conditions as follows:

$$n = V * iG * Z * 60 / (\pi * D * GZ)$$

Therefore:

$$Pr\ 18.29 = Pr\ 18.30 * Pr\ 19.30 * Pr\ 20.10 * 60 / (\pi * Pr\ 19.29 * Pr\ 19.27)$$




4.13 Load measurement (Closed loop)

The load measurement can be used both for determining the direction for evacuation with least load and also to generate an overload signal. From default the load measurement feature is enabled with Pr **20.08** set to 200ms. To disable load measurement set Pr **20.08** "time for load measurement" to zero.

The load difference between the car and the counterweight is measured and displayed in Pr **20.19** as a % of the nominal torque after the brake release delay **F37**, Pr **0.24[1]**, Pr **19.25** and time for load measure Pr **20.08** has elapsed.

Figure 4-14 Load measurement



The measurement duration is user definable and is set in Pr **20.08** in ms. This measurement is set at 200ms as default, this being sufficient for determining the load and direction. The measurement duration if set to be longer, for example 500ms, will result in more accurate results. This does however result in a longer time required for the measurement and therefore should be considered when planning / setting up for the application.


To start the evacuation in the direction of least load, the measured load value when the brake was last opened, is saved in Pr **20.19** in the unlikely event that there should be a mains power failure. The direction is displayed in Pr **19.37**. This signal should be sent to the elevator controller using a programmable digital output, Pr **8.xx** = 19.37.

Pr **19.37** from default has a direction set-up as follows; this configuration can be inverted if required using Pr **19.39**.

Pr **19.37** = On, Load in Motoring direction

Pr **19.37** = OFF, Load in Regenerative direction

Figure 4-15 Load measurement



4.13.1 Overload display

The overload bit Pr 19.36 is created by comparing the measured load in Pr 20.19 with the overload threshold that is set in Pr 20.18 as a % of nominal torque.

4.14 Load cell compensation


The Elevator Solution Software has a feature which allows load cell compensation to be implemented to overcome starting issues. The load cell or measuring transducer is fitted to the elevator and connected directly to analog input 2 on the Unidrive SP. The load cell can be either a bipolar voltage or unipolar current type.

The load cell from the elevator to the Unidrive SP provides load feedback that is used by the Elevator Solution Software to pre torque the motor prior to the brake being released. The load cell when connected to analog input 2 on the Unidrive SP can be calibrated for both zero load and full load using the load cell offset Pr 19.22 and load cell scaling Pr 19.21.

Table 4-13 Load cell parameters

Function	Parameter	Detail
Load cell %	Pr 7.02	Load cell input % when connected to analog input 2
Load cell scaling	Pr 19.21	Scaling which can be applied to calibrate load cell input
Load cell offset	Pr 19.22	Offset which can be applied to load cell input
Load cell filter	Pr 19.23	Filter for load cell to overcome any induced noise on load cell
Final torque offset	Pr 4.09	Final torque offset % used internally by the drive for compensation

Figure 4-16 Load cell compensation



NOTE

When using unipolar load cell devices the Elevator Solution Software must be configured to operate as a bipolar device internally to indicate both positive and negative torque compensation.

$$\text{Torque offset Pr 4.09} = \text{Pr 19.21 (Scaling)} * \text{Pr 19.23 (Filter)} * (\text{Pr 7.02} - \text{Pr 19.22 (Offset)})$$

Balanced car

Pr 19.22 (Offset) must be set-up for Pr 4.09 = 0 for balanced car. If Pr 4.09 is not 0 for a balanced car Pr 19.22 should be adjusted.

Empty car

The scaling in Pr 19.21 should be adjusted as follows so $\text{Pr 19.21-new} = \text{Pr 19.21-old} * \text{Pr 4.03} / \text{Pr 4.09}$

4.15 Inertia compensation

Inertia compensation can be implemented to overcome system inertia resulting in high speed loop gains. Implementing the inertia compensation will allow the speed loop gains to be reduced and overcome any increased acoustic noise. The inertia compensation feature allows the acceleration torque in Pr 4.08 to be dynamically optimized.

The inertia compensation is enabled with Pr 0.28[2], Pr 18.49 = 1 and the compensation applied directly to Pr 4.08. Once the inertia compensation is enabled, the reference acceleration is generated during the Start jerk and displayed in Pr 19.04.

Scaling can be applied to the inertia compensation through Pr 0.27[2], Pr 19.19 this should be adjusted so that the speed controller output Pr 3.04 is nearly constant after the brake has opened and also during both the starting and stopping.


The inertia compensation scaling Pr 0.27[2], Pr 19.19 can be calculated from the mechanical data as follows:

$$Pr\ 0.27[2]\ Pr\ 19.19 = 1000 * (J_G * i) / (M_N * R)$$

Where:

- J_G Inertia of the system in kgm^2 apply to the motor shaft
- M_N Rated motor torque in Nm
- R Radius of the sheave in m
- i Gear ratio

Figure 4-17 Inertia compensation



4.16 Variable speed loop gains, current loop gains, current loop filters (Closed loop)

In order to optimize control of the Unidrive SP and Elevator Solution Software, a number of gain selections for the speed loop and current loop are provided. Also included are variable current loop filters, which can be used in line with the variable gains. A total of three selections for the speed and current loop gains are provided as follows. The selections allow gains to be defined for the Start, Travel and Positioning using Pr 0.21[2], Pr 18.48 and Pr 19.48.

Table 4-14 Variable gains and Elevator Solution Software versions

Mode	Elevator Solution Software version
Constant gains	Available in all software versions
Variable Gains 1	Available in all software versions
Variable Gains 2	Available in software version V01.07 onwards
Variable Gains 2	Available in software version V01.13 onwards

NOTE

The active speed loop and current loop gains are shown in the following parameters (Speed loop) Pr 3.10 Kp, Pr 3.11 Ki, (Current loop) Pr 4.13 Kp, Pr 4.14 Ki.

4.16.1 Constant gains

Pr 0.21[2], Pr 18.48 = Off, Pr 19.48 = Off

Constant gains provide fixed values for the speed and current loop for the Start, Travel and Positioning. The current loop filter is also fixed across the Start, Travel and Positioning.

Parameter	Detail
Speed loop	
Pr 0.07, Pr 3.10	Speed loop Proportional gain Kp
Pr 0.08, Pr 3.11	Speed loop Integral gain Ki
Pr 3.42	Speed loop Speed feedback filter
Current loop	
Pr 0.38[0], Pr 4.13	Current loop Proportional gain Kp
Pr 0.39[0], Pr 4.14	Current loop Integral gain Ki
F40, Pr 0.14[2], Pr 4.12	Current loop filter

4.16.2 Variable gains 1

Pr 0.21[2], Pr 18.48 = On, Pr 19.48 = OFF

Variable gains 1 provides a speed loop gain setting for the Start and a setting for the Travel and Positioning. The current loop gains are fixed across the Start, Travel and Positioning.


The current loop filter can be defined for the Start and a setting for the Travel and Positioning. If required the variable current loop filter can be enabled/disabled and a fixed current loop filter selected with Pr 0.15[2], Pr 19.34.

From default, the variable current loop filter is enabled Pr 19.34 = OFF. For this setting Pr 4.23 is the Start current loop filter and Pr 4.12 is the Travel and Positioning current loop filter.

The transition time between the Start, Travel and Positioning gains and current loop filter are defined in Pr 0.22[2], Pr 19.11.

Parameter	Detail
Speed loop	
F43, Pr 0.25[2], Pr 18.27	Speed loop Proportional gain Kp Start
F44, Pr 0.26[2], Pr 18.28	Speed loop Integral gain Ki Start
F45, Pr 0.23[2], Pr 18.25	Speed loop Proportional gain Kp Travel
F46, Pr 0.24[2], Pr 18.26	Speed loop Integral gain Ki Travel
Pr 3.42	Speed loop Speed feedback filter
Current loop	
Pr 0.38[0], Pr 4.13	Current loop Proportional gain Kp
Pr 0.39[0], Pr 4.14	Current loop Integral gain Ki
F39, Pr 0.13[2], Pr 4.23	Current loop filter Start
F40, Pr 0.14[2], Pr 4.12	Current loop filter Travel
Pr 0.22[2], Pr 19.11	Gain and filter transition time ms

Figure 4-18 Variable gains 1



4.16.3 Variable gains 2

Pr 0.21[2], Pr 18.48 = On, Pr 19.48 = On

Variable gains 2 provide speed and current loop gain settings for the Start, Travel and Positioning. The current loop filter is also variable with settings available for the Start, Travel and Positioning. The transition time between the Start, Travel and Positioning gains and filters can either be carried out linearly with speed Pr 0.22[2] Pr 19.11 and Pr 20.30 = 0, or using defined transition times set in Pr 0.22[2], Pr 19.11 and Pr 20.30 in (ms).

Parameter	Detail
Speed loop	
F43, Pr 0.25[2], Pr 18.27	Speed loop Proportional gain Kp Start
F44, Pr 0.26[2], Pr 18.28	Speed loop Integral gain Ki Start
F45, Pr 0.23[2], Pr 18.25	Speed loop Proportional gain Kp Travel
F46, Pr 0.24[2], Pr 18.26	Speed loop Integral gain Ki Travel
Pr 0.31[2], Pr 20.27	Speed loop Proportional gain Kp Positioning
Pr 0.32[2], Pr 20.28	Speed loop Integral gain Ki Positioning
Pr 3.42	Speed loop Speed feedback filter
Current loop	
Pr 0.16[2], Pr 20.25	Current loop Proportional gain Kp Start
Pr 0.17[2], Pr 20.26	Current loop Integral gain Ki Start
F41, Pr 0.38[0], Pr 4.13	Current loop Proportional gain Kp Travel
F42, Pr 0.39[0], Pr 4.14	Current loop Integral gain Ki Travel
Pr 0.34[2], Pr 21.22	Current loop Proportional gain Kp Positioning
Pr 0.35[2], Pr 21.23	Current loop Integral gain Ki Positioning
F39, Pr 0.13[2], Pr 4.23	Current loop filter Start
F40, Pr 0.14[2], Pr 4.12	Current loop filter Travel
Pr 0.33[2], Pr 21.16	Current loop filter Positioning
Pr 0.22[2], Pr 19.11	Gain and filter transition time ms Start
Pr 20.30	Gain and filter transition time ms Positioning

Figure 4-19 Variable gains 2






Figure 4-20 Variable speed loop



4.16.4 Variable current loop

Figure 4-21 Variable current loop



4.16.5 Gain transition times

For the variable gains there are two options for the transition times between the gain values as shown in the following table. Setting values in Pr 20.30 and Pr 0.22[2], Pr 19.11 will define a time in ms for the transition of gains during the start and positioning.

Parameter	Detail
Speed loop, Current loop	
Pr 0.22[2], Pr 19.11	Gain and filter transition time ms Start
Pr 20.30	Gain and filter transition time ms Positioning

Transition times

Setting both Pr 20.30 and Pr 0.22[2], Pr 19.11 to 0 will disable the timed defined transition as shown in Figure 4-22, and the variable gains will change following the speed linearly and using the speed threshold defined in Pr 20.29.

For the variable gains transition time that follows the speed linearly as shown following, Pr 20.29 can be used to define the speed level at which the transition is completed from the Start to Travel or started during deceleration from Travel to Positioning.

Figure 4-22 Variable gains transition - following speed linearly





Figure 4-23 Variable gains transition Pr 20.30 and Pr 0.22[2], Pr 19.11 = time (ms)



4.17 Variable stator resistance control (Open loop)

For open loop control there is a variable stator resistance function that allows the stator resistance value for the motor to be modified for the profile from Start to Travel. This function can be used to optimize the motor to achieve maximum starting torque. The following parameters are used to control this function.

Table 4-15 Variable stator resistance

Parameter	Description	Notes
Pr 0.21[2], Pr 18.48	Enable	Enables variable stator resistance control in open loop
Pr 5.17	Start value for stator resistance	
Pr 21.12	End value for stator resistance	
Pr 0.22[2], Pr 19.11	Transition time	Transition time between Start and Stop stator resistance values


The variable stator resistance at default is enabled Pr 0.21[2], Pr 18.48 = On, with both Pr 5.17 and Pr 21.12 = 0.

For open loop operation and for the variable stator resistance function to operate correctly, an autotune (Pr 0.40, Pr 5.12) must be firstly carried out to measure the actual value of the motors stator resistance. From this both Pr 5.17 and Pr 21.12 are set-up with the actual measured stator resistance.

Once the autotune has been carried out and Pr 5.17 and Pr 21.12 set-up with the actual value of the motor's stator resistance, Pr 5.17 can then be optimized to achieve maximum starting torque. Pr 21.12 should remain at the autotune value for the stator resistance.

The transition time between the start value in Pr 5.17 and the end value for the start in Pr 21.12 is determined by the transition time in Pr 0.22[2], Pr 19.11 ms. At the end of the travel on removal of the drive enable, Pr 5.17 is reset to the optimized start value as shown in Figure 4-24 on page 41.

Figure 4-24 Variable stator resistance



4.18 Brake control

The brake control for the elevator can be controlled either from the Unidrive SP and the Elevator Solution Software or from the elevator controller. From default the brake control output from the Unidrive SP and Elevator Solution Software is configured for a digital output on control terminal 25.

Table 4-16 Brake control parameters

Parameter	Detail
Pr 0.19[4], Pr 18.31	Elevator Solution Software brake control output signal
Pr 8.22 = 18.31	Brake control on digital output, control terminal 25
Pr 8.27 = 18.31	Brake control on drive relay output, control terminals 41 and 42

4.18.1 Unidrive SP brake control from Elevator Solution Software

The parameter set-up for the brake control from the Elevator Solution Software function is Pr 8.22 = 18.31, or Pr 8.27 = 18.31. The control and timing sequence for the brake is shown in the following control diagrams. The brake apply delay can be adjusted in F38, Pr 0.25[1], Pr 18.24 and the brake release delay in F37, Pr 0.24[1], Pr 19.25. If the Unidrive SP trips at any stage, the brake control will become inactive and the brake will be forced to close.

Table 4-17 Brake sequence - drive control

Step	Detail
Elevator Start	
1	The elevator controller applies direction and speed signals.
2	The elevator controller applies the drive enable and the motor contactor is closed by either elevator controller or Unidrive SP and Elevator Solution Software (control terminal 22 output).
3	The Elevator Solution Software applies 100ms de-bounce delay for motor contactor and then enables the drives output.
4	Motor is magnetized with 100ms delay time.
5	Brake release output becomes active on Unidrive SP along with brake release delay F37, Pr 0.24[1], Pr 19.25
6	The Unidrive SP holds zero speed until brake-release delay and load measurement times have elapsed. The Elevator Solution Software now generates the speed profile.
Elevator Stop	
1	The elevator controller removes the speed signals on deceleration to the floor.
2	The elevator decelerates and positions at the floor level.
3	Brake output is de-activated and brake applied. Brake apply delay is active during stop Pr 18.24.
4	The elevator controller removes the drive enable after F38, Pr 0.25[1], Pr 18.24 has elapsed. The motor is then demagnetized within a 200ms delay period, and the motor contactor opened.
5	The elevator controller or Elevator Solution Software output opens the output motor contactor(s).

Figure 4-25 Brake control from the Elevator Solution Software – creep-to-floor





Figure 4-26 Brake control from the Elevator Solution Software – direct-to-floor



4.18.2 Brake control provided by elevator controller

If the elevator controller is required to control the brake this has to be configured through Pr 8.22 = 18.43. This setting changes the function of Terminal 25 output to now be "motor magnetized" indication. Only once the motor is magnetized can the elevator controller release the motor's brake. The control sequence is as follows:

Table 4-18 Brake sequence - elevator controller

Step	Detail
Elevator Start	
1	The elevator controller applies the drive enable.
2	The Unidrive SP magnetizes the motor and sets a digital output active when the motor is fully magnetized. Motor magnetized bit Pr 0.18[4], Pr 18.43.
3	The elevator controller releases the brake and waits for any brake release delay external to the Unidrive SP and Elevator Solution Software.
4	After the brake release delay the elevator controller applies the direction and speed signals.
Elevator Stop	
1	The elevator controller removes the speed signals on deceleration to the floor.
2	The elevator decelerates and positions at the floor level
3	The brake output from the elevator controller is de-activated following a wait for any brake apply delay external to the Unidrive SP and Elevator Solution Software.
4	The elevator controller removes the drive enable and the motor is demagnetized with the 200ms delay and motor contactors opened.
5	The elevator controller or Elevator Solution Software opens the output motor contactor(s).

It is recommended to set the brake release delay, F37, Pr 0.24[1], Pr 19.25 to a non-zero minimum value (for example 100). If the elevator controller removes the drive enable, the brake will be applied at that point, and the output motor contactor(s) will also be opened shortly afterwards.

4.19 Advanced door opening

From the default setting for the Elevator Solution Software there is an advanced door opening feature available. This feature begins to open the elevator car doors prior to the elevator car reaching the floor level. This allows the elevator travel times to be reduced.


The advanced door opening signal is generated by the Elevator Solution Software based upon a speed threshold and output to the elevator controller via control terminal T.24 on the Unidrive SP.

The advanced door opening speed is configured by the User in Pr 0.26[0], Pr 18.21. There are also invert and status bits available for the advanced door opening as detailed following.

Table 4-19 Advanced door opening parameters

Parameter	Detail
Pr 0.26[0], Pr 18.21	Advanced door opening speed in mm/s defined by the User.
Pr 8.21	Advanced door opening set-up for the output on T.24 of Unidrive SP. Pr 8.21 = 18.32.
Pr 8.11	Advanced door opening output signal invert.
Pr 18.32	Advanced door opening status

Figure 4-27 Advanced door opening



4.20 Motor contactor control

The motor contactors in an elevator application can consist of following possible configurations:

1. The standard two output motor contactors
2. A single output motor contactor. Can be achieved with Unidrive SP and in accordance with the SAFE TORQUE OFF (SECURE DISABLE) and EN81-1
3. Zero output motor contactors. Can be achieved with Unidrive SP and in accordance with the SAFE TORQUE OFF (SECURE DISABLE) and EN81-1.

NOTE

Refer to application note for further detailed information.



WARNING If the cable between the drive and the motor is to be interrupted by a contactor or circuit breaker, ensure that the drive is disabled before the contactor or circuit breaker is opened or closed.

A recommended motor contactor to be fitted between the drive and motor for safety purposes can be an AC3 type.

Switching the motor contactor when the drives output is active can lead to high amounts of excess voltage due to the high levels of inductance, especially with gearless elevator motors.

This can lead to:

1. Spurious OI.AC trips (which cannot be reset for 10 seconds)
2. High levels of radio frequency noise emission
3. Increased contactor wear and tear
4. Motor wear and tear / damage
5. In extreme repetitive cases drive failure can also occur

Output motor contactor control can be implemented through either the elevator controller or the Elevator Solution Software. The Elevator Solution Software feature generates an output to the elevator controller that allows the output motor contactor control to be synchronized with the drive enable. This feature prevents the output motor contactor being operated whilst the enable is active and overcomes the above issues.

The Elevator Solution Software can be set-up to control the output motor contactor using either a digital output on control terminal T.22 or using the drives relay on control terminal T.41, T.42. For the output motor contactor control using the digital output on T.22 Pr 8.28 should be set to Pr 19.32, for output motor contactor control on the drives relay Pr 8.27 should be set to Pr 19.32.

Following are the associated parameters for the output motor contactor control.

Table 4-20 Output contactor control parameters

Parameter	Detail
Pr 19.32	Motor contactor output
Pr 19.33	Feedback from motor contactor [Trip t078 generated 2 seconds after reaching the floor level if motor contactor does not open]
Pr 19.40	Enable motor contactor feedback monitor
Pr 0.26[1], Pr 20.20	Motor contactor control delay time
Pr 20.40	Motor contactor control release delay time
F38, Pr 0.25[1], Pr 18.24	Brake closing time which also applies to motor contactor closing time

To ensure the output motor contactor is closed before the drive is enabled, or the drive is disabled before the output motor contactor is opened, auxiliary contacts should be used with the enable signal.

The auxiliary contacts should be connected in series with the drives SAFE TORQUE OFF (SECURE DISABLE) (T.31) as shown following. The following diagrams show the two options for connection of the auxiliary contacts when using either single or dual output motor contactors.

The Elevator Solution Software sequencing of the enable on the Unidrive SP is delayed by approximately 100ms after the drive enable at T.31 is active to allow for de-bouncing of the output motor contactor. This prevents any spurious trip during start due to arcing of output motor contactor. When ending a normal travel, the contactor control output is also delayed internally by the same time defined for the brake closing time.

The delay for the control of the motor contactor is shown in Pr 0.26[1], Pr 20.20 in ms, negative values mean the motor contactor is opened on enable, which must be prevented.

With negative delays the brake closing time F38, Pr 0.25[1], Pr 18.24 should be reduced by at least the time displayed in Pr 0.26[1], Pr 20.20. The ideal value for Pr 0.26[1], Pr 20.20 is 50 to 100ms. Then even with normal travel the output motor contactor will open without current present on the motor.

If the elevator controller opens the safety circuit and motor contactor during a fault condition or an inspection run, the SAFE TORQUE OFF (SECURE DISABLE) on T. 31 should be opened immediately. This should be opened by an additional fast relay or other suitable measure (delay < 4 ms) in order to prevent the output motor contactor being operated when power is flowing to the motor. In addition the motor should be protected using suitable voltage limiters (varistors).

4.20.1 Drive enable

The drive enable on control terminal 31 when opened provides a SAFE TORQUE OFF (SECURE DISABLE) function. This can, in many cases, replace one of the standard two output motor contactors as the SAFE TORQUE OFF (SECURE DISABLE) is compliant with EN81-1.

The SAFE TORQUE OFF (SECURE DISABLE) function provides a means for preventing the drive from generating any torque in the motor, with a very high level of integrity. It is suitable for incorporation into a safety system for a machine. It is also suitable for use as a conventional drive enable input. The SAFE TORQUE OFF (SECURE DISABLE) function makes use of the special property of an inverter drive with an induction motor, which is that torque cannot be generated without the continuous correct active behavior of the inverter circuit. All credible faults in the inverter power circuit cause a loss of torque generation.

The SAFE TORQUE OFF (SECURE DISABLE) function is fail-safe, so when the SAFE TORQUE OFF (SECURE DISABLE) input is disconnected the drive will not operate the motor, even if a combination of components within the drive have failed. Most component failures are revealed by the drive failing to operate. SAFE TORQUE OFF (SECURE DISABLE) is also independent of the drive firmware.

Figure 4-28 Dual output motor contactors – enable circuit





Figure 4-29 Single output motor contactor – enable circuit



4.20.2 Fast disable

The Unidrive SP has a fast disable feature that can be used to disable the Unidrive SP in under 650µs, compared to the standard disable time of 10ms. This feature can be used for all operating modes and simply requires an additional input on the drive to be routed to Pr 6.29.

The fast disable can be configured in two ways:

1. In series with the standard SAFE TORQUE OFF (SECURE DISABLE) signal from the elevator controller. The SAFE TORQUE OFF (SECURE DISABLE) signal from the elevator controller is connected to control terminal 31 on the Unidrive SP, and then T.31 is linked across to another free digital input, which is then routed to Pr 6.29. In this configuration the system no longer complies with EN81-1 and dual output motor contactors are required.
2. In parallel with the standard SAFE TORQUE OFF (SECURE DISABLE) signal from the elevator controller. An additional SAFE TORQUE OFF (SECURE DISABLE) signal from the elevator controller is connected to another free digital input, which is routed to Pr 6.29. In this configuration the system complies with EN81-1 and a single output motor contactor could be used. There must not be a direct connection between the SAFE TORQUE OFF (SECURE DISABLE) input on the drive to any of the digital inputs.

4.21 Blocked elevator releasing

The blocked elevator releasing function is available in the Elevator Solution Software to release the elevator following an overspeed condition where the mechanical lock has been activated. The software feature is designed to release the elevator following removal of the mechanical lock.

By default the blocked elevator releasing function is disabled Pr 19.45 = OFF, the blocked elevator releasing function is enabled by setting Pr 19.45 = On.

The attempt to release the blocked elevator is carried out during the next start following the removal of the elevator mechanical lock and enable of the software function Pr 19.45 = On, the blocked elevator releasing can be enabled using a digital input on the drive from the elevator controller.

To generate maximum torque and jerk, the following sequence is also carried out:

- Following error detection disabled
- Soft start function disabled
- Ramps disabled
- Creep speed selected


150ms after current limit is reached at zero speed, the direction is reversed to free the elevator for a further 50ms.

The blocked elevator function detects the blocked elevator condition using the current limit active Pr 10.09 and the zero speed active Pr 10.03 following an attempt to run with Pr 19.45 = On. The detection time for the blocked elevator condition is 150ms.

Once the drive is enabled along with the blocked elevator function, and a blocked elevator condition is detected the ramps are disabled, creep speed is selected and the direction of the elevator is reversed to release the elevator.

This sequence will continue where the elevator operates for 150ms in one direction and 50ms in the opposite direction, as long as the elevator is blocked and the drive enable along with the blocked elevator releasing function Pr 19.45 are active. To stop the blocked elevator releasing function the drive enable should be removed this is then automatically followed by Pr 19.45 being set to OFF and the blocked elevator releasing function being disabled.

Figure 4-30 Blocked elevator releasing



4.22 Emergency evacuation operation

Emergency evacuation operation is possible with the Unidrive SP and the Elevator solution software. The emergency evacuation operation can be implemented in a number of ways as follows:

1. Low voltage DC back-up operation using batteries. The low voltage DC backup operation using batteries does have limited operation due to the maximum allowed battery voltage levels. Additional external circuitry is also required as detailed further on in this section.

NOTE

Careful consideration is required when proposing to use the Low voltage DC backup operation for emergency evacuation, due to the low voltage levels used. The low voltage DC levels along with the stator resistance of the motor can result in limited torque.



When in low voltage DC operation the Unidrive SP may NOT be able to limit the speed of a servo motor with an overhauling load.

WARNING



If a permanent magnet motor is made to rotate at high enough speed due to external torque, the DC bus of the drive and its associated wiring could rise above the low voltage DC operating level.

WARNING

2. UPS backup operation is possible using a single phase UPS e.g. 230Vac and an autotransformer. The autotransformer is required to step the UPS output voltage up to required operating level for Unidrive SP sizes 1 to 3. Additional external circuitry is also required as detailed further on in this section.
3. UPS backup operation for the larger size Unidrive SP, size 4 upwards is possible also with a single Phase UPS e.g. 230Vac. An autotransformer is required to step the voltage up to the required operating level for the Unidrive SP. In addition a bridge rectifier is also required to allow the Unidrive SP to be powered from its DC Bus.

NOTE

Unidrive SP size 4 and upwards has an intelligent input stage that requires all three phases to be present for the drive to start-up, therefore it is not possible to operate with a single phase AC backup power supply. For single phase UPS operation, an external bridge rectifier and inrush limiting circuit allows the AC output voltage from the UPS to be rectified and connected directly to the DC bus of the Unidrive SP.

To assist with the emergency evacuation operation the Elevator solution software also has the following features:

- Load measurement carried out for last travel
- Direction of load detected during last travel
- UPS protection, power limiting

4.22.1 Low voltage DC back-up operation

For Unidrive SP there is an option to operate with low voltage DC, this can be carried out using external batteries. Table 4-21, provides the maximum operating voltage levels for the low voltage DC back-up operation.

Table 4-21 Low voltage DC operation levels

Drive size	Under voltage trip level	Minimum start up voltage	Continuous operating voltage (Pr 6.46)		Braking IGBT turn on voltage (Pr 5.05)		Over voltage trip threshold (Pr 5.05)		Required current rating of low voltage DC supply
			200V	400V 575V 690V	200V	400V 575V 690V	200V	400V 575V 690V	
			V	V	V	V	V	V	
1	35	40	48	48	63	63	69	69	2 x drive output current (heavy duty current rating)
2	35	40	48 to 72	48 to 72	95	95	104	104	
3	35	40	48 to 72	48 to 72	95	95	104	104	
4	35	40	48 to 72	48 to 96	95	127	104	139	
5	35	40	N/A	48 to 96	N/A	127	N/A	139	
6	35	40	N/A	48 to 96	N/A	127	N/A	139	
SPMA	35	40	N/A	48 to 96	N/A	127	N/A	139	
SPMD	35	40	N/A	48 to 96	N/A	127	N/A	139	

- Minimum and maximum voltage values include ripple and noise. Ripple and noise levels must not exceed 5%.
- Minimum start up voltage, this is the minimum voltage that is required to initially start up the drive.
- Braking IGBT turn on voltage, this is the voltage level that the drives braking IGBT will operate at.
- Over voltage trip threshold, this is the voltage level that the drive will trip OV (Over Voltage).



The AC supply and DC supply must not be connected at the same time, seamless change over from AC to DC or DC to AC is not possible.

WARNING

For Unidrive SP sizes 1 to 6, a 24V external power supply must be connected to the 24V external input on the control terminal of the drive. This supplies the control circuitry and may be connected permanently.

In addition for Unidrive SP4 and upwards a 24V external power supply also needs to be connected to the 24V low voltage DC mode enable terminal of the drive. This supply should only be connected when in low voltage DC operation (this supply is in addition to the +24V external input). For further detailed information on operation and set-up refer to the *Low voltage DC operation Installation Guide* which is available for Unidrive SP.

NOTE

Careful consideration is required when proposing to use the Low voltage DC operation for emergency evacuation operation, due to the low voltage levels used. The low voltage DC levels along with the stator resistance of the motor can result in limited torque.

Figure 4-31 System configuration diagram for Unidrive SP size 1 to 3





Figure 4-32 System configuration diagram for Unidrive SP size 4 to 6, SPMA/D



Operation with an induction motor

When operating with an induction motor the drive will start to field weaken at the point when the output voltage (based on the programmed V/F) reaches the maximum DC bus voltage of the drive can support (about 34V based on a DC bus of 48V). e.g. The drive would begin to field weaken the motor at around 4Hz for a 50Hz 400V motor. The drive may continue to rotate the motor up to base speed. However, even with no external load (just a bare motor shaft) the motor could stall due to the reduced torque available whilst so far into field weakening. Be aware that reduced torque may be experienced in instances where the motor requires significant volts to magnetize. The reasons for this are listed below.

- The external low voltage DC power supply has reached it's maximum supply voltage to the drive.
- The drive has reached the maximum allowable output voltage available in this mode of operation.



The drive can only provide rated torque at low speeds as described above. It is very important to consider this when operating with an overhauling load such as elevator applications. Even with the correct braking resistor selection, the drive may not be able to maintain control of the load if the drive goes into field weakening.

WARNING

Operation with a servo motor

The speed of a servo motor is limited based on the Ke (voltage constant) value as shown in the example below. A Unidrive SP with a low voltage DC supply of 48V running a 3000rpm servo motor having a Ke value of 98V/Krpm.

- Calculate rpm per Volt. = $1000\text{rpm} / 98\text{V} = 10.2\text{rpm per volt}$
- Calculate drive output voltage = $48\text{V} / (\sqrt{2}) = 34\text{V}$
- From the above calculations the motor speed will be limited to $10.2 \times 34 = 347\text{rpm}$ (no load conditions). Under load, the maximum motor speed will be reduced.

NOTE

The calculation above gives an estimated value and does not take into account motor volt drops, load etc.



When in low voltage DC operation the Unidrive SP may NOT be able to limit the speed of a servo motor with an overhauling load.

WARNING



If a permanent magnet motor is made to rotate at a high enough speed due to external torque, the DC bus of the drive and it's associated wiring could rise above the low voltage DC operating level.

WARNING

4.22.2 UPS back-up operation

The Unidrive SP Elevator Solution Software will allow emergency evacuation operation to be carried out using a back-up AC power supply system. Unidrive SP back-up AC power supply UPS operation is restricted based upon the drive size being used as detailed following:

SP0xxx to SP3xxx

Drives in these ranges have a diode rectifier input stage with no direct monitoring of each supply input phase. Mains loss and phase loss detection is derived from the DC Bus voltage only. Therefore a single phase UPS can be used with these drives, provided there is not excessive DC bus ripple and operation is not required at full load.

SP4xxx and upwards

Drives in these ranges have an active rectifier input stage. Mains loss and phase loss detection is derived from the DC bus voltage. However the rectifier stage requires that all three phases of the supply be present in order for the drive to start-up, therefore a single phase UPS cannot be used to supply these drives.

Figure 4-33 on page 50 shows a typical UPS system that could be used for a Unidrive SP size 0 to size 3. This system uses a single phase UPS rated at 240Vac supplying a 400V drive, in order to achieve the correct operating voltage an autotransformer is used to step this up to 480Vac.

Figure 4-34 on page 50 shows a typical UPS system that could be used for a Unidrive SP size 4 and up. This system uses a single phase UPS rated at 240Vac supplying a 400V drive. In order to achieve the correct operating voltage, an autotransformer is used to step this up to 480Vac along with an external rectifier and inrush limiting circuit to provide the drive with the required DC Bus voltage.

Figure 4-33 Single phase back-up AC power supply system





Figure 4-34 Single phase back-up AC power supply system - DC output




4.22.3 Elevator Solution Software UPS protection

In order to prevent the UPS system from being overloaded during operation the Elevator Solution Software has two features which limit the current output from the drive and also limit the elevator power demand from the UPS system.

The UPS protection is enabled and disabled by the elevator control, this activates a digital input on the Unidrive SP which is routed to the elevator software Pr 19.38.

The UPS protection requires the user to enter the UPS power rating into Pr 20.15 UPS maximum power control set point. The protection uses this value as the maximum allowed power and compares this with the drives output power in Pr 5.03. If the demanded power exceeds the value in Pr 20.15, the current speed selection is removed and set to zero, the final speed set point in Pr 19.01 becomes 0.


Figure 4-35 UPS protection - Elevator Solution Software power control



In addition to the power control there is also symmetrical current limit control, Pr 4.07. The current limits are defined in Pr 21.28 evacuation current limit full load, and Pr 21.29 evacuation current limit no load. This feature is also enabled and disabled through Pr 19.38 and active at the same time as the maximum power control.

Before the transition to the emergency evacuation operation the symmetrical current limit in Pr 4.07 during normal operation is stored into memory. On activation of the emergency evacuation operation by setting Pr 19.38 = 1 the evacuation current limits become active, Pr 21.28 and Pr 21.29 based on the DC bus voltage level as shown following.

Figure 4-36 UPS protection - Elevator Solution Software current limit control



In order for the emergency evacuation control to operate correctly the following sequence should be followed;

- Drive is operating on 3ph supply, Pr **19.38** = 0, Pr **4.07** = normal setting.
- 3ph power supply is lost
- Digital input to drive, routed to Pr **19.38** from elevator controller becomes active to show evacuation operation is active.
- Drive is powered up from UPS
- Software will modify Pr **4.07** depending on the DC bus voltage level and the settings of Pr **21.28** and Pr **21.29** as shown in Figure 4-36 on page 51.
- Evacuation is completed.
- Drive is powered down.
- Digital input to drive, routed to Pr **19.38** from elevator controller is removed to show evacuation operation is completed.
- UPS is disconnected.
- Drive is powered up from 3ph supply, Pr **19.38** = 0.
- Elevator solution software loads previous normal operation current limit, Pr **4.07** from stored value.

NOTE

Interlocks should be in place to ensure correct sequencing of the startup and discharge circuits along with the emergency evacuation control.

5 I/O configuration

5.1 Unidrive SP control terminals


The control terminals on the Unidrive SP drive are user programmable except for control terminal T.31, which has a fixed function, SAFE TORQUE OFF (SECURE DISABLE) input. From default the control terminals are set-up as follows with the Elevator Solution Software.

The Unidrive SP elevator drive in default uses positive logic for all control terminals. The Unidrive SP elevator drive can however be set-up to operate in negative logic through Pr 8.29, Positive logic select.

NOTE

When configuring the Unidrive SP elevator drive for negative logic operation the SAFE TORQUE OFF (SECURE DISABLE) input will remain in positive logic.

Figure 5-1 Default control terminals



The configurations of the control terminals for the Unidrive SP elevator drive are controlled through source and destination parameters that are set-up by default with the Elevator Solution Software. The default control terminals as shown above can be re-assigned by the user through the following parameters. Control terminal inputs on the Unidrive SP elevator drive can also be manipulated e.g. inverted, scaling applied using additional parameters as follows:

Table 5-1 Default speed selection

Control Terminal		I/O set-up	Source Parameter	I/O Status	I/O Invert
Function	No.				
V1 Creep speed	T.29	Input	Pr 8.26 = 18.36	Pr 8.06	Pr 8.16
V2 Inspection speed	T.26	Input	Pr 8.23 = 18.37	Pr 8.03	Pr 8.13
V3 Nominal speed	T.27	Input	Pr 8.24 = 18.38	Pr 8.04	Pr 8.14
V4 Medium speed 1	T.5	Input	Pr 7.10 = 18.39	Pr 7.01	Pr 7.09
V5 Releveling speed	T.7	Input	Pr 7.14 = 18.40	Pr 7.02	Pr 7.13
Advanced door opening	T.24	Output	Pr 8.21 = 18.32	Pr 8.01	Pr 8.11
Brake control output	T.25	Output	Pr 8.22 = 18.31	Pr 8.02	Pr 8.12
Drive healthy relay	T.41-T42	Output	Pr 8.27 = 10.01	Pr 8.07	Pr 8.17
Direction input	T.28	Input	Pr 8.25 = 18.44	Pr 8.05	Pr 8.15
Drive enable	T.31	Input	N/A	Pr 8.09	N/A

As detailed in the above section, the Unidrive SP elevator drive control terminals can be re-assigned to additional features available in the Elevator Solution Software.

Table 5-2 provides details of the default spare control terminals available on the drive:

Table 5-2 Additional I/O

Control Terminal		I/O set-up	Source parameter	I/O status	I/O invert
Function	No.				
Motor thermistor	T.8	Input	Pr 7.18 = 0.00	Pr 7.03	Pr 7.17
Analog output 1	T.9	Output	Pr 7.19 = 3.02	N/A	N/A
Analog output 2	T.10	Output	Pr 7.22 = 4.02	N/A	N/A
+24V output	T.22	Output	Pr 8.28 = 0.00	Pr 8.08	Pr 8.18

Additional functions that can be assigned to the control terminals of the Unidrive SP Elevator drive are as follows:

Table 5-3 Additional functions

Additional functions		Information
Motor contactor control	Output	Pr 19.32 source for output
Floor sensor correction	Input	Pr 0.19[3] Pr 20.14 destination for floor sensor input
Load cell compensation	Input	Pr 4.08 destination for load cell via Analog input 2
Second direction	Input	Pr 8.24 = 19.44 second direction input to T.27
Short distance landing	Input	Pr 0.26[3] Pr 18.20 elevator controller input to drive
Direct-to-floor Stop	Input	Pr 0.16[3] Pr 20.13 floor sensor input to drive
Unidrive SP Fast disable	Input	Pr 6.29 Fast disable input to drive



If the safety function of the SAFE TORQUE OFF (SECURE DISABLE) input is required then there must not be a direct connection between the SAFE TORQUE OFF (SECURE DISABLE) input (T31) and any other digital I/O on the drive. If the safety function of the SAFE TORQUE OFF (SECURE DISABLE) input and the fast disable function is required then the drive should be given two separate independent enable signals. A safety related enable from a safe source connected to the SAFE TORQUE OFF (SECURE DISABLE) input on the drive. A second enable connected to the digital I/O on the drive selected for the fast disable function. The circuit must be arranged so that a fault which causes the fast input to be forced high cannot cause the SAFE TORQUE OFF (SECURE DISABLE) input to be forced high, including the case where a component such as a blocking diode has failed.

NOTE

For single or dual direction inputs these are controlled during the travel, therefore if there is a change of direction input during operation, the elevator must stop and the brake applied. The opposite direction will only be accepted once the drive enable has been removed.

Table 5-4 Direction inputs

Direction mode	Terminal	Status	Direction	Invert	T.27 function
Single direction input T.28	T.28	ON	Up	OFF	Pr 8.24 = 18.38
	T.28	OFF	Down	OFF	Nominal speed select
Dual direction inputs T.27 and T.28	T.27	ON	Down	OFF	Pr 8.24 = 19.44
	T.28	ON	Up	OFF	Second direction input

5.2 Motor thermistor input

By default, Analog input 3 on the Unidrive SP control terminal T.8 is set-up for the motor thermistor input. Analog input 3 is the only control terminal on the Unidrive SP that is available as a thermistor input.

Analog input 3 when used as thermistor input, is also directly linked to the thermistor connection on the 15 way D type encoder port, pins 14 and 15 of the Unidrive SP. Therefore if operating with a CT Dynamics PM motor the thermistor could be connected to the drive via the 15 way D type encoder port and therefore Analog input 3 cannot be used for any other function. The thermistor related settings associated with Analog input 3 are now used for the thermistor input on the 15 way D type encoder port.

Analog input 3 can be set-up for different functions with Pr 7.15 when operating as a thermistor input as shown in Table 5-5.

Table 5-5 Thermistor input details

Parameter value	Parameter string	Mode	Comments
0	0-20	0-20mA	
1	20-0	20-0mA	
2	4-20.tr	4-20mA with trip on loss	Trip if I <3mA
3	20-4.tr	20-4mA with trip on loss	Trip if I <3mA
4	4-20	4-20mA with no trip on loss	
5	20-4	20-4mA with no trip on loss	0.0% if I <4mA
6	VOLT	Voltage mode	
7	th.SC	Thermistor with short circuit protection	TH trip if R >3k3 TH reset if R <1k8 THS trip if R <50R
8	th	Thermistor without short circuit protection	TH trip if R >3k3 TH trip if R <1k8
9	th.diSp	Thermistor display with controlled trip	

For operating modes Pr 7.15 = th.SC and Pr 7.15 = th as soon as a overtemperature condition is detected the drive will trip whenever it is stationary or running.

For operating mode Pr 7.15 = th.diSp the temperature of the motor from the thermistor input as a resistance value is displayed in Pr 7.03 as a %, for example if the thermistor input is at 3.3k Ohms, Pr 7.03 will show a value of 33.0%.

For this operating mode the elevator will start every time and operate as long as the thermistor input is below 3.3k Ohms, if the thermistor input is above 3.3k Ohms a th trip is generated and the elevator cannot be started. If the temperature rises and the thermistor input exceeds 3.3k Ohms during operation the elevator will complete the travel and then generate the th trip.

Following a th trip the motor must cool to a level where thermistor input Pr 7.03 drops below the 1.8k Ohm level allowing the th trip to be reset. The reset for the trip can be carried out directly on the keypad of the drive or by using a digital input routed to Pr 10.33.

The thermistor overtemperature or fault can be output to the elevator controller using a digital output with the source set-up as Pr 19.35, thermistor status.

5.3 Speed selection

The Elevator Solution Software on the Unidrive SP elevator drive can be configured for either binary speed selection or priority speed selection. The default setting for the Elevator Solution software uses binary speed selection.

Pr 0.21[1], Pr 18.42 is used to configure the required speed selection.

Binary speed selection Pr 0.21[1], Pr 18.42 = OFF **Default**

Priority speed selection Pr 0.21[1], Pr 18.42 = On

Binary speed selection allows up to 11 speeds, V0 to V10 to be selected, 8 of these speeds being selectable from default on the Unidrive SP elevator drive, V0 to V5. Priority speed selection allows up to 7 speeds, V0 to V6 to be selected.

The elevator controller will determine the required speed selection.

Table 5-6 Binary speed selection

Description	Binary speed selection				Preset speed	Display
	Bit 0	Bit 1	Bit 2	Bit 3		
	T.29	T.26	T.27	T.5	Set-up parameter	Pr 18.10 =
V0 Zero speed	0	0	0	0		1810
V1 Creep speed	1	0	0	0	F24, Pr 0.15[0], Pr 18.11	1811
V2 Inspection speed	0	1	0	0	F25, Pr 0.16[0], Pr 18.12	1812
V3 Nominal speed	1	1	0	0	F26, Pr 0.17[0], Pr 18.13	1813
V4 Medium speed 1	0	0	1	0	F27, Pr 0.18[0], Pr 18.14	1814
V5 Relevelling speed	1	0	1	0	F28, Pr 0.19[0], Pr 18.15	1815
V6 Medium speed 2	0	1	1	0	F29, Pr 0.20[0], Pr 18.16	1816
V7 Additional speed 1	1	1	1	0	F30, Pr 0.21[0], Pr 18.17	1817
V8 Additional speed 1	0	0	0	1	Pr 20.22	2022
V9 Additional speed 1	1	0	0	1	Pr 20.23	2023
V10 Additional speed 1	0	1	0	1	Pr 20.24	2024

Table 5-7 Priority speed selection

Description	Priority speed selection						Preset speed	Display
	Bit 0	Bit 1	Bit 2	Bit 3	Bit 4	Bit 5		
	T.29	T.26	T.27	T.5	T.7	T.8	Set-up parameter	Pr 18.10 =
V0 Zero speed	0	0	0	0	0	0		1810
V1 Creep speed	1	0	0	0	0	0	F24, Pr 0.15[0], Pr 18.11	1811
V2 Inspection speed		1	0	0	0	0	F25, Pr 0.16[0], Pr 18.12	1812
V3 Nominal speed			1	0	0	0	F26, Pr 0.17[0], Pr 18.13	1813
V4 Medium speed 1				1	0	0	F27, Pr 0.18[0], Pr 18.14	1814
V5 Relevelling speed					1	0	F28, Pr 0.19[0], Pr 18.15	1815
V6 Medium speed 2						1	F29, Pr 0.20[0], Pr 18.16	1816

NOTE

The creep speed parameter by default is parameter F24, Pr 0.15[0], Pr 18.11. To change the parameter, set the new creep speed parameter number in Pr 20.12.

5.4 Control terminal status

The status of each of the control terminals on the Unidrive SP elevator drive can be monitored from a parameter on the keypad as detailed following and be used for diagnostics and troubleshooting.


Each control terminal has a status bit these are grouped into two parameters Pr 0.23[4], Pr 18.04 and Pr 0.24[4], Pr 18.05.

Figure 5-2 Control terminal status

Drive Parameter	Bit x	No.	Elevator Drive
Pr 0.24[4] Pr 18.05	Bit 0	29	V1 Creep speed, Speed select Bit 0
	Bit 1	26	V2 Inspection speed, Speed select Bit 1
	Bit 2	27	V3 Nominal speed, Speed select Bit 2
	Bit 3	5	V4 Medium speed, Speed select Bit 3
	Bit 4	7	V5 Re-levelling speed, Speed select Bit 4
Pr 0.23[4] Pr 18.04	Bit 0	24	Advanced door opening, V Threshold 1
	Bit 1	25	Brake control output
	Bit 2	41	Drive healthy, Relay output
		42	
	Bit 3	28	Direction input, ON = Up, OFF = Down
	Bit 4	31	Drive enable, Secure Disable

5.5 Logic diagrams

Figure 5-3 Digital I/O







Figure 5-4 Analog I/O



6 Basic operation

This chapter introduces the user interfaces, menu structure and security level of the drive.


6.1 Understanding the display

There are two types of keypad available for the Unidrive SP, LED and LCD. The SM-Keypad and SP0-Keypad have an LED display, and the SM-Keypad Plus has an LCD display. The SP0-Keypad can only be fitted to size 0, and the SM-Keypad can only be fitted to size 1 and upwards. The SM-Keypad Plus can either be fitted to the size 1 and upwards, or it can be remotely mounted on an enclosure door.

6.1.1 SM-Keypad/SP0-Keypad (LED)

The display consists of two horizontal rows of 7 segment LED displays. The upper display shows the drive status or the current menu and parameter number being viewed. The lower display shows the parameter value or the specific trip type.

Figure 6-1 SM-Keypad



6.1.2 SM-Keypad Plus (LCD)

The display consists of three lines of text. The top line shows the drive status or the current menu and parameter number being viewed on the left, and the parameter value or the specific trip type on the right. The lower two lines show the parameter name or the help text.

Figure 6-2 SM-Keypad Plus





Figure 6-3 SP0-Keypad



NOTE The red stop button is also used to reset the drive.

The SM-Keypad/SP0-Keypad and the SM-Keypad Plus can indicate when a SMARTCARD access is taking place or when the second motor map is active (menu 21). These are indicated on the displays as follows:

	SM-Keypad / SP0-Keypad	SM-Keypad Plus
SMARTCARD access taking place	The decimal point after the fourth digit in the upper display will flash.	The symbol 'CC' will appear in the lower left hand corner of the display
Second motor map active	The decimal point after the third digit in the upper display will flash.	The symbol 'Mot2' will appear in the lower left hand corner of the display

6.2 Keypad operation

6.2.1 Control buttons


The keypad consists of:

1. Joypad - used to navigate the parameter structure and change parameter values.
2. Mode button - used to change between the display modes – parameter view, parameter edit, status.
3. Three control buttons - used to control the drive if keypad mode is selected.
4. Help button (SM-Keypad Plus only) - displays text briefly describing the selected parameter.

The Help button toggles between other display modes and parameter help mode. The up and down functions on the joypad scroll the help text to allow the whole string to be viewed. The right and left functions on the joypad have no function when help text is being viewed.

The display examples in this section show the SM-Keypad 7 segment LED display. The examples are the same for the SM-Keypad Plus except that the information displayed on the lower row on the SM-Keypad is displayed on the right hand side of the top row on the SM-Keypad Plus.


Figure 6-4 Display modes



* can only be used to move between menus if L2 access has been enabled (Pr 0.49). Refer to section 6.14 on page 68.

**Timeout defined by Pr 11.41 (default value = 240s).

Figure 6-5 Mode examples



Do not change parameter values without careful consideration; incorrect values may cause damage or a safety hazard.

NOTE

When changing the values of parameters, make a note of the new values in case they need to be entered again.

NOTE


For new parameter-values to apply after the AC supply to the drive is interrupted, new values must be saved. Refer to section 6.11 on page 67.

6.3 SM-Keypad Plus

The following information covers the SM-Keypad Plus with alpha numeric LCD display and additional Help feature. The following section details displaying and adjusting the elevator drive parameters

6.3.1 SM-Keypad and SM-Keypad Plus function details

Figure 6-6 SM-Keypad Plus



NOTE

The SM-Keypad Plus display is recommended for use with the Elevator Solution Software with this providing help text in addition to the parameter descriptions.

NOTE

When using the SM-Keypad Plus display with the Elevator Solution Software it is recommended that the keypad custom elevator text is programmed into the SM-Keypad Plus display. The custom elevator text will provide detailed information on specific elevator parameters on the display which would not normally be available with the standard keypad software.

NOTE

The SM-Keypad Plus display must be used along with the custom elevator text file if operation with the F menu is required.

6.4 Operation

Figure 6-7 SM-Keypad Plus display at power-up

Status	Display
Initialising	Keypad Plus Initialising Ver: 01.00.00
Only on first power-up	Keypad Plus READING DATABASE Drive ██████████
Only on first power-up	Keypad Plus PROGRAMMING FLASH Drive ██████████
Display Operating mode	inh SErVO Operating mode
If the drive has tripped the display is flashing. Refer to Chapter 12 Diagnostics	trip Enc3
Initialising finished Drive ready	0.10 0.0 Motor speed

Figure 6-8 Select parameter




Figure 6-9 Edit parameter






Figure 6-10 Edit parameter in another Menu 0 level



6.5 Menu structure

The drive parameter structure consists of menus and parameters. The drive initially powers up so that only menu 0 can be viewed. The up and down arrow buttons are used to navigate between parameters and once level 2 access (L2) has been enabled (see Pr 0.49) the left and right buttons are used to navigate between menus. For further information refer to section 6.14 *Parameter access level and security* on page 68.


Figure 6-11 Parameter navigation



* can only be used to move between menus if L2 access has been enabled (Pr 0.49). Refer to section section 6.14 on page 68.

The menus and parameters will roll over in both directions. i.e. if the last parameter is displayed, a further press will cause the display to rollover and show the first parameter. When changing between menus the drive remembers which parameter was last viewed in a particular menu and thus displays that parameter.


Figure 6-12 Menu structure



6.6 Menu 0

Menu 0 is used to bring together various commonly used parameters for basic easy set up of the drive. Appropriate parameters are cloned from the advanced menus into menu 0 and thus exist in both locations.

Figure 6-13 Menu 0 Copying



6.7 Advanced menus

The advanced menus consist of groups or parameters appropriate to a specific function or feature of the drive. Menus 0 to 22 can be viewed on all keypads. Menus 40 and 41 are specific to the SM-Keypad Plus (LCD). Menus 70 to 91 can be viewed with an SM-Keypad Plus (LCD) only when an SM-Applications or SM-Applications Lite is fitted.

Menu	Description	LED	LCD
0	Commonly used basic set up parameters for quick / easy programming	✓	✓
1	Frequency / speed reference	✓	✓
2	Ramps	✓	✓
3	Slave frequency, speed feedback and speed control	✓	✓
4	Torque and current control	✓	✓
5	Motor control	✓	✓
6	Sequencer and clock	✓	✓
7	Analog I/O	✓	✓
8	Digital I/O	✓	✓
9	Programmable logic, motorised pot and binary sum	✓	✓
10	Status and trips	✓	✓
11	General drive set-up	✓	✓
12	Threshold detectors and variable selectors	✓	✓
13	Position control	✓	✓
14	User PID controller	✓	✓
15, 16, 17	Solutions Module set-up	✓	✓
18	Application menu 1	✓	✓
19	Application menu 2	✓	✓
20	Application menu 3	✓	✓
21	Second motor parameters	✓	✓
22	Additional Menu 0 set-up	✓	✓
40	Keypad configuration menu	X	✓
41	User filter menu	X	✓
70	PLC registers	X	✓
71	PLC registers	X	✓
72	PLC registers	X	✓
73	PLC registers	X	✓
74	PLC registers	X	✓
75	PLC registers	X	✓
85	Timer function parameters	X	✓
86	Digital I/O parameters	X	✓
88	Status parameters	X	✓
90	General parameters	X	✓
91	Fast access parameters	X	✓

6.7.1 SM-Keypad Plus set-up menus

Table 6-1 Menu 40 parameter descriptions

Parameter	Range(⇅)
40.00	Parameter 0 0 to 32767
40.01	Language selection English (0), Custom (1), French (2), German (3), Spanish (4), Italian (5)
40.02	Software version 999999
40.03	Save to flash Idle (0), Save (1), Restore (2), Default (3)
40.04	LCD contrast 0 to 31
40.05	Drive and attribute database upload was bypassed Updated (0), Bypass (1)
40.06	Browsing favourites control Normal (0), Filter (1)
40.07	Keypad security code 0 to 999
40.08	Communication channel selection Disable (0), Slot1 (1), Slot2 (2), Slot3 (3), Slave (4), Direct (5)
40.09	Hardware key code 0 to 999
40.10	Drive node ID (Address) 0 to 255
40.11	Flash ROM memory size 4Mbit (0), 8Mbit (1)
40.19	String database version number 0 to 999999
40.20	Screen saver strings and enable None (0), Default (1), User (2)
40.21	Screen saver interval 0 to 600
40.22	Turbo browse time interval 0 to 200ms

Table 6-2 Menu 41 parameter descriptions

Parameter	Range(⇅)
41.00	Parameter 0 0 to 32767
41.01 to 41.50	Browsing filter source F01 to F50 Pr 0.00 to Pr 391.51
41.51	Browsing favourites control Normal (0), Filter (1)

6.7.2 Display messages

The following tables indicate the various possible mnemonics which can be displayed by the drive and their meaning.

Trip types are not listed here but can be found in *Chapter 12 Diagnostics*.

Table 6-3 Alarm indications

Lower display	Description
br.rS	Braking resistor overload
	Braking resistor I ² t accumulator (Pr 10.39) in the drive has reached 75.0% of the value at which the drive will trip and the braking IGBT is active.
Hot	Heatsink or control board or inverter IGBT over temperature alarms are active
	The drive heatsink temperature has reached a threshold and the drive will trip 'Oh2' if the temperature continues to rise (see the 'Oh2' trip). or The ambient temperature around the control PCB is approaching the over temperature threshold (see the 'O.CtL' trip).
OVld	Motor overload
	The motor I ² t accumulator in the drive has reached 75% of the value at which the drive will be tripped and the load on the drive is >100%
Autotune	Autotune in progress
	The autotune procedure has been initialised. 'Auto' and 'tunE' will flash alternatively on the display.
Lt	Limit switch is active
	Indicates that a limit switch is active and that it is causing the motor to be stopped (i.e. forward limit switch with forward reference etc.)
PLC	Onboard PLC program is running
	An Onboard PLC program is installed and running. The lower display will flash 'PLC' once every 10s.

Table 6-4 Status indications

Upper display	Description	Drive output stage
ACUU	AC Supply loss	Enabled
	The drive has detected that the AC supply has been lost and is attempting to maintain the DC bus voltage by decelerating the motor.	
*Auto tunE	Autotune in progress	Enabled
	The autotune procedure has been initialised. '*Auto' and 'tunE' will flash alternatively on the display.	
dEC	Decelerating	Enabled
	The drive is decelerating the motor.	
inh	Inhibit	Disabled
	The drive is inhibited and cannot be run. The drive enable signal is not applied to terminal 31 or Pr 6.15 is set to 0.	
rdY	Ready	Disabled
	The drive is ready to be run.	
run	Running	Enabled
	The drive is running.	
StoP	Stop or holding zero speed	Enabled
	The drive is holding zero speed. Regen> The drive is enabled but the AC voltage is too low, or the DC bus voltage is still rising or falling.	
triP	Trip condition	Disabled
	The drive has tripped and is no longer controlling the motor. The trip code appears on the lower display.	

Table 6-5 Solutions Module and SMARTCARD status indications on power-up

Lower display	Description
boot	A parameter set is being transferred from the SMARTCARD to the drive during power-up.
cArd	The drive is writing a parameter set to the SMARTCARD during power-up. For further information, please refer to section 10.2.3 on page 141
IoAging	The drive is writing information to a Solutions Module.

6.8 Programming parameters from the SMARTCARD

The Unidrive SP and Elevator Solution Software can be programmed with a parameter set loaded to a SMARTCARD from an existing system (Unidrive SP and Elevator Solution Software). Or the parameter set for an existing system can be saved to the SMARTCARD. Programming the Unidrive SP and Elevator Solution Software with a parameter set from an existing system will configure system to operate in the same mode as the system which the parameter set was copied from.

NOTE

Also refer to section 10 on page 139

6.9 Transferring data

Data transfer, erasing and protecting the information is performed by entering a code in Pr **xx.00** and then resetting the drive as shown in Table 6-6.

Table 6-6 SMARTCARD codes

Code	Action
2001	Transfer drive parameters as difference from defaults to a bootable SMARTCARD block in data block number 001
3yyy	Transfer drive parameters to a SMARTCARD block number yyy
4yyy	Transfer drive data as difference from defaults to SMARTCARD block number yyy
5yyy	Transfer drive Onboard PLC program to SMARTCARD block number yyy
6yyy	Transfer SMARTCARD data block yyy to the drive
7yyy	Erase SMARTCARD data block yyy
8yyy	Compare drive parameters with block yyy
9555	Clear SMARTCARD warning suppression flag (V01.07.00 and later)
9666	Set SMARTCARD warning suppression flag (V01.07.00 and later)
9777	Clear SMARTCARD read-only flag
9888	Set SMARTCARD read-only flag
9999	Erase SMARTCARD


Where yyy indicates the block number 001 to 999. See Table 10-1 on page 139 for restrictions on block numbers.

NOTE

If the read only flag is set then only codes 6yyy or 9777 are effective.

6.9.1 SMARTCARD parameter setting

To program the drive with the SMARTCARD using the drive keypad

<p>1. Save drive parameters to the SMARTCARD data block:</p> <ul style="list-style-type: none"> Erase data block x by Pr 0.00 = 700x (x = Number - 7001 for data block 1) Action / reset by pressing the reset button Save data block x by Pr 0.00 = 400x (x = Number - 4001 for data block 1) Action / reset by pressing the reset button If trip C.Chg (179) the data block is already used, carry out erase as described above. <p>NOTE 400x = Transfer difference from defaults only. Refer also to section 10 SMARTCARD operation on page 139</p>	 <ol style="list-style-type: none"> Pr 0.00 = 700x Action / reset button Pr 0.00 = 400x Action / reset button
<p>2. Program drive parameters from SMARTCARD data block</p> <ul style="list-style-type: none"> Select data block x with Pr 0.00 = 600x (x = Number - 6001 for data block 1) Action / reset by pressing the reset button Save Parameters by setting Pr 0.00 = 1000 Action / reset by pressing the reset button trip C.rtg (186) indicate, that the source data block was created from a drive with a different power rating. Motor data and current limit will not be programmed. Manual adjustment is required: Pr 0.06: Current limit 175...250 Pr 0.41: Switching frequency 6 - 16 kHz Pr 0.46: Motor current <p>NOTE 400x = Transfer difference from defaults only. Refer also to section 10 SMARTCARD operation on page 139</p>	 <ol style="list-style-type: none"> Pr 0.00 = 600x Action / reset button Pr 0.00 = 1000 Action / reset button

Programming the drive with a data block from the SMARTCARD will set the operation mode, motor and encoder feedback parameters along with the basic parameters for the elevator drive. After the SMARTCARD parameter set has been programmed to the drive set up can continue directly to section 8.2 *Closed loop vector - Autotune* on page 136, assuming all relevant elevator parameters and configuration have been set-up.

6.10 Changing the operating mode


Changing the operating mode returns all parameters to their default value, including the motor parameters. (Pr **0.49** *Security status* and Pr **0.34** *User security code* are not affected by this procedure.)

Procedure

Use the following procedure only if a different operating mode is required:

- Ensure the drive is not enabled, i.e. terminal 31 is open or Pr **6.15** is (0)
- Enter either of the following values in Pr **0.00**, as appropriate:
1253 (Europe, 50Hz AC supply frequency)
1254 (USA, 60Hz AC supply frequency)

3. Change the setting of Pr **0.48** as follows:

0.48 setting		Operating mode
	1	Open-loop
	2	Closed-loop Vector
	3	Closed-loop Servo
	4	Regen (See the <i>Unidrive SP Regen Installation Guide</i> for more information about operating in this mode)

The figures in the second column apply when serial communications are used.

4. Either:

- Press the red  reset button
- Toggle the reset digital input
- Carry out a drive reset through serial communications by setting Pr **10.38** to 100 (ensure that Pr. **xx.00** returns to 0).

6.11 Saving parameters

When changing a parameter in Menu 0, the new value is saved when pressing the  Mode button to return to parameter view mode from parameter edit mode.

If parameters have been changed in the advanced menus or menu 0[1], menu 0[2], menu 0[3], menu 0[4], then the change will not be saved automatically. A save function must be carried out.

Procedure

Enter 1000 in Pr. **MM.00**

Either:

- Press the red  reset button
- Toggle the reset digital input
- Carry out a drive reset through serial communications by setting Pr **10.38** to 100 (ensure that Pr. **MM.00** returns to 0).

NOTE

If the drive is in the under voltage trip state or is being supplied from a low voltage DC supply, a value of 1001 must be entered into Pr **MM.00** to perform a save function.

NOTE

Entering 1253 or 1254 in Pr **MM.00** will only load defaults if the setting of Pr **0.48** has been changed.

6.12 Restoring parameter defaults

Restoring parameter defaults by this method saves the default values in the drive's memory. (Pr **0.49** and Pr **0.34** are not affected by this procedure.)

Procedure

1. Ensure the drive is not enabled, i.e. terminal 31 is open or Pr **6.15** is (0)
2. Enter 1233 (EUR 50Hz settings) or 1244 (USA 60Hz settings) in Pr **MM.00**.
3. Either:
 - Press the red  reset button
 - Toggle the reset digital input
 - Carry out a drive reset through serial communications by setting Pr **10.38** to 100 (ensure that Pr. **MM.00** returns to 0).

6.13 Restoring Elevator Solution Software defaults

All parameters used for the Elevator Solution Software can be set back to the default values at any stage by setting Pr **18.50** = 0. This will automatically set the Elevator Solution Software parameters to their default values and carry out a save, with all previous parameter adjustments being over written.

6.14 Parameter access level and security

The parameter access level determines whether the user has access to menu 0 only or to all the advanced menus (menus 1 to 22) in addition to menu 0.

The user security determines whether the access to the user is read only or read write.

Both the user security and parameter access level can operate independently of each other as shown in the table below:

Parameter Access Level	User Security	Menu 0 status	Advanced menus status
L1	Open	RW	Not visible
L1	Closed	RO	Not visible
L2	Open	RW	RW
L2	Closed	RO	RO

RW = Read / write access RO = Read only access

The default settings of the drive are parameter access level L1 and user security open, i.e. read / write access to Menu 0 with the advanced menus not visible.

6.14.1 Access level

The access level is set in Pr **0.49** and allows or prevents access to the advanced menu parameters.

String	Value	Effect
L1	0	Access to menu 0 only
L2	1	Access to all menus (menu 0 to menu 21)

The Access Level can be changed through the keypad even if the User Security has been set.

6.14.2 User security

The user security, when set, prevents write access to any of the parameters (other than Pr. **0.49** and Pr **11.44 Access Level**) in any menu.

Setting user security

Enter a value between 1 and 999 in Pr **0.34** and press the  button; the security code has now been set to this value. In order to activate the security, the access level must be set to Loc in Pr **0.49**. When the drive is reset, the security code will have been activated and the drive returns to access level L1. The value of Pr **0.34** will return to 0 in order to hide the security code. At this point, the only parameter that can be changed by the user is the access level Pr **0.49**.

Unlocking user security

Select a read write parameter to be edited and press the  button, the upper display will now show CodE. Use the arrow buttons to set the security code and press the  button.

With the correct security code entered, the display will revert to the parameter selected in edit mode.

If an incorrect security code is entered the display will revert to parameter view mode.

To lock the user security again, set Pr **0.49** to Loc and press the  reset button.

Disabling user security

Unlock the previously set security code as detailed above. Set Pr **0.34** to 0 and press the  button. The user security has now been disabled, and will not have to be unlocked each time the drive is powered up to allow read / write access to the parameters.

6.14.3 Elevator Solution Software security code protection (Pr 20.15)

Access to Menu 0 parameters (Pr **0.12** = 1 to 4) is only allowed:

- a) If the security code in Pr **20.15** = 0, (default)
- b) If the setting of Pr **MM.00** corresponds to the drive security code.

By setting the security code in Pr **20.15** ≠ 0, it will lock the access to the elevator parameter sets available in Menu 0 (Pr **0.12** = 1 to 4). Only personnel who know the security code will be able to access these.

6.15 Displaying parameters with non-default values only

By entering 12000 in Pr **MM.00**, the only parameters that will be visible to the user will be those containing a non-default value. This function does not require a drive reset to become active. In order to deactivate this function, return to Pr **MM.00** and enter a value of 0.

Please note that this function can be affected by the access level enabled, refer to section 6.14 *Parameter access level and security* for further information regarding access level.

6.16 Displaying destination parameters only

By entering 12001 in Pr **MM.00**, the only parameters that will be visible to the user will be destination parameters. This function does not require a drive reset to become active. In order to deactivate this function, return to Pr **MM.00** and enter a value of 0.

Please note that this function can be affected by the access level enabled, refer to section 6.14 *Parameter access level and security* for further information regarding access level.

6.17 Serial communications

6.17.1 Introduction

The Unidrive SP has a standard 2-wire EIA485 interface (serial communications interface) which enables all drive set-up, operation and monitoring to be carried out with a PC or PLC if required. Therefore, it is possible to control the drive entirely by serial communications without the need for a keypad or other control cabling. The drive supports two protocols selected by parameter configuration:

- Modbus RTU
- CT ANSI

Modbus RTU has been set as the default protocol, as it is used with the PC-tools commissioning software as provided on the CD ROM.

The serial communications port of the drive is a RJ45 socket, which is isolated from the power stage and the other control terminals.

The communications port applies a 2 unit load to the communications network.

USB/EIA232 to EIA485 Communications

An external EIA232 hardware interface such as a PC cannot be used directly with the 2-wire EIA485 interface of the drive. Therefore a suitable converter is required.

Suitable USB to EIA485 and EIA232 to EIA485 isolated converters are available from Control Techniques as follows:

- CT USB Comms cable (CT Part No. 4500-0096)
- CT EIA232 Comms cable (CT Part No. 4500-0087)

When using the above converter or any other suitable converter with the Unidrive SP, it is recommended that no terminating resistors be connected on the network. It may be necessary to 'link out' the terminating resistor within the converter depending on which type is used. The information on how to link out the terminating resistor will normally be contained in the user information supplied with the converter.

6.17.2 Serial communications set-up parameters

The following parameters need to be set according to the system requirements.

0.35 {11.24} Serial mode	
RW	Txt
↕	AnSI (0) rtU (1) ⇒ rtU (1)

This parameter defines the communications protocol used by the 485 comms port on the drive. This parameter can be changed via the drive keypad, via a Solutions Module or via the comms interface itself. If it is changed via the comms interface, the response to the command uses the original protocol. The master should wait at least 20ms before send a new message using the new protocol. (Note: ANSI uses 7 data bits, 1 stop bit and even parity; Modbus RTU uses 8 data bits, 2 stops bits and no parity.)

Comms value	String	Communications mode
0	AnSI	ANSI
1	rtU	Modbus RTU protocol
2	Lcd	Modbus RTU protocol, but with an SM-Keypad Plus only

ANSI3.28 protocol

Full details of the CT ANSI communications protocol are the *Unidrive SP Advanced User Guide*.

Modbus RTU protocol

Full details of the CT implementation of Modbus RTU are given in the *Unidrive SP Advanced User Guide*.

Modbus RTU protocol, but with an SM-Keypad Plus only

This setting is used for disabling communications access when the SM-Keypad Plus is used as a hardware key. See the *SM-Keypad Plus User Guide* for more details.

0.36 {11.25} Serial communications baud rate	
RW	Txt
↕	300 (0), 600 (1), 1200 (2), 2400 (3), 4800 (4), 9600 (5), 19200 (6), 38400 (7), 57600 (8)*, 115200 (9)* ⇒ 19200 (6)

* only applicable to Modbus RTU mode

This parameter can be changed via the drive keypad, via a Solutions Module or via the comms interface itself. If it is changed via the comms interface, the response to the command uses the original baud rate. The master should wait at least 20ms before send a new message using the new baud rate.

NOTE

When using the CT EIA232 Comms cable the available baud rate is limited to 19.2k baud.

0.37 {11.23} Serial communications address	
RW	Txt
↕	0 to 247 ⇒ 1

Used to define the unique address for the drive for the serial interface. The drive is always a slave.

Modbus RTU

When the Modbus RTU protocol is used addresses between 0 and 247 are permitted. Address 0 is used to globally address all slaves, and so this address should not be set in this parameter.

ANSI

When the ANSI protocol is used the first digit is the group and the second digit is the address within a group. The maximum permitted group number is 9 and the maximum permitted address within a group is 9. Therefore, Pr **0.37** is limited to 99 in this mode. The value 00 is used to globally address all slaves on the system, and x0 is used to address all slaves of group x, therefore these addresses should not be set in this parameter.

6.18 Setting of motor and elevator parameters

Before the initial start, the data for the motor and the elevator must be entered. Refer to the motor nameplate and elevator parameters.

Table 6-7 Menu 0 parameters (Pr 0.12 = 0)

Parameter	Description	Type	Range	Default			Units	
				OL	VT	SV		
0.01	1.07	Minimum reference clamp	RW	±Speed limit max	0.0			Hz / rpm
0.02	F22 1.06	Maximum reference clamp	RW	±Speed limit max	50	1500	3000.0	min ⁻¹
0.03	F32 2.11	Acceleration rate	RW	0 to 200	50			cm / s
				0 to 2.00		0.5		mm / s
0.04	F33 2.21	Deceleration rate	RW	0 to 200	80			cm / s
				0 to 2.00		0.8		mm / s
0.05	1.14	Reference selector	RW	0 to 5	Pr			
0.06	F13 4.07	Symmetrical current limit	RW	Current limit max	165	175		% In
0.07	F43	5.14	RW	Voltage mode select	4			
		18.27		Speed loop Kp -Gain 1 Start	0 to 65,535		0.1000	1/rad s ⁻¹
0.08	F44	5.15	RW	Low frequency boost	1 to 3			% mV
		18.28		Speed loop Ki -Gain 1 Start	0 to 65,535		10.00	1/rad s ⁻¹
0.09		5.26	RW	Dynamic V/F enable	OFF (0) or On (1)	OFF (0)		
		3.12		Speed loop Kd -Gain 1 Start	0 to 65,535	0.00000	0.00000	1/rad s ⁻¹
0.10	3.02	Motor speed	RO	± Speed limit max				rpm
0.11	4.02	Active current	RO	± Drive current max				A
0.12	20.16	Menu zero selector	RW	0 to 4	0			
0.13	F21 18.29	Nominal elevator speed rpm	RO	0 to 4000	987			rpm
0.14	F19 18.30	Nominal elevator speed mm/s	RW	0 to 10000	800			mm/s
0.15	F24 18.11	V1 Creep speed	RW	0 to 10000	50			mm/s
0.16	F25 18.12	V2 Inspection speed	RW	0 to 10000	400			mm/s
0.17	F26 18.13	V3 Nominal speed	RW	0 to 10000	800			mm/s
0.18	F27 18.14	V4 Medium speed 1	RW	0 to 10000	100			mm/s
0.19	F28 18.15	V5 Relevelling speed	RW	0 to 10000	100			mm/s
0.20	F29 18.16	V6 Medium speed 2	RW	0 to 10000	100			mm/s
0.21	F30 18.17	V7 Additional speed 1	RW	0 to 10000	100			mm/s
0.22		19.13	RW	0 to 1000	200			cm/s ²
				0 to 10000		1000	2000	mm/s ²
0.23	F34 19.14	Start jerk	RW	0 to 10000	500			mm/s ³
0.24	F35 19.15	Run jerk	RW	0 to 10000	1000			mm/s ³
0.25	F36 19.16	Stop jerk	RW	0 to 10000	800			mm/s ³
0.26	18.21	Speed threshold 1	RW	0 to 10000	300			mm/s
0.27	18.22	Speed threshold 2	RW	0 to 10000	500			mm/s
0.28	F50 18.10	Reference parameter selected	RO	Pr 18.11 to Pr 18.17, Pr 20.22 to Pr 20.24	1810			
0.29	F05 3.34	Drive encoder lines per revolution	RW	0 to 50,000	1024			PPR
0.30	11.42	Smartcard parameter cloning	RW	nonE(0),rEAd(1),Prog(2),AutO(3),boot(4)	nonE			
0.31	20.22	V8 Additional speed 2	RW	0 to 10000	50			mm/s
0.32	20.23	V9 Additional speed 3	RW	0 to 10000	400			mm/s
0.33	20.24	V10 Additional speed 4	RW	0 to 10000	800			mm/s
0.34	F49 19.02	Actual speed	RO	0 to 32,767				mm/s

Parameter			Description	Type	Range	Default			Units
						OL	VT	SV	
0.35		11.24	Serial comms mode	RW	AnSI(0), rTU(1), Lcd(3)	rtu			
0.36		11.25	Serial comms baud rate	RW	300(0) to 115200(9)	19200			baud
0.37		11.23	Serial comms address	RW	0 to 247	1			
0.38	F41	4.13	Current loop Kp - Gain 2 Travel	RW	0 to 30,000		75		
0.39	F42	4.14	Current loop Ki - Gain 2 Travel	RW	0 to 30,000		1000		
0.40	F14	5.12	Autotune	RW	0 to 6	0			0 to 6
0.41	F12	5.18	Switching frequency	RW	3(0),4(1),6(2),8(3),12(4),16(5)	3			kHz
0.42	F09	5.11	Number of motor poles	RW	Auto to 120 poles (0 - 60)	Auto	6		Poles
0.43	F11	5.10	Power factor	RW	0.000 to 1.000	0.850			
		3.25	Encoder phase angle		0.0 to 359.9		359.9		Degrees
0.44	F08	5.09	Motor rated voltage	RW	0 to AC voltage set max	Vn motor			V
0.45	F10	5.08	Rated load rpm / rated speed	RW	0.00 to 40,000.00	1500	1450		rpm
		4.15	Thermal time constant		0 to 3000.0		89.0		
0.46	F07	5.07	Motor rated current	RW	0 to Rated current max	In motor			I rated
0.47		5.06	Motor rated frequency	RW	0 to 3,000	50			Hz
0.48	F01	11.31	Operating mode	RW	OPEn LP, CL VECt, SErVO	OPEn LP	VT	SErVO	
0.49		11.44	Security status	RW	L1(0), L2(1), Loc(2)	L2		L1	
0.50		11.29	Drive software version	RO	1.00 to 99.99				

*The adjustment of the gear ratio and the sheave diameter is done with the nominal elevator rpm. It can be calculated as follows:

$$F21, Pr 0.13[0] (Pr 18.29) [n_{Nominal}] = F19, Pr 0.14[0] (Pr 18.30)[V_{Nominal}mm/s] * Gearing * Roping * 60 / (\pi * D_{sheive}[mm])$$

For Synchronous motors only, the number of motor poles and the motor current is required. Do not enter the motor data that is greyed out. For the initial test run, only the motor data and the elevator data that is listed in the examples must be adjusted. For elevators with induction motors, with or without encoders, the full motor map must be set.

7 Parameters

For access and adjustment of parameters on the SP, two different types of display are available. The SM-Keypad with a LED display and the SM-Keypad Plus a keypad with an alphanumeric LCD display plus Help function. All displays are hot swappable.

NOTE

If using the SM-Keypad with the LED display parameters accessed in the drive will be the standard parameters.

NOTE

If the pre-configured F Menu parameters are required an SM-Keypad Plus must be used with the alphanumeric LCD display. When using the preconfigured F Menu this limits access to elevator drive parameters from parameter **F01** through to parameter **F51**. For access to the elevator drive Menu 0 and advanced parameters within the elevator drive the Menu select parameter **F51** must be set to Normal.

7.1 Parameter access / security code

By setting a security code in Pr **20.15** > 0 this will activate the security and lock access to the elevator parameter sets in Menu 0 (Pr **0.12** = 1 to 4). Only personnel who know the security code will be able to access Menu 0 (Pr **0.12** = 1 to 4).

Access to Menu 0 parameters (Pr **0.12** = 1 to 4) is only allowed:

- If the security code in Pr **20.15** = 0, (default)
 - If the setting of Pr **xx.00** corresponds to the drive security code
- When the security has been overcome access is available to Menu 0, 18, 19, 20 and 21.

7.2 Elevator Solution Software status

To verify the Elevator Solution Software is running, Pr **0.29**[0], Pr **20.02** should toggle every 1s between 10614 and -10614.

7.3 Advanced parameters

The advanced menus used by the elevator drive, are menus 18, 19, 20, and 21. Detailed information regarding these menus is available beginning in section 7.8 *Menu 18 parameters* on page 81 through to section 7.11 *Menu 21 parameters* on page 127.

7.4 Defaults

All parameters used for the elevator drive software can be set back to the default values through the advanced parameters. Pr **18.50** = OFF (0), this will automatically set the Elevator Solution Software parameters to their default values and carry out a save, all previous parameter adjustments are over written.

7.5 Drive mode change

From Elevator Solution Software version 01.10 the drive parameter settings can be saved during a mode change from for example closed loop vector to open loop. The motor, control interface and elevator parameters are stored in the nonvolatile ram in the Elevator Solution Software. The configuration can be completely restored after a drive mode change provided the following procedure is followed:

1. Pr **xx.00** = 1255 (EUR) or 1256 (US) (change drive mode excluding menus 15 through to 20)
2. Pr **00.48** = Set drive mode
3. Press the reset button -the drive mode change will then be executed.

The following parameters are restored after a drive mode change:

Parameter	Description	Parameter	Description
Pr 2.11	Acceleration rate	Pr 8.24	T27 source / destination
Pr 2.21	Deceleration rate	Pr 8.14	T27 invert
Pr 4.09	Torque offset	Pr 8.25	T28 source / destination
Pr 5.06	Motor rated frequency	Pr 8.15	T28 invert
Pr 5.07	Motor rated current	Pr 8.26	T29 source / destination
Pr 5.08	Motor rated rpm / speed	Pr 8.16	T29 invert
Pr 5.09	Motor rated voltage	Pr 8.27	Relay source
Pr 5.10	Motor rated power factor	Pr 8.17	Relay source invert
Pr 5.11	Motor number of poles	Pr 11.23	Serial address
Pr 5.18	Switching frequency	Pr 11.24	Serial mode
Pr 7.10	Analog input 1 destination	Pr 11.25	Baud rate
Pr 7.14	Analog input 2 destination	Pr 12.06	Threshold 1 output invert
Pr 7.15	Analog input 3 mode	Pr 12.07	Threshold 1 destination
Pr 8.21	T24 source / destination	Pr 12.26	Threshold 2 output invert
Pr 8.11	T24 invert	Pr 12.27	Threshold 2 destination
Pr 8.31	T24 output select	Pr 21.05	Fast stop rate
Pr 8.22	T25 source / destination	Pr 21.16	Current filter 3 Stop
Pr 8.12	T25 invert	Pr 21.22	Current loop Kp -Gain 3 Stop
Pr 8.32	T25 output select	Pr 21.23	Current loop Ki -Gain 3 Stop
Pr 8.23	T26 source / destination	Pr 21.28	Evacuation current limit full load
Pr 8.13	T26 invert	Pr 21.29	Evacuation current limit no load
Pr 8.33	T26 output select		

NOTE

If the aforementioned sequence of setting Pr **xx.00** = 1255 (EUR) or 1256 (US) is not executed, the factory default settings will be restored to the Unidrive SP without saving the elevator software parameter settings.

When the drive mode is changed from open loop to closed loop vector or servo, the following parameters are restored:


Parameter	Description
F40, Pr 0.14[2], Pr 4.12	Current filter 2 Travel
F41, Pr 0.38[0], Pr 4.13	Current loop Kp 2 -Gain Travel
F42, Pr 0.39[0], Pr 4.14	Current loop Ki 2 -Gain Travel
F05, Pr 0.29[0], Pr 3.34	Drive encoder lines per revolution
F03, Pr 0.34[1], Pr 3.38	Drive encoder type
F06, Pr 0.33[1], Pr 3.36	Drive encoder supply voltage
Pr 3.39	Drive encoder termination
F11, Pr 0.43[0], Pr 3.25	Drive encoder phase angle (Servo mode)

Using this function the elevator can be operated without any additional settings after a mode change back to closed loop vector or servo modes from open loop.

7.6 Menu 0 parameter structure

Pr 0.00 to Pr 0.12 and Pr 0.38 to Pr 0.50 in Menu 0 are fixed parameters with pre-defined functions.

Figure 7-1 Menu structure



Pr 0.13 to Pr 0.37 are the elevator Menu 0 parameters that are used to display four separate elevator parameter sets. The user through Pr 0.12 can select either of the elevator parameter sets. After power-up the standard configuration for Pr 0.13 to Pr 0.37 is loaded automatically by (Pr 0.12 = 0).

By setting Pr 0.12 to the predefined code 1, 2, 3 or 4, other configurations of Pr 0.13 to Pr 0.37 are selected as shown in the following:

Default parameters	Pr 0.12 = 0
Installation parameters	Pr 0.12 = 1
Control parameters	Pr 0.12 = 2
Distance parameters	Pr 0.12 = 3
Diagnostics Parameters	Pr 0.12 = 4

In this documentation the value of Pr 0.12 is shown in square brackets after the Menu 0 parameter to indicate which configuration is selected.

For example:

Pr 0.26[1] of the elevator parameters, Pr 0.12 = 1 therefore Pr 0.26[1]

To select Pr 0.18[2], set Pr 0.12 = 2 and go to Pr 0.18[2]

Table 7-1 Menu 0 default parameters (Pr 0.12 = 0)

Parameter			Description	Type	Range	Default			Units
						OL	VT	SV	
0.12		20.16	Menu selector	RW	0 to 4		0		
0.13[0]	F21	18.29	Nominal elevator rpm	RO	0 to 4000		987		rpm
0.14[0]	F19	18.30	Nominal elevator speed	RW	0 to 10000		800		mm/s
0.15[0]	F24	18.11	V1 Creep speed	RW	0 to 10000		50		mm/s
0.16[0]	F25	18.12	V2 Inspection speed	RW	0 to 10000		400		mm/s
0.17[0]	F26	18.13	V3 Nominal speed	RW	0 to 10000		800		mm/s
0.18[0]	F27	18.14	V4 Medium speed 1	RW	0 to 10000		100		mm/s
0.19[0]	F28	18.15	V5 Relevelling speed	RW	0 to 10000		100		mm/s
0.20[0]	F29	18.16	V6 Medium speed 2	RW	0 to 10000		100		mm/s
0.21[0]	F30	18.17	V7 Additional speed 1	RW	0 to 10000		100		mm/s
0.22[0]		19.13	Stop deceleration	RW	0 to 1000	1000			cm/s ²
					0 to 10000			1000	
0.23[0]	F34	19.14	Start jerk	RW	0 to 10000		500		mm/s ³
0.24[0]	F35	19.15	Run jerk	RW	0 to 10000		1000		mm/s ³
0.25[0]	F36	19.16	Stop jerk	RW	0 to 10000		800		mm/s ³
0.26[0]		18.21	Speed threshold 1	RW	0 to 10000		300		mm/s
0.27[0]		18.22	Speed threshold 2	RW	0 to 10000		500		mm/s
0.28[0]	F50	18.10	Reference parameter selected	RO	Pr 18.11 to Pr 18.17 Pr 20.22 to Pr 20.24		1810		
0.29[0]	F05	3.34	Drive encoder lines per revolution	RW	0 to 50,000		1024	4096	PPR
0.30[0]		11.42	Smartcard parameter cloning	RW	nonE(0),rEAd(1),Prog(2), AutO(3),boot(4)		nonE(0)		
0.31[0]		20.22	V8 Additional speed 2	RW	10000		50		mm/s
0.32[0]		20.23	V9 Additional speed 3	RW	0 to 10000		400		mm/s
0.33[0]		20.24	V10 Additional speed 4	RW	0 to 10000		800		mm/s
0.34[0]	F49	19.02	Actual speed	RO	0 to 32,767				mm/s
0.35[0]		11.24	Serial comms mode	RW	AnSI(0), rTU(1), Lcd(3)		rTU(1)		
0.36[0]		11.25	Serial comms baud rate	RW	300(0) to 115200(9)		19200		kb
0.37[0]		11.23	Serial comms address	RW	0 to 247		1		
0.38[0]	F41	4.13	Current loop Kp -Gain 2 Travel	RW	0 to 30,000			75	
0.39[0]	F42	4.14	Current loop Ki -Gain 2 Travel	RW	0 to 30,000			1000	

Table 7-2 Menu 1 installation parameters (Pr 0.12 = 1)

Parameter			Description	Type	Range	Default			Units
						OL	VT	SV	
0.12		20.16	Menu selector	RW	0 to 4	0			
0.13[1]		18.03	Calculated nominal elevator speed	RO	0 to 32,000	987			rpm
0.14[1]	F16	20.10	Roping	RW	0 to 4	1			
0.15[1]	F15	19.29	Sheave diameter	RW	0 to 32767	480			mm
0.16[1]	F17	19.30	Gear ratio numerator	RW	0 to 32767	31			
0.17[1]	F18	19.29	Gear ratio denominator	RW	0 to 32767	1			
0.18[1]		18.18	Speed for Start optimizer	RW	0 to 10000	10			mm/s
0.19[1]	F31	19.28	Time for Start optimizer	RW	0 to 10000	700			ms
0.20[1]		19.17	Jerk for Start optimizer	RW	0 to 10000	10			mm/s ³
0.21[1]		18.42	Reference selector type	RW	OFF (0) or On (1)	OFF (0)			
0.22[1]	F23	18.45	Invert direction	RW	OFF (0) or On (1)	OFF (0)			
0.23[1]		8.22	Terminal 25 function [Brake O/P]	RW	Pr xx.xx	18.31			
0.24[1]	F37	19.25	Brake release delay	RW	0 to 10000	500			ms
0.25[1]	F38	18.24	Brake apply delay	RW	0 to 10000	1000			ms
0.26[1]		20.20	Motor contactor delay time	RO	0 to 10000				ms
0.27[1]		18.47	Enable peak curve operation	RW	OFF (0) or On (1)	OFF (0)			
0.28[1]	F53	20.01	Software version [t079]	RO	xxxx				
0.29[1]	F54	20.02	Software identity number	RO	± 10614	± 10614			
0.30[1]			Not used						
0.31[1]		3.26	Speed feedback selector	RW	Drv / Slot	drv			
0.32[1]		3.35	Drive encoder single turn comms bits	RW	0 to 32	0			Bits
0.33[1]	F06	3.36	Drive encoder supply voltage	RW	5, 8, 15	5			V
0.34[1]	F03	3.38	Drive encoder type	RW	0 to 9	Ab(0)		Ab.Servo(3)	
0.35[1]		3.40	Drive encoder error detection level	RO	0 to 7	1			
0.36[1]	F04	3.41	Drive encoder auto-configuration	RO	OFF (0) or On (1)	OFF (0)			
0.37[1]	F20	19.31	Enable operational rpm configuration	RW	OFF (0) or On (1)	On (1)			
0.51[3]		19.49	Enable Fast Stop	RW	OFF (0) or On (1)	OFF (0)			
0.52[3]		21.05	Fast stop deceleration ramp	RW	0 to 1000	200			cm/s ²
					0 to 10000		2000		mm/s ²

Table 7-3 Menu 2 control parameters (Pr 0.12 = 2)

Parameter			Description	Type	Range	Default			Units
						OL	VT	SV	
0.12		20.16	Menu selector	RW	0 to 4	0			
0.13[2]	F39	4.23	Current filter 1 Start	RW	0 to 25.0		0.0		ms
0.14[2]	F40	4.12	Current filter 2 Travel	RW	0 to 25.0		2.0	0.0	ms
0.15[2]		19.34	Enable constant current filter	RW	OFF (0) or On (1)		OFF (0)		
0.16[2]		20.25	Current loop Kp - Gain 1 Start	RW	0 to 30,000		75		
0.17[2]		20.26	Current loop Ki - Gain 1 Start	RW	0 to 30,000		1000		
0.18[2]		5.27	Enable slip compensation	RW	OFF (0) or On (1)	On (1)			
		5.22	High speed mode enable		OFF (0) or On (1)		OFF (0)		
0.19[2]	F47	19.20	P-gain Start locking	RW	0 to 1000		10		
0.20[2]		19.12	D-gain Start locking	RW	0 to 30000		0		
0.21[2]		18.48	Enable stator resistance control	RW	OFF (0) or On (1)	On (1)			
			Enable separate Start -Travel gains		OFF (0) or On (1)		On (1)		
0.22[2]		19.11	Variable gains transition time acceleration	RW	0 to 32767		1000		ms
			Variable stator resistance time		0 to 32767	1000			ms
0.23[2]	F45	18.25	Speed loop Kp - Gain 2 Travel	RW	0 to 65,535		500		1/rad s-1
0.24[2]	F46	18.26	Speed loop Ki - Gain 2 Travel	RW	0 to 65,535		500		1/rad s-1
0.25[2]	F43	18.27	Speed loop Kp - Gain 1 Start	RW	0 to 65,535		1000		1/rad s-1
0.26[2]	F44	18.28	Speed loop Ki - Gain 1 Start	RW	0 to 65,535		1000		1/rad s-1
0.27[2]		19.19	Inertia compensation scaling	RW	0 to 32767	1000			
0.28[2]		18.49	Enable inertia compensation	RW	OFF (0) or On (1)	OFF (0)			
0.29[2]		18.23	Magnetizing current threshold [t076]	RW	0 to 990	200	500		0.1%
			Demagnetization time		0 to 9900			200	ms
0.30[2]		19.48	Enable variable speed loop gains	RW	OFF (0) or On (1)		OFF (0)		
0.31[2]		20.27	Speed loop Kp 3 Positioning	RW	0 to 65,535		500		1/rad s-1
0.32[2]		20.28	Speed loop Ki 3 Positioning	RW	0 to 65,535		500		1/rad s-1
0.33[2]		21.16	Current loop filter 3 Positioning	RW	0.0 to 25.0		2.0		ms
0.34[2]		21.22	Current loop Kp 3 Positioning	RW	0 to 30,000		75		
0.35[2]		21.23	Current loop Ki 3 Positioning	RW	0 to 30,000		1000		
0.36[2]		03.42	Drive encoder filter	RW	0 to 16	0			ms
0.37[2]		05.26	High dynamic performance enable	RW	OFF (0) or On (1)		OFF (0)		

Table 7-4 Menu 3 distance parameters (Pr 0.12 = 3)

Parameter		Description	Type	Range	Default			Units
					OL	VT	SV	
0.12	20.16	Menu selector	RW	0 to 4	0			
0.13 [3]	20.21	Measured creep distance	RO	-2^{31} to $2^{31}-1$				mm
0.14 [3]	19.10	Reference deceleration distance	RO	-32,768 to 32,767				mm
0.15 [3]	18.02	Deceleration following error	RO	-32,768 to 32,767				mm
0.16 [3]	20.13	Direct to floor sensor source	RW	0 to 4	0			
0.17 [3]	19.42	Enable floor sensor correction	RW	OFF (0) or On (1)		OFF (0)		
0.18 [3]		Not used						
0.19 [3]	20.14	Floor sensor correction source	RW	0 to 4		0		
0.20 [3]	18.19	Floor sensor target distance	RW	0 to 10000		0		mm
0.21 [3]	18.09	Remaining floor sensor distance	RO	0 to 10000		0		mm
0.22 [3]	19.09	Speed at floor sensor active	RO	-32,768 to 32,767		0		mm/s
0.23 [3]	20.05	Time from floor sensor active to Stop	RO	0 to 10000	0			ms
0.24 [3]	20.17	Kp - gain following error regulation	RW	0 to 32767	0			
0.25 [3]		Not used						
0.26 [3]	18.20	Short floor landing distance	RW	0 to 10000				mm
0.27 [3]	19.06	Distance for peak curve	RO	0 to 10000				mm
0.28 [3]	19.07	Distance after peak curve	RO	0 to 10000				mm
0.29 [3]	19.05	Stopping distance	RO	0 to 10000	13			mm
0.30 [3]		Not used						
0.31 [3]	2.13	Deceleration distance V2	RO	0.0 to 1,000	26.600			s/1000rpm
0.32 [3]	2.14	Deceleration distance V3	RO	0.0 to 1,000	73.800			s/1000rpm
0.33 [3]	2.15	Deceleration distance V4	RO	0.0 to 1,000	3.400			s/1000rpm
0.34 [3]	2.16	Deceleration distance V5	RO	0.0 to 1,000	3.400			s/1000rpm
0.35 [3]	2.17	Deceleration distance V6	RO	0.0 to 1,000	3.400			s/1000rpm
0.36 [3]	2.18	Deceleration distance V7	RO	0.0 to 1,000	3.400			s/1000rpm
0.37 [3]	2.23	Deceleration distance V8	RO	0.0 to 1,000	0.000			s/1000rpm
0.51 [3]	2.24	Deceleration distance V9	RO	0.0 to 1,000	26.600			s/1000rpm
0.52 [3]	2.25	Deceleration distance V10	RO	0.0 to 1,000	73.800			s/1000rpm

Table 7-5 Menu 4 diagnostic parameters (Pr 0.12 = 4)

Parameter	Description	Type	Range	Default			Units	
				OL	VT	SV		
0.13[4]	3.05	Zero speed threshold	RW	0 to 20Hz, 0 to 200rpm	1.0			Hz / rpm
0.14[4]	20.07	Rotor flux level	RO	0 to 10,000				0.1A
0.15[4]	20.06	Max motor voltage last travel	RO	0 to motor rated voltage				V
0.16[4]	3.01	Final speed reference	RO	±Speed limit max				Hz / rpm
0.17[4]	20.09	Maximum overload	RO	0 to 10,000				% In
0.18[4]	18.43	Motor magnetized [t076]	RO	OFF (0) or On (1)	OFF (0)			
0.19[4]	18.31	Brake output status [T.25]	RO	OFF (0) or On (1)	OFF (0)			
0.20[4]	10.20	Last trip	RO	0 to 230				
0.21[4]	10.21	Trip before last	RO	0 to 230				
0.22[4]	3.04	Speed controller output	RO	± Torque prod current max				%torque
0.23[4]	18.04	Control terminal status	RO	00000 to 11111				
0.24[4]	18.05	Control terminal status	RO	00000 to 11111				
0.25[4]	18.07	Maximum speed error [t070]	RO	0 to 10,000				mm/s
0.26[4]	19.24	Maximum speed error threshold	RW	0 to 10,000	2000	100		mm/s
0.27[4]	18.06	Maximum distance error [t071]	RO	0 to 10,000				mm
0.28[4]	19.18	Maximum distance error threshold	RW	0 to 10,000	100	100		mm
0.29[4]	3.03	Speed error	RO	± Speed max rpm				rpm
0.30[4]	3.27	Drive encoder speed feedback	RO	± 40,000.0 rpm				rpm
0.31[4]	11.36	SMARTCARD data previously loaded	RO	0 to 999	0			
0.32[4]	11.37	SMARTCARD data number	RO	0 to 1000	0			
0.33[4]	11.38	SMARTCARD data type	RO	0 to 18	FrEE			
0.34[4]	11.40	SMARTCARD data checksum	RO	0 to 65,335	0			
0.35[4]	20.35 20.39	Diagnostic travel interrupt code V1.21 onwards	RO	0 or 1	0			

7.7 Elevator drive F menu parameters

NOTE

If using the SM-Keypad / SP0 Keypad with the LED display parameters accessed in the drive will be the standard parameters and not the pre-configured F Menu.

NOTE

If the pre-configured F menu parameters are required an SM-Keypad Plus must be used with the alphanumeric LCD display. When using the preconfigured F menu this limits access to elevator drive parameters from parameter F01 through to parameter F51. For access to the elevator drive menu 0 and advanced parameters within the elevator drive the menu select parameter F51 must be set to Normal

To use the F menu the SM-Keypad Plus must also have the correct text file programmed and the elevator drive software must be ≥ V01.18

7.7.1 Selecting F-Menu configuration with SM-Keypad Plus

The F-menu can be used for fast set-up of the elevator drive with a suitable programmed SM-Keypad Plus. The parameters of this menu are arranged in the order of the set-up.

To configure the elevator drive menu 0 for the F menu:

Enable F-Menu:

Pr 41.51 = Filter > Display F-Menu

To configure the elevator drive for the standard elevator drive menu 0:

Enable Drive-Menu:

Pr F51 = Normal > Display Unidrive SP-Drive-Menu

Parameter access, Security code

For the pre-configured F menu there is no security code required. Selecting the F menu automatically limits access to just the F menu. All advanced parameter access is disabled.

Defaults

All parameters used for the elevator drive software can only be set back to the default values through the advanced parameters. Pr 18.50 = OFF (0), this will automatically set the elevator drive software parameters to their default values and carry out a save, all previous parameter adjustments are over written.

7.7.2 Advanced parameters

In addition to the F menu for the elevator drive there are advanced menus that can also be accessed. This can be carried out by either setting parameter F51 = Normal when operating in the F menu, or by simply fitting a standard SM-Keypad to the elevator drive.

Table 7-6 F Menu, single line descriptions

Parameter	Description	Type	Range	Default			Units
				OL	VT	SV	
F00	xx.00 Pr 00 for code entry	RW	0 to 32,767				
F01	11.31 Operating mode	RW	OPEn LP, CL VECT, SERVO	OPEn LP	CL VECT	SERVO	
F02	19.26 Number of direction inputs	RW	0 to 1	0			
F03	3.38 Drive encoder type	RW	0 to 9	Ab(0)		Ab.Servo (3)	
F04	3.41 Drive encoder auto configuration	RW	OFF (0) or On (1)	OFF (0)			
F05	3.34 Drive encoder lines per revolution	RW	0 to 50,000	1024		4096	PPR
F06	3.26 Drive encoder supply voltage	RW	5V (0) 8V (1) 15V (2)	5V (0)			V
F07	5.07 Motor rated current	RW	0 to Rated current max	In motor			A
F08	5.09 Motor rated voltage	RW	0 to AC voltage set max	Vn motor			V
F09	5.11 Number of motor poles	RW	Auto to 120 poles (0 - 60)	Auto (0)		6-pole (3)	
F10	5.08 Nominal speed	RW	0.00 to 40,000.00	1,500	1,450		rpm
F10	4.15 Motor thermal time constant	RO	0 to 3000.0			89.0	
F11	5.10 Power factor	RW	0.000 to 1.000	0.85			
F11	3.25 Encoder phase angle	RW	0.0 to 359.9				0
F12	5.18 Switching frequency	RW	3(0),4(1),6(2),8(3),12(4),16(5)	3kHz (0)		6kHz (0)	kHz
F13	4.07 Symmetrical current limit (Pre V1.21)	RW	0 to Motor current limit max	165.0	175.0		%
	5.06 Motor rated frequency (V1.21 onwards)		0 to Motor rated frequency	50			Hz
F14	5.12 Autotune	RW	0 to 6	0			
F15	19.29 Sheave diameter	RW	0 to 32,767	480			mm
F16	20.10 Roping	RW	1:1 (1) 2:1 (2) 3:1 (3) 4:1 (4)	1			
F17	19.27 Gear ratio denominator	RW	0 to 32,767	1			
F18	19.30 Gear ratio numerator	RW	0 to 32,767	31			
F19	18.30 Nominal elevator speed mm/s	RW	0 to 10,000	800			mm/s
F20	19.31 Enable operational rpm configuration	RW	OFF (0) or On (1)	On (1)			
F21	18.29 Nominal elevator speed rpm	RW	0 to 10,000	987			rpm
F22	1.06 Maximum speed clamp (Pre V1.21)	RW	Speed limit max	50Hz	1,500rpm	3,000rpm	Hz / rpm
	4.07 Symmetrical current limit (V1.21 onwards)		0 to Motor current limit max	165.0	175.0		%
F23	18.45 Direction invert	RW	OFF (0) or On (1)	OFF (0)			
F24	18.11 V1 Creep speed	RW	0 to 10,000	50			mm/s
F25	18.12 V2 Inspection speed	RW	0 to 10,000	10			mm/s
F26	18.13 V3 Nominal speed	RW	0 to 10,000	100			mm/s
F27	18.14 V4 Medium speed 1	RW	0 to 10,000	300			mm/s
F28	18.15 V5 Releveling speed	RW	0 to 10,000	500			mm/s
F29	18.16 V6 Medium speed 2	RW	0 to 10,000	800			mm/s
F30	18.17 V7 Additional speed 1	RW	0 to 10,000	1000			mm/s
F31	19.28 Time for Start optimizer	RW	0 to 10,000	700			ms
F32	2.11 Acceleration rate	RW	0.0 to 3,200.000	50	0.500		cm/s ² or m/s ²
F33	2.21 Deceleration rate	RW	0.0 to 3,200.000	80	0.800		cm/s ² or m/s ²
F34	19.14 Start jerk	RW	0 to 10,000	500			mm/s ³
F35	19.15 Run jerk	RO	0 to 10,000	1000			mm/s ³
F36	19.16 Stop jerk	RW	0 to 10,000	800			mm/s ³
F37	19.25 Brake release delay	RW	0 to 10,000	500			ms
F38	18.24 Brake apply delay	RW	0 to 10,000	1000			ms
F39	4.23 Current filter 1 Start	RW	0 to 25.0		0.0		ms
F40	4.12 Current filter 2 Travel	RW	0 to 25.0		2.0		ms
F41	4.13 Current loop Kp - Gain 2 Travel	RW	0 to 30,000	20	150	75	
F42	4.14 Current loop Ki - Gain 2 Travel	RW	0 to 30,000	40	2000	1000	
F43	18.27 Speed loop Kp - Gain 1 Start	RW	0 to 20,000		1000		1/rad s ⁻¹
F44	18.28 Speed loop Ki - Gain 1 Start	RW	0 to 20,000		1000		1/rad s ⁻¹

Parameter	Description	Type	Range	Default			Units
				OL	VT	SV	
F45	18.25	Speed loop Kp - Gain 2 Travel	RW	0 to 20,000		500	1/rad s ⁻¹
F46	18.26	Speed loop Ki - Gain 2 Travel	RW	0 to 20,000		500	1/rad s ⁻¹
F47	19.20	P-gain Start locking	RW	0 to 20,000		10	1/rad s ⁻¹
F48	4.20	Percentage load	RW	± User current max			%
F49	19.02	Actual speed	RW	± 32,000			mm/s
F50	18.10	Reference parameter selected	RW	Pr 18.11 to Pr 18.17 Pr 20.22 to Pr 20.24		18.10	Pr xx.xx
F51	41.51	Change F Menu	RO	Filter OR Normal		Filter	

Following are the standard default F menu parameters available with remote keypad operation over the elevator controller display.

Pr	Description	Type	Range	Default
F52	Remote keypad language	RW	English, Deutsche	English
F53	Software version	RO	xxx	
F54	Software variant	RO	+10614	±10614
F55	Remote keypad reset	RW	0 or 1	0

7.8 Menu 18 parameters

Parameter			Description	Type	Range	Default			Units
						OL	VT	SV	
18.01			Not used						
18.02		0.15[3]	Deceleration following error	RO	0 to 32,000		0		mm
18.03		0.13[1]	Calculated nominal elevator speed	RO	0 to 32,000		987		rpm
18.04		0.23[4]	Control terminal status	RO	00000 to 11111				
18.05		0.24[4]	Control terminal status	RO	00000 to 11111				
18.06		0.27[4]	Maximum distance error [t071]	RO	0 to 32,000				mm
18.07		0.25[4]	Maximum speed error [t070]	RO	0 to 32,000				mm/s
18.08			Torque for inertia compensation	RO	0 to 32,000				0.10%
18.09		0.21[3]	Remaining floor sensor distance	RO	0 to 32,000				mm
18.10	F50	0.28[0]	Reference parameter selected	RO	Pr 18.11 to Pr 18.17, Pr 20.22 to Pr 20.24		18.10		
18.11	F24	0.15[0]	V1 Creep speed	RW	0 to 10,000		50		mm/s
18.12	F25	0.16[0]	V2 Inspection speed	RW	0 to 10,000		400		mm/s
18.13	F26	0.17[0]	V3 Nominal speed	RW	0 to 10,000		800		mm/s
18.14	F27	0.18[0]	V4 Medium speed 1	RW	0 to 10,000		100		mm/s
18.15	F28	0.19[0]	V5 Relevelling speed	RW	0 to 10,000		100		mm/s
18.16	F29	0.20[0]	V6 Medium speed 2	RW	0 to 10,000		100		mm/s
18.17	F30	0.21[0]	V7 Additional speed 1	RW	0 to 10,000		100		mm/s
18.18		0.18[1]	Speed for Start optimizer	RW	0 to 10,000		10		mm/s
18.19		0.20[3]	Floor sensor target distance	RW	0 to 10,000		0		mm
18.20		0.26[3]	Short floor landing distance	RW	0 to 10,000		0		mm
18.21		0.26[0]	Speed threshold 1	RW	0 to 32,767		300		mm/s
18.22		0.27[0]	Speed threshold 2	RW	0 to 32,767		500		mm/s
18.23		0.29[2]	Magnetisation current threshold [t076]	RW	0 to 990		500		0.1%
			Demagnetising time		0 to 990			200	
18.24	F38	0.25[1]	Brake apply delay	RW	0 to 10,000		1000		ms
18.25	F45	0.23[2]	Speed loop Kp - Gain 2 Travel	RW	0 to 65,535		500		1/rad s ⁻¹
18.26	F46	0.24[2]	Speed loop Ki - Gain 2 Travel	RW	0 to 65,535		500		1/rad s ⁻¹
18.27	F43	0.25[2]	Speed loop Kp - Gain 1 Start	RW	0 to 65,535		1000		1/rad s ⁻¹
18.28	F44	0.26[2]	Speed loop Ki - Gain 1 Start	RW	0 to 65,535		1000		1/rad s ⁻¹
18.29	F21	0.13[0]	Nominal elevator speed rpm	RW	0 to 4,000		987		rpm
18.30	F19	0.14[0]	Nominal elevator speed mm/s	RW	0 to 10,000		800		mm/s
18.31		0.19[4]	Brake output status [T.25]	RO	OFF (0) or On (1)		OFF (0)		
18.32			Speed threshold 1 status [T.24]	RW	OFF (0) or On (1)		OFF (0)		
18.33			Speed threshold 2 status	RW	OFF (0) or On (1)		OFF (0)		
18.34			Standstill	RO	OFF (0) or On (1)		On (1)		
18.35			Enable short floor landing	RW	OFF (0) or On (1)		OFF (0)		
18.36			Reference select Bit 0	RW	OFF (0) or On (1)		OFF (0)		
18.37			Reference select Bit 1	RW	OFF (0) or On (1)		OFF (0)		
18.38			Reference select Bit 2	RW	OFF (0) or On (1)		OFF (0)		
18.39			Reference select Bit 3	RW	OFF (0) or On (1)		OFF (0)		
18.40			Reference select Bit 4	RW	OFF (0) or On (1)		OFF (0)		
18.41			Reference select Bit 5	RW	OFF (0) or On (1)		OFF (0)		
18.42		0.21[1]	Reference selector type	RW	OFF (0) or On (1)		OFF (0)		
18.43		0.18[4]	Motor magnetized [t076]	RO	OFF (0) or On (1)		OFF (0)		
18.44			CCW direction	RO	OFF (0) or On (1)		OFF (0)		
18.45	F23	0.22[1]	Invert direction	RW	OFF (0) or On (1)		OFF (0)		
18.46			Enable load measurement	RW	OFF (0) or On (1)		OFF (0)		
18.47		0.27[1]	Enable peak curve operation	RW	OFF (0) or On (1)		OFF (0)		
18.48		0.21[2]	Enable separate Start - Travel gains	RW	OFF (0) or On (1)		On (1)		
			Open loop motor resistance control		OFF (0) or On (1)	On (1)			
18.49		0.28[2]	Enable Inertia compensation	RW	OFF (0) or On (1)		OFF (0)		
18.50			Default elevator software parameters	RW	OFF (0) or On (1)		On (1)		

18.02	Deceleration following error										
Variants	Unidrive SP, Unidrive ES										
Drive modes	Closed-loop vector, Servo										
Coding	Bit	Txt	VM	RO	US	RW					
				1							
Range	Closed-loop vector, Servo					0 to 32,000 (mm)					
Linked to	Pr 0.15[3]										
Update rate	Background read										

This parameter displays the following error during deceleration.


18.03	Calculated nominal elevator speed										
Variants	Unidrive SP, Unidrive ES										
Drive modes	Open-loop, Closed-loop vector, Servo										
Coding	Bit	Txt	VM	RO	US	RW					
				1							
Range	Open-loop, Closed-loop vector, Servo					0 to 32,000 (rpm)					
Linked to	Pr 0.13[1]										
Update rate	4ms read										

This is the nominal elevator rpm (actual speed of the elevator motor before taking into account the gearing, roping etc) and is derived from the operational rpm configuration F20, Pr 0.37[1], Pr 19.31.

18.04	Terminal status										
18.05	Terminal status										
Variants	Unidrive SP, Unidrive ES										
Drive modes	Open-loop, Closed-loop vector, Servo										
Coding	Bit	Txt	VM	RO	US	RW					
				1							
Range	Open-loop, Closed-loop vector, Servo					00000 to 11111					
Linked to	Pr 0.23[4], Pr 0.24[4]										
Update rate	Background read										

For analyzing the status of the control terminals on the Unidrive SP / Unidrive ES, Pr 18.04, Pr 18.05 are arranged in groups and displayed as follows. Also available through Menu 0 diagnostics Pr 0.23[4] and Pr 0.24[4].

Figure 7-2 Control terminal status



18.06	Maximum distance error [t071]										
Variants	Unidrive SP, Unidrive ES										
Drive modes	Open-loop, Closed-loop vector, Servo										
Coding	Bit	Txt	VM	RO	US	RW					
				1							
Range	Open-loop, Closed-loop vector, Servo					0 to 32,000 (mm)					
Linked to	Pr 0.27[4]										
Update rate	Background read										

This parameter displays the actual distance error. The distance error is the integral of the difference between the ramp speed Pr 19.03 and the actual speed of the motor F49, Pr 0.34[0], Pr 19.02. The distance error is compared with an allowable threshold set in Pr 0.28[4], Pr 19.18. If the distance error exceeds the user defined threshold, a t071 trip is generated.

The distance error during one travel is displayed in Pr 0.27[4], Pr 18.06 independent of the activation of the error detection. The display is reset to 0 at each start. The maximum distance error detection, and t071 trip can both be disabled by setting Pr 0.28[4], Pr 19.18 = 0.

18.07	Maximum speed error [t070]										
Variants	Unidrive SP, Unidrive ES										
Drive modes	Open-loop, Closed-loop vector, Servo										
Coding	Bit	Txt	VM	RO	US	RW					
				1							
Range	Open-loop, Closed-loop vector, Servo					0 to 32,000 (mm/s)					
Linked to	Pr 0.25[4]										
Update rate	Background read										

This parameter displays the actual speed error.

For **open loop** mode the speed error detection is activated once the drive reaches current limit operation with the trip being generated after the time defined in Pr 19.24 (2s default). Pr 19.24 defines the maximum allowable time to operate in current limit, high settings will result in the detection being disabled.

For **closed loop** the speed error is calculated from the difference between the ramp speed Pr 19.03 and to the actual speed of the motor in F49, Pr 0.34[0], Pr 19.02.

The speed error is compared with the user setting of the allowable threshold set in Pr 0.26[4], Pr 19.24. If the threshold is exceeded for more than 100ms a Trip 70 is generated by the Elevator Solution Software.

The speed error during one travel is displayed in Pr 0.25[4], Pr 18.07 independent of the activation of the speed error detection. The display is reset to 0 at each start. The Speed error detection can be disabled by setting Pr 0.26[4] (Pr 19.24) = 0.

18.08	Torque for inertia compensation										
Variants	Unidrive SP, Unidrive ES										
Drive modes	Open-loop, Closed-loop vector, Servo										
Coding	Bit	Txt	VM	RO	US	RW					
				1							
Range	Open-loop, Closed-loop vector, Servo					0 to 32,000 (0.1%)					
Linked to											
Update rate	Background read										

This is the level of torque that has been applied for the Inertia compensation. The inertia compensation has to be enabled with Pr 0.28[2], Pr 18.49 = On (1) for this parameter to display the level of torque for the inertia compensation.

18.09	Remaining floor sensor correction distance											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1								
Range	Closed-loop vector, Servo						0 to 32,000 (mm)					
Linked to	Pr 0.21[3]											
Update rate	Background read											

This parameter displays the remaining distance to the floor level once the floor sensor active limit switch has been reached. This parameter, once the floor sensor active signal has been triggered, will display the actual position of the elevator as it approaches the floor. On reaching the floor level Pr 0.21[3], Pr 18.09 = 0 ±1 mm

If the stop distance is too low or the floor sensor signal is given at too high a speed, it is possible that the elevator may not stop smoothly and a hard stop will occur.

- Pr 0.17[3], Pr 19.42 Enable floor sensor correction
- Pr 0.19[3], Pr 20.14 Floor sensor correction
- Pr 0.20[3], Pr 18.19 Floor sensor correction target distance

To monitor the function, the following RO parameters can be used:

- Pr 0.23[3], Pr 20.05 Time from floor sensor correction active to stop
- Pr 0.22[3], Pr 19.09 Speed at floor sensor correction active
- Pr 0.21[3], Pr 18.09 Remaining floor sensor correction distance

18.10	Reference parameter selected											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1								
Range	Open-loop, Closed-loop vector, Servo						Pr 18.10 to 18.17 Pr 20.22 to 20.24					
Linked to	F50, Pr 0.28[0]											
Update rate	4ms read											

This parameter displays the speed reference that has been selected using the drives control terminals. When Pr 18.10 = 1810 this indicates that no speed reference has been selected.

Speed references can be viewed in F24, Pr 0.15[0], Pr 18.11 to F30, Pr 0.21[0], Pr 18.17 and Pr 0.31[0], Pr 20.22 to Pr 0.33[0], Pr 20.24.

Parameter 18.10	Description	Set-up parameter
1810	No speed selected	N/A
1811	V1 Creep speed	F24, Pr 0.15[0], Pr 18.11
1812	V2 Inspection speed	F25, Pr 0.16[0], Pr 18.12
1813	V3 Nominal speed	F26, Pr 0.17[0], Pr 18.13
1814	V4 Medium speed 1	F27, Pr 0.18[0], Pr 18.14
1815	V5 Releveling speed	F28, Pr 0.19[0], Pr 18.15
1816	V6 Medium speed 2	F29, Pr 0.20[0], Pr 18.16
1817	V7 Additional speed 1	F30, Pr 0.21[0], Pr 18.17
2022	V8 Additional speed 2	Pr 0.31[0], Pr 20.22
2023	V9 Additional speed 3	Pr 0.32[0], Pr 20.23
2024	V10 Additional speed 4	Pr 0.33[0], Pr 20.24

18.11	V1 Creep speed											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector, Servo						0 to 10,000 (mm/s)					
Default	Open-loop, Closed-loop vector, Servo						50					
Linked to	F24, Pr 0.15[0]											
Update rate	4ms read											

NOTE

At default the creep speed parameter is Pr 18.11. To change this configuration refer to Pr 20.12.

18.12	V2 Inspection speed											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector, Servo						0 to 10,000 (mm/s)					
Default	Open-loop, Closed-loop vector, Servo						400					
Linked to	F25, Pr 0.16[0]											
Update rate	4ms read											

18.13	V3 Nominal speed											
Variants	V3 Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector, Servo						0 to 10,000 (mm/s)					
Default	Open-loop, Closed-loop vector, Servo						800					
Linked to	F26, Pr 0.17[0]											
Update rate	4ms read											

18.14	V4 Medium speed 1											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector, Servo						0 to 10,000 (mm/s)					
Default	Open-loop, Closed-loop vector, Servo						100					
Linked to	F27, Pr 0.18[0]											
Update rate	4ms read											

18.15	V5 Releveling speed											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector, Servo						0 to 10,000 (mm/s)					
Default	Open-loop, Closed-loop vector, Servo						100					
Linked to	F28, Pr 0.19[0]											
Update rate	4ms read											

18.16	V6 Medium speed 2																																								
Variants	Unidrive SP, Unidrive ES																																								
Drive modes	Open-loop, Closed-loop vector, Servo																																								
Coding	<table border="1"> <tr> <td>Bit</td> <td>Txt</td> <td>VM</td> <td>RO</td> <td>US</td> <td>RW</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>1</td> <td>1</td> <td></td> </tr> </table>	Bit	Txt	VM	RO	US	RW																			1	1														
Bit	Txt	VM	RO	US	RW																																				
				1	1																																				
Range	Open-loop, Closed-loop vector, Servo 0 to 10,000 (mm/s)																																								
Default	Open-loop, Closed-loop vector, Servo 100																																								
Linked to	F29, Pr 0.20[0]																																								
Update rate	4ms read																																								

18.17	V7 Additional speed 1																																								
Variants	Unidrive SP, Unidrive ES																																								
Drive modes	Open-loop, Closed-loop vector, Servo																																								
Coding	<table border="1"> <tr> <td>Bit</td> <td>Txt</td> <td>VM</td> <td>RO</td> <td>US</td> <td>RW</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>1</td> <td>1</td> <td></td> </tr> </table>	Bit	Txt	VM	RO	US	RW																			1	1														
Bit	Txt	VM	RO	US	RW																																				
				1	1																																				
Range	Open-loop, Closed-loop vector, Servo 0 to 10,000 (mm/s)																																								
Default	Open-loop, Closed-loop vector, Servo 100																																								
Linked to	F30, Pr 0.21[0]																																								
Update rate	4ms read																																								

The above speeds **V2** through to **V7** are user defined speeds and can be re arranged, e.g **V2** can be Inspection speed or Medium speed. The only dedicated speed is the creep speed **V1** which is used for position calculations in functions like deceleration distance calculation, short distance landing and floor sensor correction. If another speed should be used as creep speed, the parameter number has to be adjusted in Pr **20.12**. For selection of the speeds **V1** through to **V7** refer to Chapter 5 *I/O configuration* on page 53 of this User Guide.

From Elevator Solution Software version 01.12 onwards the deceleration distances for all speeds are displayed in Pr **2.13** to Pr **2.18** and Pr **2.23** to Pr **2.25** as shown in the following table.


Speed (mm/s)	Pr 18.12	Pr 18.13	Pr 18.14	Pr 18.15	Pr 18.16	Pr 18.17	Pr 20.02	Pr 20.23	Pr 20.24
Deceleration distance (cm)	Pr 2.13 Pr 0.31[3]	Pr 2.14 Pr 0.32[3]	Pr 2.15 Pr 0.33[3]	Pr 2.16 Pr 0.34[3]	Pr 2.17 Pr 0.35[3]	Pr 2.18 Pr 0.36[3]	Pr 2.23 Pr 0.37[3]	Pr 2.24 Pr 0.51[3]	Pr 2.25 Pr 0.52[3]

18.18	Speed for Start optimizer																																								
Variants	Unidrive SP, Unidrive ES																																								
Drive modes	Open-loop, Closed-loop vector, Servo																																								
Coding	<table border="1"> <tr> <td>Bit</td> <td>Txt</td> <td>VM</td> <td>RO</td> <td>US</td> <td>RW</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>1</td> <td>1</td> <td></td> </tr> </table>	Bit	Txt	VM	RO	US	RW																			1	1														
Bit	Txt	VM	RO	US	RW																																				
				1	1																																				
Range	Open-loop, Closed-loop vector, Servo 0 to 10,000 (mm/s)																																								
Default	Open-loop, Closed-loop vector, Servo 10																																								
Linked to	Pr 0.18[1]																																								
Update rate	Background read																																								

The Start optimizer is used to overcome starting difficulties or static friction in the elevator and could be associated to the rucksack mechanical arrangement. The start optimizer is activated by setting the start optimization time in parameter **F31, Pr 0.19[1], Pr 19.28**.

In addition to the start optimization time there is also a speed **Pr 0.18[1], Pr 18.18** and a jerk **Pr 0.20[1], Pr 19.17** for the start optimization function. On completion of the start optimizer, the standard Run jerk becomes the active parameter **F34, Pr 0.23[0], Pr 19.14** as the elevator then follows the standard velocity profile.

Figure 7-3 Start optimizer



18.19	Floor sensor correction target distance												
Variants	Unidrive SP, Unidrive ES												
Drive modes	Closed-loop vector, Servo												
Coding	Bit	Txt	VM	RO	US	RW							
					1	1							
Range	Closed-loop vector, Servo						0 to 10,000 (mm)						
Default	Closed-loop vector, Servo						0						
Linked to	Pr 0.20[3]												
Update rate	Background read												

This parameter defines the floor sensor correction distance (distance from floor sensor to floor level). This is set-up by the user based upon the position of the floor sensor limit switch in the elevator shaft.

Pr 0.21[3], Pr 18.19 displays the initial floor sensor correction target distance and Pr 0.21[3], Pr 18.09 displays the remaining floor sensor correction distance updated position as the elevator approaches the floor level.

If the stop distance is too low or the floor sensor signal is given at too high a speed, it is possible that the Elevator may not stop smoothly and a hard stop will occur.

- Pr 0.17[3], Pr 19.42 Enable floor sensor correction
- Pr 0.19[3], Pr 20.14 Floor sensor correction source

To monitor this function the following RO parameters can be used:

- Pr 0.21[3], Pr 18.09 Remaining floor sensor correction distance
- Pr 0.23[3], Pr 20.05 Time from floor sensor correction active to stop

18.20	Short landing distance												
Variants	Unidrive SP, Unidrive ES												
Drive modes	Open-loop, Closed-loop vector, Servo												
Coding	Bit	Txt	VM	RO	US	RW							
					1	1							
Range	Open-loop, Closed-loop vector, Servo						0 to 10,000 (mm)						
Default	Open-loop, Closed-loop vector, Servo						0						
Linked to	Pr 0.26[3]												
Update rate	Background read												

If the floor distance is smaller than the braking time distance from the selected speed, peak curve operation cannot be used. This is the case if the floor distance is less than 0.7 m for example. For such small floor distances, the elevator software function provides the short floor landing distance with real distance control. Short floor landing is enabled with Pr 18.35, which at default is OFF (0).

The short floor landing distance is set-up in Pr 0.26[3], Pr 18.20 and the short floor landing enabled with a digital output from the elevator controller to a digital input on the drive at the floor level.

The control signals for creep speed and short floor landing must be applied simultaneously. The speed profile is internally calculated in order that the creep speed is reached after the short floor landing distance Pr 0.26[3], Pr 18.20. If the creep speed command is disabled, the drive will stop the car with the set deceleration.

18.21	Speed threshold 1											
18.22	Speed threshold 2											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector, Servo						0 to 32,767 (mm/s)					
Default	Open-loop, Closed-loop vector, Servo						speed threshold 1 - 300 speed threshold 2 - 500					
Linked to	Pr 0.26[0], Pr 0.27[0]											
Update rate	Background read											

The above parameters are used to set-up the thresholds for both speed threshold 1 and 2. These speed thresholds could be used for advanced door opening, and speed monitoring for example.

From the default settings of the Elevator Solution Software there is an advanced door opening feature available. This is configured in the software and output on T.24 (Speed threshold 1). The advanced door opening is configured to allow the speed at which the advanced door opening is active and is adjustable through Pr 0.26[0], Pr 18.21.

If required the output on T.24 can also be inverted with Pr 8.11. The status of the advanced door opening with speed threshold 1 can be viewed in Pr 18.32.

18.23	Magnetizing current threshold [t076] Demagnetization time, Servo mode											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector Servo						0 to 990 (0.1 %) 0 to 990 (ms)					
Default	Open-loop, Closed-loop vector Servo						500 200					
Linked to	Pr 0.29[2]											
Update rate	Background read											

Open loop, Closed loop Magnetizing current threshold

This is the threshold for which the motor magnetized function operates, once the motor has magnetized the brake release signal is activated. If the motor does not reach the motor magnetized threshold following an enable and a time delay a t076 trip is generated. The motor magnetized status is available in Pr 0.18[4], Pr 18.43.

The t076 trip is normally associated to either a motor connection or output motor contactor connection error. Or the magnetization threshold is set to high for the motors rated magnetization current.

Servo Demagnetization time

This parameter sets the time taken for the permanent magnet motor to demagnetize, once the demagnetized time has elapsed the enable is removed and the motor contactor opened. During the demagnetization time period set in Pr 18.23, the current limits in Pr 4.05 and Pr 4.06 are reduced to prevent any knocking sound during the end of travel. The time can be adjusted where required.

18.24	Brake apply delay											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector Servo						0 to 10,000 (ms)					
Default	Open-loop, Closed-loop vector, Servo						1000					
Linked to	F38, Pr 0.25[1]											
Update rate	4ms read											

Brake control using drive

In the default condition the brake controller is set-up to provide a brake release output signal on control terminal 25 of the drive, Pr 8.22 = 18.31. The brake release becomes active once the motor magnetized threshold condition is reached in Pr 0.29[2], Pr 18.23.

The status of the brake control is available in Pr 0.19[4], Pr 18.31 and the motor magnetized status is available in Pr 0.18[4], Pr 18.43. If the drive trips at any stage the brake control will become inactive and the brake will be forced to close by the elevator controller.

Brake control using elevator controller

If the elevator controller is carrying out the brake control, control terminal 25 on the drive can now be configured as "motor magnetized output"
Pr 8.22 = 18.43.

Brake apply delay F38, Pr 0.25[0], Pr 18.24

Brake release delay F37, Pr 0.24[1], Pr 19.25

Brake output status Pr 0.19[4] Pr 18.31

18.25	Speed Loop Kp - Gain 2 Travel											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Closed-loop vector, Servo						0 to 32,767 ($[0.0001 * 1/\text{rad s}^{-1}]$)					
Default	Closed-loop vector, Servo						500					
Linked to	F45, Pr 0.23[2]											
Update rate	Background read											

18.26	Speed Loop Ki - Gain 2 Travel											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Closed-loop vector, Servo						0 to 32,767 ($[0.01 * \text{s}/\text{rad s}^{-1}]$)					
Default	Closed-loop vector, Servo						500					
Linked to	F46, Pr 0.24[2]											
Update rate	Background read											

18.27	Speed Loop Kp - Gain 1 Start											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Closed-loop vector, Servo						0 to 32,767 ($[0.0001 * 1/\text{rad s}^{-1}]$)					
Default	Closed-loop vector, Servo						1000					
Linked to	F43, Pr 0.07[0], Pr 0.25[2]											
Update rate	Background read											

18.28	Speed Loop Ki - Gain 1 Start											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Closed-loop vector, Servo						0 to 32,767 ($[0.01 * \text{s}/\text{rad s}^{-1}]$)					
Default	Closed-loop vector, Servo						1000					
Linked to	F44, Pr 0.08[0], Pr 0.26[2]											
Update rate	Background read											

For optimization of the speed loop on Unidrive SP the following gains are available,

- Kp** Proportional Gain
- Ki** Integral Gain
- Kd** Differential Gain

The following parameters can be used to monitor the performance of the drive during adjustment of the speed loop gains, comparing the speed reference to the speed feedback. Adjustment of the speed loop gains is carried out to minimize the speed loop following error and reach the required performance.

- Pr 3.01 Final speed reference
- Pr 3.02 Unidrive SP speed feedback
- Pr 3.03 Speed loop following error

NOTE

In addition to the speed loop gains, there is also a speed feedback filter Pr 3.42 which can be adjusted to improve the speed feedback for the closed loop control.

NOTE

In order to tune the speed loop the worst case conditions must be used, low speed and high speed under both full and low load conditions.

Kd Differential Gain

For virtually all elevator applications the Kd differential gain is not required. Therefore when referring to tuning of the speed loop gains we refer mainly to the Kp proportional and Ki integral gains.

Kp Proportional Gain

If Kp proportional gain has a value and Ki is set to zero the controller will only have a proportional term, and there must be a speed error to produce a torque reference. As the motor load increases there will be a difference between the speed reference and actual speed (speed feedback). This effect, called regulation depends on the level of the proportional gain, the higher the gain, the smaller the speed following error for a given load.

If the Kp proportional gain is too low for a given load condition;


- The speed following error will increase
- Speed droop and overshoot can be present during transitions in speed reference
- Oscillations can be present during constant speed operation.

If the Kp proportional gain is increased for a given load the speed following error along with the speed droop and overshoot will be reduced.

If the Kp proportional gain is increased too high, either;

- The acoustic noise generated from the motor due to the Kp proportional gain amplifying the speed feedback quantization, will become unacceptably high.
- The closed loop stability limit will be reached where quantization due to the encoder feedback resolution will appear on the speed feedback as oscillations.

Figure 7-4 Speed loop Kp Proportional gain




Ki Integral Gain

The Ki integral gain responds proportionally to the accumulated speed error over a period of time. The Ki integral gain prevents regulation and increases the output dynamic performance.

- Increasing the integral gain reduces the time taken for the speed to reach the correct level and increases the stiffness of the system, i.e. it reduces the shaft displacement produced when applying a load torque to the motor.
- Increasing the integral gain also reduces the system damping giving overshoot after a transient. For a given Ki integral gain the damping can be improved by further increasing the Kp proportional gain.
- A compromise must be reached where the system response, stiffness and damping are all adequate for the application.

Figure 7-5 Speed loop Ki Integral gain



NOTE

The resolution of the encoder feedback device will affect the maximum achievable Kp proportional gain. Higher resolution encoders such as Sincos encoders provide much higher resolution and are the preferred feedback device for high ride quality.

Ab 1024 ppr encoder **10bit** (10bit incremental)

SinCos 1024 ppr encoder **20bit** (10bit incremental + 10bit interpolated)

18.29	Nominal elevator speed												
Variants	Unidrive SP, Unidrive ES												
Drive modes	Open-loop, Closed-loop vector, Servo												
Coding	Bit	Txt	VM	RO	US	RW							
					1	1							
Range	Open-loop, Closed-loop vector, Servo						0 to 4,000 (rpm)						
Default	Open-loop, Closed-loop vector, Servo						987						
Linked to	F21, Pr 0.13[0]												
Update rate	4ms read												

This is the actual speed of the elevator motor before taking into account the gearing and roping etc and is used by the operational rpm configuration **F20, Pr 0.37[1], Pr 19.31** to calculate the final elevator nominal speed in rpm for **F21, Pr 0.13[1], Pr 18.03**.

18.30	Nominal elevator speed												
Variants	Unidrive SP, Unidrive ES												
Drive modes	Open-loop, Closed-loop vector, Servo												
Coding	Bit	Txt	VM	RO	US	RW							
					1	1							
Range	Open-loop, Closed-loop vector, Servo						0 to 10,000 (mm/s)						
Default	Open-loop, Closed-loop vector, Servo						800						
Linked to	F19, Pr 0.14[0]												
Update rate	4ms read												

This is the nominal rated speed for the elevator in mm/s and is used by the operational rpm configuration **F20, Pr 0.37[1], Pr 19.31** to calculate the elevator nominal speed in rpm for **F21, Pr 0.13[1], Pr 18.03**.

18.31	Brake output status											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1			1								
Range	Open loop, Closed-loop vector, Servo						OFF(0) or On(1)					
Linked to	Pr 0.19[4]											
Update rate	Background read											

This parameter displays the status of the software control brake output signal. At default the brake control output is set-up for control terminal T.25. Brake released = ON, Brake applied = OFF.

Brake apply delay **F38**, Pr **0.25[0]**, Pr **18.24**

Brake release delay **F37**, Pr **0.24[1]**, Pr **19.25**

Brake output status Pr **0.19[4]** Pr **18.31**

18.32	Speed threshold 1 status [Advanced door opening]											
18.33	Speed threshold 2 status											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1			1								
Range	Open loop, Closed-loop vector, Servo						OFF(0) or On(1)					
Linked to												
Update rate	Background read											

These parameters display the status of the user defined speed threshold outputs, which could be used for features such as advanced door opening or speed monitoring for example. At default speed threshold 1 is set up for advanced door opening on T.24 [Pr 8.21 = 18.32]

18.34	Standstill											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1								
Range	Open loop, Closed-loop vector, Servo						OFF(0) or On(1)					
Linked to												
Update rate	Background read											

This parameter indicates when the elevator is at standstill, this being used for speed loop and current loop gain selection along with current loop filters and elevator operational status.

18.35	Enable short distance landing											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Open loop, Closed-loop vector, Servo						OFF(0) or On(1)					
Default	Open loop, Closed-loop vector, Servo						OFF (0)					
Linked to												
Update rate	Background read											

If the short floor distance is smaller than the braking time distance from the selected speed, peak curve operation cannot be used. This is the case if the floor distance is less than 0.7 m for example.

For such small floor distances, the elevator software function provides the short floor landing with real distance control. Short floor landing is enabled using Pr **18.35** via an additional digital input on the drive. The short floor landing distance is set-up in Pr **0.26[3]**, Pr **18.20** and enabled with the digital input from the elevator controller to the drive at the floor level sensor.

The control signals for creep speed and short distance landing must be applied simultaneously. The speed profile is internally calculated in order that the creep speed is reached after the short floor landing distance Pr **0.26[3]** (Pr **18.20**). If the creep speed command is disabled, the drive will stop the car with the set deceleration.

18.36	Reference select Bit 0											
18.37	Reference select Bit 1											
18.38	Reference select Bit 2											
18.39	Reference select Bit 3											
18.40	Reference select Bit 4											
18.41	Reference select Bit 5											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Open loop, Closed-loop vector, Servo						OFF(0) or On(1)					
Default	Open loop, Closed-loop vector, Servo						OFF (0)					
Linked to												
Update rate	Background read											

18.42	Reference selector type											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Open loop, Closed-loop vector, Servo						OFF(0) or On(1)					
Default	Open loop, Closed-loop vector, Servo						OFF (0)					
Linked to	Pr 0.21[1]											
Update rate	Background read											

Speed selection can be configured for either binary (up to 10 speeds) or priority (up to 7 speeds) selection. Selection of either binary or priority speed selection is dependant on the elevator controller, and user requirements. Priority speeds can be increased further by introducing an SM-I/O Plus Solutions Module if required. The default setting for the speed selection is binary selection. To switch to priority speed selection (1 of n), set Pr **0.21[1]** (Pr **18.42**) = On.

18.43	Motor magnetized (t076)											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1			1								
Range	Open loop, Closed-loop vector, Servo						OFF(0) or On(1)					
Linked to	Pr 0.18[4]											
Update rate	Background read											

This is the motor magnetized status, following enable and once the motor has magnetized to the motor magnetized threshold level in Pr **0.29[2]**, Pr **18.23** this parameter will switch from OFF to ON and the brake release signal is activated. The magnetization current can also be viewed in Pr **20.07** as a percentage of the rated magnetization current.

If the motor does not reach the motor magnetized threshold following an enable a t076 trip is generated.

18.44	Direction input 1											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1			1								
Range	Open loop, Closed-loop vector, Servo						OFF(0) or On(1)					
Linked to												
Update rate	Background read											

This parameter displays the direction demanded (clockwise or counter clockwise) using the digital input when operating with either a single direction input Pr **19.26** = 0 or dual direction inputs Pr **19.26** = 1.

If Pr **19.26** = 0, single direction input then:

- Pr **18.44** = OFF (0) clockwise rotation demanded
- Pr **18.44** = On (1) counter clockwise rotation demanded

If Pr **19.26** = 1, dual direction inputs then:

- Pr **18.44** = OFF (0) no counter clockwise rotation demanded
- Pr **18.44** = On (1) counter clockwise rotation demanded.
- Pr **19.44** = OFF (0) no clockwise rotation demand
- Pr **19.44** = On (1) clockwise rotation demanded.

The direction input invert **F23**, Pr **0.22[1]**, Pr **18.45** inverts the direction but does not affect this parameter.

18.45	Invert direction											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Open-loop, Closed-loop vector, Servo						OFF(0) or On(1)					
Default	Open-loop, Closed-loop vector, Servo						OFF (0)					
Linked to	F23 , Pr 0.22[1]											
Update rate	4ms read											

This parameter can be used to invert the default single direction input on control terminal 28, or to invert the dual direction inputs on control terminals 27 and 28 to the drive.

Selection of single or multiple direction inputs is made through Pr **F02**, Pr **0.22[1]**, Pr **19.26**

Inverting the direction using this parameter does not affect Pr **18.44**.

18.46	Enable load measurement											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Open loop, Closed-loop vector, Servo						OFF(0) or On(1)					
Default	Open loop, Closed-loop vector, Servo						OFF (0)					
Linked to												
Update rate	Background read											

The load measurement feature allows load dependent torque compensation to be applied using Pr **4.08**. For this a load measuring transducer can be used that provides a ±10V signal that is proportional to load.

The measurement from the load cell is used during acceleration at the start and is then frozen once the contract speed is achieved for each travel.

18.47	Enable peak curve operation											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Closed-loop vector, Servo						OFF(0) or On(1)					
Default	Closed-loop vector, Servo						OFF (0)					
Linked to	Pr 0.27[1]											
Update rate	4ms read											

Peak curve operation guarantees a constant stopping distance, independent of the moment when the signal to stop occurs. This allows the use of a single speed for different floor leveling distances.

Peak curve operation modifies the maximum operating speed to ensure that the required distance is achieved and floor level is reached. The peak curve operation can be used during both creep-to-floor operation and distance controlled creep speed (Floor sensor correction mode).

The peak curve operation is enabled by setting Pr 0.27[1], Pr 18.47 = On. Depending on the speed when the speed signal is disabled, 3 different results can occur:

1. If the final speed is achieved there is no influence on the speed profile.
2. If there is increasing or constant acceleration, braking occurs with the normal profile parameters in a calculated time.
3. During deceleration and the transition to a stop, the profile parameters are automatically adjusted.

18.48	Enable separate Start - Travel gains											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Closed-loop vector, Servo						OFF(0) or On(1)					
Default	Closed-loop vector, Servo						On (1)					
Linked to	Pr 0.21[2]											
Update rate	4ms read											

Constant speed loop gains

Pr 0.21[2], Pr 18.48 = OFF

Separate Speed loop gains

Start, Travel

Pr 0.21[2], Pr 18.48 = On, Pr 19.48 = OFF

Separate Speed loop gains, Current loop gains, Current demand filter

Start, Travel, Stop

Pr 0.21[2], Pr 18.48 = On, Pr 19.48 = On

For most applications, the separate Start and Travel gains are suitable, and should allow the required ride comfort to be reached. If however problems are encountered during deceleration and stop, the Start, Travel, Stop gains can be enabled using Pr 19.48.

18.48	Open loop motor resistance control											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open loop											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Open loop						OFF(0) or On(1)					
Default	Open loop						On (1)					
Linked to	Pr 0.21[2]											
Update rate	4ms read											

Open loop motor stator resistance control is enabled with Pr 18.48 = On.

Once an autotune has been carried out, Pr 5.17 and Pr 21.12 are set-up with the actual value of the motors stator resistance. Pr 5.17 can then be optimised to achieve maximum starting torque. Pr 21.12 should remain at the autotune value for the stator resistance. The transition time between the start value in Pr 5.17 and the end value for the start in Pr 21.12 is determined by the transition time in Pr 19.11 ms. At the end of the travel on removal of the drive enable Pr 5.17 is reset to the optimized start value.

Pr 18.48 Enable variable stator resistance

Pr 5.17 Start stator resistance [optimum value for start]

Pr 21.12 Stop stator resistance [autotune value]

Pr 19.11 Stator resistance transition time

The optimum value for Pr 5.17 will need to be found when using different motors, and therefore adjustment and testing will be required to determine the correct level for maximum torque at the motor.

18.49	Enable inertia compensation											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Open-loop, Closed-loop vector, Servo						OFF(0) or On(1)					
Default	Open-loop, Closed-loop vector, Servo						OFF (0)					
Linked to	Pr 0.28[2]											
Update rate	4ms read											

Inertia compensation can be implemented to overcome system inertia and high speed loop gains (required due to no inertia compensation) resulting in motor noise. Implementing the inertia compensation therefore can allow high speed loop gains to be reduced.

Adjustment of the inertia compensation can be implemented through Pr 0.27[2], Pr 19.19 with this being adjusted with half load present in the elevator car. The inertia compensation torque is routed through to Pr 4.08 once enabled with Pr 0.28[2], Pr 18.49 = 1.

The inertia compensation can also be used to overcome encoder issues which can result in excessive speed ripple. The inertia compensation should be adjusted so that the speed controller output Pr 3.04 is virtually constant following brake release.

18.50	Default elevator parameters											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Open-loop, Closed-loop vector, Servo						OFF(0) or On(1)					
Default	Open-loop, Closed-loop vector, Servo						On(1)					
Linked to												
Update rate	4ms read											

The Default elevator parameters allows all elevator parameters used for the Elevator Solution Software to be set back to their original default values at any stage by setting Pr 18.50 = OFF.

Once Pr 18.50 is set to OFF it will take approximately 5s to default the elevators parameters and return to Pr 18.50 = On. This will automatically set parameters to their default values and carry out a save, with all previous parameters adjustments being over-written.

7.9 Menu 19 parameters

Parameter	Description		Type	Range	Default			Units
					OL	VT	SV	
19.01			Speed setpoint	RO	0 to 32,767		0	mm/s
19.02	F49	0.34[0]	Actual speed	RO	0 to 32,767		0	mm/s
19.03			Ramp speed	RO	0 to 32,767		0	mm/s
19.04			Reference acceleration	RO	0 to 32,767		0	mm/s ²
19.05		0.29[3]	Stopping distance	RO	0 to 32,767		13	mm
19.06		0.27[3]	Distance for peak curve	RO	0 to 32,767		0	mm
19.07		0.28[3]	Distance after peak curve	RO	0 to 32,767		0	mm
19.08		0.14[3]	Calculated deceleration distance	RO	0 to 32,767		0	mm
19.09		0.22[3]	Speed at floor sensor active	RO	0 to 32,767		0	mm/s
19.10		0.15[3]	Reference deceleration distance	RO	0 to 32,767		0	mm
19.11		0.22[2]	Variable gains transition time acceleration	RW	0 to 32,767		1000	ms
			Variable stator resistance time					
19.12		0.20[2]	D-gain Start locking	RW	0 to 65,535		0	
19.13		0.22[0]	Stop deceleration	RW	0 to 2,000		1000	mm/s ²
19.14	F34	0.23[0]	Start jerk	RW	0 to 10,000		500	mm/s ³
19.15	F35	0.24[0]	Run jerk	RW	0 to 10,000		1000	mm/s ³
19.16	F36	0.25[0]	Stop jerk	RW	0 to 10,000		800	mm/s ³
19.17		0.20[1]	Jerk for Start optimizer	RW	0 to 10,000	400	10	mm/s ³
19.18		0.28[4]	Maximum distance error threshold	RW	0 to 10,000		100	mm
19.19		0.27[2]	Inertia compensation scaling	RW	0 to 32,767		1000	0.1%
19.20	F47	0.19[2]	P-gain Start locking	RW	0 to 65,535		10	
19.21			Load measurement scaling	RW	0 to 32,767		1000	0.1%
19.22			Offset load measurement	RW	0 to 32,767		0	0.3125mV
19.23			Filter time constant load measurement	RW	0 to 32,767		100	ms
19.24		0.26[4]	Maximum speed error threshold	RW	0 to 1,000	2000	100	mm/s
19.25	F37	0.24[1]	Brake release delay	RW	0 to 10,000		500	ms
19.26	F02		Number of direction inputs	RW	0 or 1		0	
19.27	F17	0.17[1]	Gear ratio denominator	RW	0 to 32,767		1	
19.28	F31	0.19[1]	Time for Start optimizer	RW	0 to 10,000	700	300	ms
19.29	F15	0.15[1]	Sheave diameter	RW	0 to 32,767		480	mm
19.30	F18	0.16[1]	Gear ratio numerator	RW	0 to 32,767		31	
19.31	F20	0.37[1]	Enable operational rpm configuration	RW	OFF (0) or On (1)		On (1)	
19.32			Motor contactor output	RO	OFF (0) or On (1)		OFF (0)	
19.33			Feedback motor contactor [t078]	RO	OFF (0) or On (1)		On (1)	
19.34		0.15[2]	Enable constant current filter	RW	OFF (0) or On (1)		OFF (0)	
19.35			Thermistor display	RO	OFF (0) or On (1)		OFF (0)	
19.36			Overload output	RO	OFF (0) or On (1)		OFF (0)	
19.37			Load direction (last measured)	RO	OFF (0) or On (1)		On (1)	
19.38			Emergency rescue enable	RW	OFF (0) or On (1)		OFF (0)	
19.39			Load direction invert	RW	OFF (0) or On (1)		OFF (0)	
19.40			Enable motor contactor monitor	RW	OFF (0) or On (1)		OFF (0)	
19.41			Reference select Bit 6	RW	OFF (0) or On (1)		OFF (0)	
19.42		0.17[3]	Enable floor sensor correction	RW	OFF (0) or On (1)		OFF (0)	
19.43			Enable motor phase loss detection [t077]	RW	OFF (0) or On (1)		OFF (0)	
19.44			CW direction	RO	OFF (0) or On (1)		OFF (0)	
19.45			Enable blocked elevator releasing	RW	OFF (0) or On (1)		OFF (0)	
19.46			Fast Start terminal activation	RW	OFF (0) or On (1)		OFF (0)	
19.47			Enable jerk acceleration to Travel	RW	OFF (0) or On (1)		OFF (0)	
19.48			Enable variable gains	RW	OFF (0) or On (1)		OFF (0)	
19.49	F55		Remote Keypad operation Reset	RW	OFF (0) or On (1)		OFF (0)	
		0.51[3]	Enable Fast stop					
19.50			Global warning	RO	OFF (0) or On (1)		OFF (0)	

19.06	Distance for peak curve operation											
19.07	Distance after peak curve operation											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1								
Range	Closed-loop vector, Servo						0 to 32,767 (mm)					
Linked to	Pr 0.27[3] Pr 0.28[3]											
Update rate	4ms read											

The reference speed before and after speed reduction is used as the calculation base for the controlled stopping distance. The Set-point peak curve distance is calculated from the profile parameters and displayed in Pr 0.27[3], Pr 19.06. This value is equivalent to the deceleration distance for the applied speed. The deceleration distance is measured during peak curve operation and displayed in Pr 0.28[3], Pr 19.07.

19.08	Calculated deceleration distance											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1								
Range	Closed-loop vector, Servo						0 to 32,767 (mm)					
Linked to	Pr 0.14[3]											
Update rate	4ms read											

The positioning mode uses the selected speed and profile settings as a reference to calculate and display the calculated deceleration distance in Pr 0.14[3], Pr 19.08 in mm. The deceleration distance is controlled to this value independent of the load. The actual distance moved is displayed in Pr 0.15[3], Pr 19.10 in mm.

19.09	Speed at floor sensor active											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1								
Range	Closed-loop vector, Servo						0 to 32,767 (mm/s)					
Linked to	Pr 0.22[3]											
Update rate	4ms read											

This parameter displays the speed of the elevator when the floor sensor correction becomes active. If the stop distance is too low or the floor sensor signal is given at too high a speed, it is possible that the elevator may not stop smoothly and a hard stop will occur.

Pr 0.17[3], Pr 19.42 Enable floor sensor correction

Pr 0.19[3], Pr 20.14 Floor sensor correction input - drive control terminal

Pr 0.20[3], Pr 18.19 Floor sensor correction target distance

To monitor the floor sensor correction function the following RO parameters can be used:

Pr 0.23[3], Pr 20.05 Time from floor sensor correction active to Stop

Pr 0.22[3], Pr 19.09 Speed at floor sensor correction active

Pr 0.21[3], Pr 18.09 Remaining floor sensor correction distance

19.10	Reference deceleration distance											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1								
Range	Closed-loop vector, Servo						0 to 32,767 (mm)					
Default	Closed-loop vector, Servo						0					
Linked to	Pr 0.14[3]											
Update rate	4ms read											

The actual deceleration distance moved is displayed here in mm. The positioning mode uses the selected speed and profile settings as a reference to calculate and display the calculated deceleration distance in Pr 0.14[3], Pr 19.08 in mm.

19.11	Variable gains transition time											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Closed-loop vector, Servo						0 to 32,767 (ms)					
Default	Closed-loop vector, Servo						1000					
Linked to	Pr 0.22[2]											
Update rate	4ms read											

This parameter allows the time for the variable speed loop and current loop gains along with the current loop filter to be defined. The time set here is active following the enable during the Start only. The transition time can be controlled by a defined time, or by using a defined speed. To select between the two methods the following parameter settings are required.

Pr 0.22[2], Pr 19.11 > 0 = Time dependant transition

Pr 0.22[2], Pr 19.11 = 0 Speed transition

Also refer to Pr 0.21[2], Pr 18.48 and Pr 19.48.

19.11	Variable stator resistance transition time											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop						0 to 32,767 (ms)					
Default	Open-loop						1000					
Linked to	Pr 0.22[2]											
Update rate	4ms read											

This parameter allows the time for the variable stator resistance change to be carried out. The time set here is active following the enable Pr 18.48.

Pr 18.48 Enable variable stator resistance

Pr 5.17 Start stator resistance [optimum value for start]

Pr 21.12 Stop stator resistance [autotune value]


Pr 19.11 Stator resistance transition time

19.12	D gain Start locking											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Closed-loop vector, Servo						0 to 65,535					
Default	Closed-loop vector, Servo						0					
Linked to	Pr 0.20[2]											
Update rate	4ms read											

With both gearless elevators and planetary gears a position controller is particularly suitable for the start. This prevents any movement of the motor during brake opening. The position controller is made up of both a proportional Pr 0.19[2], Pr 19.20 and derivative term Pr 0.20[2], Pr 19.12. This feature will attempt to hold the car in position during opening of the brake and is only active whilst the brake is being opened. Once the motor starts the position controller then becomes inactive.

The D gain Pr 0.20[2] Pr 19.12 counteracts a detectably quick change of position. Settings from 10 up to 100 are recommended. This helps the position control and performs more minor compensation procedures with slight deviations. The set values are limited by the stiffness of the speed loop gains, which are determined essentially by the speed feedback device being used (SinCos encoders being far superior (higher resolution) to standard incremental encoders or resolvers).

Figure 7-6 Start locking




19.13	Stop deceleration																																											
Variants	Unidrive SP, Unidrive ES																																											
Drive modes	Open-loop, Closed-loop vector, Servo																																											
Coding	<table border="1"> <tr> <td>Bit</td> <td>Txt</td> <td>VM</td> <td>RO</td> <td>US</td> <td>RW</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>1</td> <td>1</td> <td></td> </tr> </table>	Bit	Txt	VM	RO	US	RW																				1	1																
Bit	Txt	VM	RO	US	RW																																							
				1	1																																							
Range	Open-loop, Closed-loop vector, Servo 0 to 2000 (mm/s ²)																																											
Default	Open-loop, Closed-loop vector, Servo 1000																																											
Linked to	Pr 0.22[0]																																											
Update rate	4ms read																																											

The Stop deceleration rate is used during the final deceleration from creep speed to stop. This deceleration rate applies to the standard creep to floor operation and also floor sensor correction control. This deceleration rate is not required and not used for the direct to floor positioning.

Elevator profile jerks

The following Start, Run and Stop jerks can be used to improve the ride quality of the elevator. Adjustment of the jerks can result in increased acceleration and deceleration times (increased acceleration or deceleration time when jerk(s) are reduced, and reduced acceleration or deceleration times when jerk(s) are increased).

Figure 7-7 Elevator profile jerks



19.14	Start jerk																																								
Variants	Unidrive SP, Unidrive ES																																								
Drive modes	Open-loop, Closed-loop vector, Servo																																								
Coding	<table border="1"> <tr> <td>Bit</td> <td>Txt</td> <td>VM</td> <td>RO</td> <td>US</td> <td>RW</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>1</td> <td>1</td> <td></td> </tr> </table>	Bit	Txt	VM	RO	US	RW																			1	1														
Bit	Txt	VM	RO	US	RW																																				
				1	1																																				
Range	Open-loop, Closed-loop vector, Servo 0 to 10,000 (mm/s ³)																																								
Default	Open-loop, Closed-loop vector, Servo 500																																								
Linked to	F34, Pr 0.23[0]																																								
Update rate	4ms read																																								

The Start jerk is only active during the start, and following the start optimizer if enabled. The default value is suitable for most applications, but can be adjusted. To achieve a softer jerk, reduce Pr 19.14. In order to have a harder jerk increase the value.

19.15	Run jerk																																								
Variants	Unidrive SP, Unidrive ES																																								
Drive modes	Open-loop, Closed-loop vector, Servo																																								
Coding	<table border="1"> <tr> <td>Bit</td> <td>Txt</td> <td>VM</td> <td>RO</td> <td>US</td> <td>RW</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>1</td> <td>1</td> <td></td> </tr> </table>	Bit	Txt	VM	RO	US	RW																			1	1														
Bit	Txt	VM	RO	US	RW																																				
				1	1																																				
Range	Open-loop, Closed-loop vector, Servo 0 to 10,000 (mm/s ³)																																								
Default	Open-loop, Closed-loop vector, Servo 1000																																								
Linked to	F35, Pr 0.24[0]																																								
Update rate	4ms read																																								

The Run jerk is active during acceleration to travel and travel to deceleration followed by deceleration to creep speed (creep to floor) or deceleration to stop (direct to floor). The default value is suitable for most applications but can be adjusted. To have a softer jerk, reduce Pr 19.15 to have a harder jerk increase the value. Also refer to Pr 19.47, jerk at end of initial acceleration.

19.16	Stop jerk																																								
Variants	Unidrive SP, Unidrive ES																																								
Drive modes	Open-loop, Closed-loop vector, Servo																																								
Coding	<table border="1"> <tr> <td>Bit</td> <td>Txt</td> <td>VM</td> <td>RO</td> <td>US</td> <td>RW</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>1</td> <td>1</td> <td></td> </tr> </table>	Bit	Txt	VM	RO	US	RW																			1	1														
Bit	Txt	VM	RO	US	RW																																				
				1	1																																				
Range	Open-loop, Closed-loop vector, Servo 0 to 10,000 (mm/s ³)																																								
Default	Open-loop, Closed-loop vector, Servo 800																																								
Linked to	F36, Pr 0.25[0]																																								
Update rate	4ms read																																								

The Stop jerk is active for creep to floor operating during deceleration from creep speed to stop. The default value is suitable for most applications, but can be adjusted. To achieve a softer jerk, reduce Pr 19.16. In order to have a harder jerk increase the value.

19.17	Jerk for Start optimizer																																								
Variants	Unidrive SP, Unidrive ES																																								
Drive modes	Open-loop, Closed-loop vector, Servo																																								
Coding	<table border="1"> <tr> <td>Bit</td> <td>Txt</td> <td>VM</td> <td>RO</td> <td>US</td> <td>RW</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>1</td> <td>1</td> <td></td> </tr> </table>	Bit	Txt	VM	RO	US	RW																			1	1														
Bit	Txt	VM	RO	US	RW																																				
				1	1																																				
Range	Open-loop, Closed-loop vector, Servo 0 to 10,000 (mm/s ³)																																								
Default	Open-loop, Closed-loop vector, Servo 400 10																																								
Linked to	Pr 0.20[1]																																								
Update rate	4ms read																																								


To overcome static friction in the elevator arrangement or to overcome starting difficulties a start optimizer function is available. The Start optimizer has the following:

Start optimizer time in Pr 0.19[1], Pr 19.28 (> 0 to enable start optimizer)

Start optimizer speed Pr 0.18[1], Pr 18.18

Start optimizer jerk in Pr 0.20[1], Pr 19.17

Figure 7-8 Start optimizer



If the target speed set in Pr 0.18[1], Pr 18.18 is not reached during the time defined in Pr 0.19[1], Pr 19.28 there will be a continuous transition to the nominal acceleration using the standard start jerk F34, Pr 0.23[0] Pr 19.14.

19.18	Maximum distance error threshold												
Variants	Unidrive SP, Unidrive ES												
Drive modes	Open-loop, Closed-loop vector, Servo												
Coding	Bit	Txt	VM	RO	US	RW							
					1	1							
Range	Open-loop, Closed-loop vector, Servo						0 to 10,000 (mm)						
Default	Open-loop, Closed-loop vector, Servo						100						
Linked to	Pr 0.28[4]												
Update rate	4ms read												

The distance error is the integral of the difference between the ramp speed Pr 19.03 and the actual speed of the motor F49, Pr 0.34[0], Pr 19.02 and is compared with an allowable threshold set in F31, Pr 0.28[4], Pr 19.18.

If the distance error exceeds the user defined threshold, a t071 trip is generated. The distance error during one travel is displayed in Pr 0.27[4], Pr 18.06 independent of the activation of the error detection. The display is reset to 0 at each start.

The distance error detection can be disabled by setting F31, Pr 0.28[4], Pr 19.18 = 0

19.19	Inertia compensation scaling												
Variants	Unidrive SP, Unidrive ES												
Drive modes	Open-loop, Closed-loop vector, Servo												
Coding	Bit	Txt	VM	RO	US	RW							
					1	1							
Range	Open-loop, Closed-loop vector, Servo						0 to 32,767 (0.1%)						
Default	Open-loop, Closed-loop vector, Servo						1000						
Linked to	Pr 0.27[2]												
Update rate	4ms read												

The setting of the inertia compensation scaling should be adjusted so that the speed controller output Pr 3.04 is nearly constant after the brake has opened, and also during both the starting and stopping.

The inertia compensation scaling can be calculated from the mechanical data as follows:

$$\text{Pr } 0.27[2] \text{ Pr } 19.19 = 1000 * (\text{JG} * i) / (\text{MN} * \text{R})$$

- JG** Inertia of the system in kgm² apply to the motor shaft
- MN** Rated motor torque in Nm
- R** Radius of the sheave in m
- i** Gear ratio


19.20	P gain Start locking										
Variants	Unidrive SP, Unidrive ES										
Drive modes	Closed-loop vector, Servo										
Coding	Bit	Txt	VM	RO	US	RW					
					1	1					
Range	Closed-loop vector, Servo						0 to 65,535				
Default	Closed-loop vector, Servo						10				
Linked to	F47, Pr 0.19[2]										
Update rate	4ms read										

With both gearless elevators and planetary gears a position controller is particularly suitable for the start. This prevents any movement of the motor during brake opening. The position controller is made up of a proportional Pr 0.19[2], Pr 19.20 and derivative term Pr 0.20[2], Pr 19.12.

This feature will attempt to hold the car in position during opening of the brake and is only active whilst the brake is being opened. Once the motor starts the position controller then becomes inactive.

When setting the P gain, Pr 0.19[2], Pr 19.20 > 0 the car is always pulled back into position during opening the brake. The maximum detectable position error is determined by the level of Pr 0.19[2], Pr 19.20. Settings from 3 up to 30 are recommended.

Figure 7-9 Start locking



19.21	Load measurement scaling										
Variants	Unidrive SP, Unidrive ES										
Drive modes	Open-loop, Closed-loop vector, Servo										
Coding	Bit	Txt	VM	RO	US	RW					
					1	1					
Range	Open-loop, Closed-loop vector, Servo						± 32,767 (0.1%)				
Default	Open-loop, Closed-loop vector, Servo						1000				
Linked to											
Update rate	4ms read										

This is the scaling applied to the load input on analog input 2 (load cell from elevator) and follows the load input offset Pr 19.22 and load input time constant Pr 19.23. The load input is applied as a torque feed forward signal to Pr 4.09 if Pr 18.46 = On.

19.22	Offset load measurement										
Variants	Unidrive SP, Unidrive ES										
Drive modes	Open-loop, Closed-loop vector, Servo										
Coding	Bit	Txt	VM	RO	US	RW					
					1	1					
Range	Open-loop, Closed-loop vector, Servo						± 32,767 (0.3125mV)				
Default	Open-loop, Closed-loop vector, Servo						0				
Linked to											
Update rate	4ms read										

This is the offset which is applied to the load input (load cell from elevator) on analog input 2 of the drive.

19.23	Filter time constant for load measurement											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector, Servo						± 32,767 (ms)					
Default	Open-loop, Closed-loop vector, Servo						100					
Linked to												
Update rate	4ms read											

This is the filter time constant applied to the load input (load cell from elevator) on analog input 2 of the drive.

19.24	Maximum speed error threshold											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector, Servo						0 to 1,000 (mm/s)					
Default	Open-loop, Closed-loop vector, Servo						2000 100					
Linked to	Pr 0.26[4]											
Update rate	4ms read											

The maximum speed error is calculated from the difference between the ramp speed Pr 19.03 and the actual speed of the motor F49, Pr 0.34[0], Pr 19.02 in mm/s.

The maximum speed error is compared with the user setting of the allowable maximum speed error in Pr 0.26[4], Pr 19.24. If the threshold is exceeded for more than 100ms the elevator software generates a t070 trip.

The speed error detection can be disabled by setting Pr 0.26[4], Pr 19.24 = 0. The maximum speed error during the travel is displayed in Pr 0.25[4], Pr 18.07 independent of the activation of the speed error detection. The display is reset to 0 at each start.

19.25	Brake release delay											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector, Servo						0 to 10,000 (ms)					
Default	Open-loop, Closed-loop vector, Servo						500					
Linked to	F37, Pr 0.24[1]											
Update rate	4ms read											

Brake control using drive

In the default condition the brake controller is set-up to provide a brake release output signal on control terminal 25 of the drive Pr 8.22 = 18.31.

The brake release delay time is adjusted using Pr F37, Pr 0.24[1], Pr 19.25 in ms. The brake output becomes active once the motor magnetized state is reached Pr 0.18[4], Pr 18.43 motor magnetized. The threshold for the motor magnetized is available in Pr 0.29[2], Pr 18.23.

If the drive trips the brake control will become inactive and the brake will be forced to close by the elevator controller.

Brake apply delay F38, Pr 0.25[0], Pr 18.24

Brake release delay F37, Pr 0.24[1], Pr 19.25

Brake output status Pr 0.19[4] Pr 18.31

19.26	Number of direction inputs											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Open-loop, Closed-loop vector, Servo						0 to 1					
Default	Open-loop, Closed-loop vector, Servo						0					
Linked to	F02, Pr 19.26											
Update rate	Background read											

This parameter allows the user to define the number of direction inputs on the drive. At default the drive has a single direction input on control terminal T.28, when selecting dual direction inputs the drive is configured for direction inputs on both control terminals T.27 and T.28.

The direction inputs can be seen in Pr 18.44 for a single direction input and both Pr 18.44 and Pr 19.44 for dual direction inputs.

19.27	Gear ratio denominator											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector, Servo						0 to 32,767					
Default	Open-loop, Closed-loop vector, Servo						1					
Linked to	F18, Pr 0.17[1]											
Update rate	4ms read											

Where the elevator has a gearbox this is the gear ratio denominator and is used by the operational rpm configuration F20, Pr 0.37[1], Pr 19.31, for the calculation of the nominal elevator rpm F21, Pr 0.13[1], Pr 18.03.

19.28	Time for Start optimizer											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector, Servo						0 to 10,000 (ms)					
Default	Open-loop,						700					
	Closed-loop vector, Servo						300					
	Recommended range						300 to 800					
Linked to	F31, Pr 0.19[1]											
Update rate	4ms read											

To overcome static friction in the elevator arrangement or to overcome starting difficulties a Start optimizer function is available. The Start optimizer has:


Start optimizer time in Pr 0.19[1], Pr 19.28 (> 0 to enable start optimizer)

Start optimizer speed Pr 0.18[1], Pr 18.18

Start optimizer jerk in Pr 0.20[1], Pr 19.17

If the target speed set in Pr 0.18[1], Pr 18.18 is not reached during the time defined in Pr 0.19[1], Pr 19.28 there will be a continuous transition to the nominal acceleration using the standard start jerk F34, Pr 0.23[0] Pr 19.14.

Figure 7-10 Start optimizer



19.29	Sheave diameter											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector, Servo						0 to 32767 (mm)					
Default	Open-loop, Closed-loop vector, Servo						480					
Linked to	F15, Pr 0.15[1]											
Update rate	4ms read											

This is the diameter of the sheave in mm and is used by the operational rpm configuration **F20, Pr 0.37[1], Pr 19.31**, for the calculation of the nominal elevator rpm **F21, Pr 0.13[1], Pr 18.03**.

19.30	Gear ratio numerator											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector, Servo						0 to 32,767					
Default	Open-loop, Closed-loop vector, Servo						31					
Linked to	F17, Pr 0.16[1]											
Update rate	4ms read											

Where the elevator has a gearbox this is the gear ratio numerator and is used by the operational rpm configuration **F20, Pr 0.37[1], Pr 19.31**, for the calculation of the nominal elevator rpm **F21, Pr 0.13[1], Pr 18.03**.

19.31	Enable operational rpm configuration											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Open-loop, Closed-loop vector, Servo						OFF (0) or On (1)					
Default	Open-loop, Closed-loop vector, Servo						On (1)					
Linked to	F20, Pr 0.37[1]											
Update rate	4ms read											

This is the operational rpm configuration, which uses the nominal elevator speed mm/s, gear ratio, sheave diameter and roping to calculate the nominal elevator speed, rpm in parameter **F21, Pr 0.13[0], Pr 18.29**.

19.32	Motor contactor output											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1			1								
Range	Open-loop, Closed-loop vector, Servo						OFF (0) or On (1)					
Linked to												
Update rate	4ms read											

This parameter indicates the state of the motor contactor control output from the drive.

- **19.32** = OFF: Motor contactor open
- **19.32** = On: Motor contactor closed

By default the motor contactor control output is configured for control terminal T 22.

The sequence in which this output becomes active is:

1. Speed selection
2. Drive enable
3. Motor contactor output active

19.33	Feedback from motor contactor											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1			1								
Range	Open-loop, Closed-loop vector, Servo						OFF (0) or On (1)					
Linked to												
Update rate	4ms read											

This parameter indicates the state of the motor contactor, and is used as feedback to indicate that the contactor has opened / closed following a control sequence. If the monitoring is enabled with Pr **19.40** and the motor contactor feedback is not present as expected within 2s, a trip t078 will be generated.

19.34	Enable constant current filter											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Closed-loop vector, Servo						OFF (0) or On (1)					
Default	Closed-loop vector, Servo						OFF (0)					
Linked to	Pr 0.15 [2]											
Update rate	4ms read											

This parameter allows either a constant or variable current loop filter to be used along with the for variable speed loop gains. If Pr **19.34** = On, a constant current filter is used (Pr **4.12**) for the complete travel. During this operation, there is no current filter active for the start locking region. To activate a current filter, set Pr **19.34** = OFF and a current filter value in Pr **4.23**.

Also refer to Pr **0.21**[2], Pr **18.48** and Pr **19.48**.

19.35	Thermistor display											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1			1								
Range	Open-loop, Closed-loop vector, Servo						OFF (0) or On (1)					
Linked to												
Update rate	4ms read											

This parameter displays the level of the motor temperature from the motor thermistor connected to analog input 3, if programmed with function Pr 7.15 = *th.disp*.

When Pr 19.35 = On, this indicates that the motor thermistor is > 33% (this equating to 3.3kohms). This can be used to provide the elevator controller with a motor thermal status during operation without stopping the elevator via a digital output.

If an over temperature condition is identified by the software, the elevator completes the travel and once the enable is removed a th trip will be generated.

19.36	Overload output											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1			1								
Range	Closed-loop vector, Servo						OFF (0) or On (1)					
Linked to												
Update rate	4ms read											

This parameter is active when there is an overload condition. This is calculated in the Elevator Solution Software during the start. The actual level of load present is displayed in Pr 20.19 load measurement value.

The overload Pr 19.36 is generated by comparing the measured load value of Pr 20.19 with the overload threshold that is set in Pr 20.18 as a percentage of nominal torque.

19.37	Load direction – last measured											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1			1								
Range	Closed-loop vector, Servo						OFF (0) or On (1)					
Linked to												
Update rate	4ms read											

This parameter displays the direction of the load during the last load measurement at start. This load measurement is carried out to assist in the emergency evacuation control, movement in the direction of least load.

Pr 19.37 = OFF Regenerative load

Pr 19.37 = On Motoring load

Pr 19.39 = Invert

19.38	Emergency rescue enable											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Open-loop, Closed-loop vector, Servo						OFF (0) or On (1)					
Default	Open-loop, Closed-loop vector, Servo						OFF (0)					
Linked to												
Update rate	4ms read											

This parameter is used to enable the emergency rescue and is implemented using a digital input from the elevator controller to the drive via a digital input and routed to Pr **19.38**.

When Pr **19.38** = On the following is also carried out to prevent a UPS system overload in an emergency rescue situation

- Pr **0.20[2]**, Pr **19.12** and **F47**, Pr **0.19[2]**, Pr **19.20** = 0 Disable position controller
- Pr **0.28[4]**, Pr **19.18** and Pr **0.26[4]**, Pr **19.24** = 0 Disable following error detection
- F31**, Pr **0.19[1]**, Pr **19.28** = 0 Disable Start optimizer
- Pr **20.08** = 0 Disable load measurement
- Pr **4.07** = Pr **21.28**, Pr **21.29** Current limit, limit output power

19.39	Load direction invert											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Open-loop, Closed-loop vector, Servo						OFF (0) or On (1)					
Default	Open-loop, Closed-loop vector, Servo						OFF (0)					
Linked to												
Update rate	4ms read											

This parameter allows the load direction last measured in Pr **19.37** to be inverted.

19.40	Enable motor contactor monitor											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Open-loop, Closed-loop vector, Servo						OFF (0) or On (1)					
Default	Open-loop, Closed-loop vector, Servo						OFF (0)					
Linked to												
Update rate	4ms read											

If this parameter is set to ON, the software expects output motor contactor feedback in Pr **19.33**. If the monitoring is enabled and the output motor contactor feedback is not present in Pr **19.33** a t078 trip will be generated.

The output motor contactor feedback is routed to Pr **19.33** using a drives digital input and auxiliary contacts on the motor contactors.

19.41	Reference select Bit 6											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Open-loop, Closed-loop vector, Servo						OFF (0) or On (1)					
Default	Open-loop, Closed-loop vector, Servo						OFF (0)					
Linked to												
Update rate	4ms read											

This parameter is used to select a 7th speed with operating with priority speed selection. Priority speed selection (1 of n), selected with Pr **0.21[1]**, Pr **18.42** = On.

19.42	Enable floor sensor correction											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Closed-loop vector, Servo						OFF (0) or On (1)					
Default	Closed-loop vector, Servo						OFF (0)					
Linked to	Pr 0.17[3]											
Update rate	4ms read											

Independent of the selected profile additional floor sensor correction can be utilized. Improved accurate distance correction is possible if a floor sensor can be detected in the range of 50 to 500mm before the flush or level with floor target position.
 Floor sensor correction should be used with direct-to-floor positioning on elevators with speeds in excess of 1m/s. This ensures maximum accuracy. To enable floor sensor correction, the following parameters should be set up:

- Pr 0.17[3], Pr 19.42 Enable floor sensor correction
- Pr 0.19[3], Pr 20.14 Floor sensor correction input - drive control terminal
- Pr 0.20[3], Pr 18.19 Floor sensor correction target distance

To monitor the floor sensor correction the following RO parameters can be used:

- Pr 0.23[3], Pr 20.05 Time from floor sensor correction active to Stop
- Pr 0.22[3], Pr 19.09 Speed at floor sensor correction active
- Pr 0.21[3], Pr 18.09 Remaining floor sensor correction distance

19.43	Enable motor phase loss detection											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Open-loop, Closed-loop vector, Servo						OFF (0) or On (1)					
Default	Open-loop, Closed-loop vector, Servo						OFF (0)					
Linked to												
Update rate	4ms read											

The Elevator Solution Software has motor phase loss detection this can be enabled for open loop, closed loop and servo modes. In the case where there is a motor phase loss for greater than 2s a t077 trip will be generated.

19.44	Direction input 2											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1			1								
Range	Open loop, Closed-loop vector, Servo						OFF (0) or On (1)					
Linked to												
Update rate	4ms read											

This parameter displays the direction demanded when operating with dual direction inputs Pr 19.26 = 1.

If Pr 19.26 = 1 dual direction inputs, then:

- Pr 18.44 = OFF (0) no counter clockwise rotation demanded
- Pr 18.44 = On (1) counter clockwise rotation demanded.
- Pr 19.44 = OFF (0) no clockwise rotation demand
- Pr 19.44 = On (1) clockwise rotation demanded.

The direction input invert F23, Pr 0.22[1], Pr 18.45 inverts the direction but does not affect this parameter.

If deselecting the dual direction inputs (Pr 19.26 = 0) and the previous function is required for the digital input, Pr 8.24 should be set back to 18.38.

19.45	Unlocking elevator car next travel											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Open-loop, Closed-loop vector, Servo						OFF (0) or On (1)					
Default	Open-loop, Closed-loop vector, Servo						OFF (0)					
Linked to												
Update rate	4ms read											

The over speed mechanical brackets on the elevator car will operate so the car is stopped in a locked in position when an over speed condition occurs. The drive will attempt to release the car at next start when Pr **19.45** = On (1) and a blocked condition is identified. Blocked condition is identified using Pr **10.09** current limit active, and Pr **10.03** zero speed active.

19.46	Fast start terminal activation											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Closed-loop vector, Servo						OFF (0) or On (1)					
Default	Closed-loop vector, Servo						OFF (0)					
Linked to												
Update rate	4ms read											

This is the fast start terminal activation, under this condition the motor will be magnetized and the brake opened whilst the doors are being closed. Pr **19.46** should be controlled in synchronization with the drive enable using an additional digital input on the drive from the elevator controller.

19.47	Enable jerk acceleration to Travel											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Open-loop, Closed-loop vector, Servo						OFF (0) or On (1)					
Default	Open-loop, Closed-loop vector, Servo						OFF (0)					
Linked to												
Update rate	4ms read											

When Pr **19.47** = 1 this enables a separate jerk Pr **20.36** for the end of the initial acceleration, replacing the standard run jerk Pr **19.15**. For deceleration the standard run jerk Pr **19.15** is still active.

If Pr **19.47** = 0 Pr **20.36** is disabled and the standard run jerk in Pr **19.15** is active.

19.48	Enable variable gains											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Closed-loop vector, Servo						OFF (0) or On (1)					
Default	Closed-loop vector, Servo						OFF (0)					
Linked to												
Update rate	4ms read											

Constant speed loop gains

Pr 0.21[2], Pr 18.48 = OFF

Separate speed loop gains

Start, Travel

Pr 0.21[2], Pr 18.48 = On, Pr 19.48 = OFF

Separate speed loop gains, current loop gains, current demand filter

Start, Travel, Stop

Pr 0.21[2], Pr 18.48 = On, Pr 19.48 = On

Pr 19.48 allows for variable gains to be set-up for deceleration to stop should ride comfort issues exist.

19.49	Enable fast stop											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector, Servo						OFF (0) or On (1)					
Default	Open-loop, Closed-loop vector, Servo						OFF (0)					
Linked to	Pr 0.51[3]											
Update rate	4ms read											

A fast stop function has been introduced with software version 01.10 onwards of the Elevator Solution Software, which is enabled by setting Pr 19.49 = On.

The Fast Stop feature is available mainly for commissioning and inspection of the elevator, providing the following features:

1. Offers user defined fast stop profile
2. Faster stopping, rather than following the standard deceleration and jerks that may be too long during commissioning and inspection.
3. Can overcome hard stops and be less aggressive during short movements during commissioning and installation.

When the fast stop is enabled, and a speed with the value of 0 mm/s is selected, the deceleration rate in Pr 21.05 is selected for the fast stop deceleration only.

For the fast stop the jerk is also modified, default 200ms. This is calculated from the fast deceleration rate Pr 21.05, $\text{jerk} = \text{Pr } 21.05 / 0.2$

19.50	Global warning											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
	1				1	1						
Range	Open-loop, Closed-loop vector, Servo						OFF (0) or On (1)					
Default	Open-loop, Closed-loop vector, Servo						OFF (0)					
Linked to												
Update rate	4ms read											

The global warning indicates a failure detected during travel, but does not generate a trip.

7.10 Menu 20 parameters

Parameter			Description	Type	Range	Default			Units
						OL	VT	SV	
20.01	F53	0.28[1]	Software version	RO	xxx				
20.02	F54	0.29[1]	Software identity number	RO	± 10614	± 10614			
20.03			Not used						
20.04		5.03	Maximum power for travel	RO	0 to 10,000				kW
20.05		0.23[3]	Time from floor sensor active to Stop	RO	0 to 10,000	0			ms
20.06		0.15[4]	Max motor voltage last travel	RO	0 to motor rated voltage				V
20.07		0.14[4]	Magnetization current level	RO	0 to 10,000	0		100	0.1A
20.08			Time for load measurement	RW	0 to 10,000		0		ms
20.09			Maximum overload	RO	0 to current limit	0			In %
20.10	F16	0.14[1]	Roping	RW	0 to 4	1			
20.11			Program status	RO	0 to 10,000	0			
20.12			Creep speed parameter number	RW	0 to 30,000	0			
20.13			Direct to floor sensor source	RW	0 to 4		0		
20.14		0.19[3]	Floor sensor correction source	RW	0 to 4		0		
20.15			UPS maximum power control setpoint	RW	0 to 30,000				kW
20.16		0.12[0]	Menu zero selector	RW	0 to 4	0			
20.17			Kp - gain following error regulation	RW	0 to 30,000				
20.18			Overload threshold	RW	0 to 30,000	120			In %
20.19			Load measurement value	RO	0 to 10,000				In %
20.20		0.26[1]	Motor contactor delay time	RO	0 to 10,000				ms
20.21		0.13[3]	Measured creep distance	RO	0 to 10,000	0			mm
20.22			V8 Additional speed 2	RW	0 to 10,000	50			mm/s
20.23			V9 Additional speed 3	RW	0 to 10,000	400			mm/s
20.24			V10 Additional speed 4	RW	0 to 10,000	800			mm/s
20.25		0.16[2]	Current loop Kp - Gain 1 Start	RW	0 to 30,000		75		
20.26		0.17[2]	Current loop Ki - Gain 1 Start	RW	0 to 30,000		1000		
20.27		0.31[2]	Speed loop Kp - Gain 3 Positioning	RW	0 to 65,535		500		1/rad s-1
20.28		0.32[2]	Speed loop Ki - Gain 3 Positioning	RW	0 to 65,535		500		1/rad s-1
20.29	F52		Remote keypad (English / Deutsch) DCP only	RW	English, Deutsch	English			
			Variable gains transition speed threshold		0 to 30,000		0		mm/s
20.30			Variable gains transition time deceleration	RW	0 to 30,000		0		ms
20.31			Not used						
20.32			Not used						
20.33			Not used						
20.34			Not used						
20.35		0.35[4]	Diagnostic travel interrupt code (up to V1.20)	RO	0 to 30,000	0			
20.35			Not used						
20.36			Run Jerk - Acceleration	RW	0 to 10,000	1000			mm/s ³
20.37			Not used						
20.38			Not used						
20.39		0.35[4]	Diagnostic travel interrupt code (V1.21 onwards)	RO	0 to 30,000	0			
20.40			Motor contactor release delay time	RW	0 to 90,000	100	0		ms

20.01	Software version											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1								
Range	Open-loop, Closed-loop vector, Servo						xxxx					
Linked to	F53, Pr 0.28[1]											
Update rate	4ms read											

This parameter indicates the software version of the Elevator Solution Software present in the SM-Applications / SM-Applications Lite.

20.02	Software identity number											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1								
Range	Open-loop, Closed-loop vector, Servo						±10614					
Linked to	F54, Pr 0.29[1]											
Update rate	4ms read											

This parameter indicates the variant of the Elevator Solution Software present in the SM-Applications / SM-applications Lite. Alternates between +10614 and -10614 to indicate the software is running.

20.04	Maximum power last travel											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1								
Range	Open-loop, Closed-loop vector, Servo						0 to Max power (kW)					
Linked to	Pr 5.03											
Update rate	4ms read											

This parameter displays the maximum power during the last travel and is measured during the start with a 1000ms filter and Pr 5.03 "output power" in the drive.

20.05	Time from floor sensor correction active to Stop											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1								
Range	Closed-loop vector, Servo						0 to 10,000 (ms)					
Linked to	Pr 0.23[3]											
Update rate	4ms read											

Independent of the selected profile additional floor sensor correction can be utilized. Improved accurate distance correction is possible if a floor sensor can be detected in the range of 50 to 500mm before the flush or level with floor target position.

Floor sensor correction should be used with direct-to-floor positioning control on elevators with speeds in excess of 1m/s. This ensures maximum accuracy. Floor sensor correction is set up as follows:

- Pr 0.17[3], Pr 19.42 Enable floor sensor correction
- Pr 0.19[3], Pr 20.14 Floor sensor correction input / drive control terminal
- Pr 0.20[3], Pr 18.19 Floor sensor correction target distance

To monitor the floor sensor correction function the following RO parameters can be used:

- Pr 0.23[3], Pr 20.05 Time from floor sensor correction active to Stop
- Pr 0.22[3], Pr 19.09 Speed at floor sensor correction active
- Pr 0.21[3], Pr 18.09 Remaining floor sensor correction distance

20.06	Max motor voltage last travel											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1								
Range	Open-loop, Closed-loop vector, Servo						0 to motor rated voltage					
Linked to	Pr 0.15[4]											
Update rate	4ms read											

This parameter displays the maximum motor voltage during the last travel.

20.07	Magnetization current level											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1								
Range	Open-loop, Closed-loop vector, Servo						0 to 100(%) Fixed 100					
Linked to	Pr 0.14[4]											
Update rate	4ms read											

The magnetization current level Pr 20.07 indicates if the drive is going into field weakening, which is not intended. This is derived from Pr 4.17 and normally the value should be 100%...95%. If however the value is below 90% this could be caused by:-

- Incorrect motor map setting
- Incorrect speed selected, too high

20.08	Time for load measurement											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Closed-loop vector, Servo						10,000 (ms)					
Default	Closed-loop vector, Servo						0					
Linked to												
Update rate	4ms read											

This parameter defines the time required for the load measurement. To disable the load measurement set Pr 20.08 = 0. This measurement duration is set at 200ms as default with this being sufficient for determining the load direction. Measuring times of 500 ms are however recommended for an accurate measurement. The measurement duration if set to be longer will result in more accurate results. This does result in a longer time required for the measurement and therefore should be considered for when planning / setting up for the application.

20.09	Maximum overload											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1								
Range	Open-loop, Closed-loop vector, Servo						0 to current limit (%)					
Linked to												
Update rate	4ms read											

This parameter displays the maximum allowed overload as a percentage. Also refer to Pr 20.18.

20.10	Roping											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector, Servo						0 to 4					
Default	Open-loop, Closed-loop vector, Servo						1					
Linked to	F16, Pr 0.14[1]											
Update rate	4ms read											

This is the roping for the elevator and is used by the operational rpm configuration **F20**, Pr **0.37[1]**, Pr **19.31**, for the calculation of the nominal elevator rpm **F21**, Pr **0.13[1]**, Pr **18.03**.

20.11	Program status											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1								
Range	Open-loop, Closed-loop vector, Servo						0 to 10,000					
Linked to												
Update rate	4ms read											

This parameter indicates the status of the elevator solution software and can be used to identify the control state.

20.12	Creep speed parameter number											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector, Servo						0000 to xxxx					
Default	Open-loop, Closed-loop vector, Servo						0000					
Linked to												
Update rate	4ms read											

This parameter can be used to define the creep speed, at default the creep speed is set to Pr **18.11** if another parameter is required for the creep speed this should be entered here.

For example if Pr **18.12** is required for the creep speed this can be entered as follows: Pr **20.12** = 1812.

20.13	Direct-to-floor sensor source											
Variants	Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Closed-loop vector, Servo						0 to 4					
Default	Closed-loop vector, Servo						0					
Linked to	Pr 0.16[3]											
Update rate	4ms read											

For some applications, especially high-speed elevators and long travel distance elevators, direct-to-floor positioning control is often used to overcome inherent delays normally associated with creep-to-floor elevators.

With direct-to-floor positioning the speed is applied according to the selected floor distance. As a function of the distance to the desired final position, the elevator controller will disable the speed signal, and direct deceleration to the target position will take place. Direct-to-floor positioning should only be used on elevating up to 1m/s due to the accuracy, above 1m/s floor sensor correction should also be enabled. The following settings can be selected:

- Pr 0.16[3], Pr 20.13 = 0 Direct-to-floor disabled, creep-to-floor active
- Pr 0.16[3], Pr 20.13 = 1 Direct-to-floor positioning with stop signal via analog input 1 (T.5)
- Pr 0.16[3], Pr 20.13 = 2 Direct-to-floor positioning with stop signal via analog input 2 (T.7)
- Pr 0.16[3], Pr 20.13 = 3 Direct-to-floor positioning with stop signal via analog input 3 (T. 8)
- Pr 0.16[3], Pr 20.13 = 4 Direct-to-floor positioning with disable the speed signals

20.14	Floor sensor correction source											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Closed-loop vector, Servo						0 to 4					
Default	Closed-loop vector, Servo						0					
Linked to	Pr 0.19[3]											
Update rate	4ms read											

Independent of the selected profile additional floor sensor correction can be utilized. Improved accurate distance correction is possible if a floor sensor can be detected in the range of 50 to 500mm before the flush or level with floor target position.

Floor sensor correction should be used with direct-to-floor positioning control on elevators with speeds in excess of 1m/s. This ensures maximum accuracy. Floor sensor correction is set up as follows:

- Pr 0.17[3], Pr 19.42 Enable floor sensor correction
- Pr 0.20[3], Pr 18.19 Floor sensor correction target distance

To monitor the function following RO parameters could be used:

- Pr 0.23[3], Pr 20.05 Time from floor sensor correction active to Stop
- Pr 0.22[3], Pr 19.09 Speed at floor sensor correction active
- Pr 0.21[3], Pr 18.09 Remaining floor sensor correction distance

The floor sensor correction is activated based upon the settings of Pr 0.19[3], Pr 20.14 which is used to set-up the source for the external floor sensor correction signal:

- Pr 0.19[3], Pr 20.14 = 0 Floor sensor correction disabled
- Pr 0.19[3], Pr 20.14 = 1 Floor sensor correction = analog input 1 (T.5)
- Pr 0.19[3], Pr 20.14 = 2 Floor sensor correction = analog input 2 (T.7)
- Pr 0.19[3], Pr 20.14 = 3 Floor sensor correction = analog input 3 (T.8)
- Pr 0.19[3], Pr 20.14 = 4 Distance controlled stopping

20.15	UPS maximum power control set point											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector, Servo						0 to Max power (kW)					
Default	Open-loop, Closed-loop vector, Servo						0					
Linked to												
Update rate	4ms read											

This parameter is used to limit the maximum power available to the motor from the UPS used for emergency backup operation. This should be set-up based upon the UPS power rating.

20.16	Menu zero selector											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
						1						
Range	Open-loop, Closed-loop vector, Servo						0 to 4					
Default	Open-loop, Closed-loop vector, Servo						0					
Linked to	Pr 0.12[0]											
Update rate	4ms read											

Pr 0.00[0] to Pr 0.12[0] and Pr 0.38[0] to Pr 0.50[0] are fixed parameters.

Pr 0.13[0] to Pr 0.37[0] have selectable parameter sets, and are selected by the user as follows.

Menu 0, Pr 0.12[0], is changed to select a different parameter set or group of elevator parameters. After power-up or saving of parameters, the standard configuration for Pr 0.13[0] to Pr 0.37[0] is loaded automatically. By setting Pr 0.12[0] to the predefined code 1, 2, 3 or 4, other configurations of Pr 0.13[0] to Pr 0.37[0] are selected as shown following.

In this documentation the parameter set or group selected with Pr 0.12[0] is shown in square brackets after the menu zero parameter to indicate which configuration is selected.

For example:

Pr 0.26[1] of the elevator parameters

Pr 0.12 = 1, Pr 0.26 [1]

To select Pr 0.18[2]

Set Pr 0.12 = 2 and select Pr 0.18

Pr 0.12[0] = 0 Basic parameters from Pr 0.13[0] to Pr 0.37[0]

Pr 0.12[0] = 1 Installation parameters from Pr 0.13[1] to Pr 0.37[1]

Pr 0.12[0] = 2 Control parameters from Pr 0.13[2] to Pr 0.37[2]

Pr 0.12[0] = 3 Distance parameters from Pr 0.13[3] to Pr 0.37[3]

Pr 0.12[0] = 4 Diagnostics parameters from Pr 0.13[4] to Pr 0.37[4]

20.17	P gain deceleration following error regulation											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector, Servo						0 to 30,000					
Default	Open-loop, Closed-loop vector, Servo						0					
Linked to												
Update rate	4ms read											

The Kp following error regulation gain is used for direct to floor operation. This is combined with the floor sensor correction to give improved position accuracy. This parameter is the gain, which amplifies the position error between the position calculated by the ramp and the actual position, and corrects the speed set point, so the error is reduced.

20.18	Overload threshold											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop, Closed-loop vector, Servo						0 to current limit (%)					
Default	Open-loop, Closed-loop vector, Servo						120					
Linked to												
Update rate	4ms read											

This parameter is used to define the maximum allowable overload, also refer to Pr **20.09**.

20.19	Load measurement value											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1								
Range	Open-loop, Closed-loop vector, Servo						0 to current limit (%)					
Linked to												
Update rate	4ms read											

This parameter displays the percentage load present following brake release and the time specified for the load measurement Pr **20.08**.

To disable the load measurement set the time for load measurement Pr **20.08** = 0.

20.20	Motor contactor delay time											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1								
Range	Open-loop, Closed-loop vector, Servo						0 to 10,000 (ms)					
Linked to												
Update rate	4ms read											

This parameter displays the time for the motor contactor output signal to become active. This is the time between the command to open the motor contactor and the opening of T.31 assumed as the motor contactor feedback. If this time is negative, the motor contactor is opened with current flowing, which should be prevented, because this could damage the contactors and cause OIAC trips.

20.21	Measured creep distance											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1								
Range	Open-loop, Closed-loop vector, Servo						0 to 10,000 (mm)					
Linked to												
Update rate	4ms read											

The measured creep distance is started once the profile generator goes from the contract speed through deceleration and reaches creep speed. During operation in creep speed the speed is integrated over time, which gives the distance. The integration is stopped when leaving creep speed to stop.

20.22	V8 additional speed 2										
20.23	V9 additional speed 3										
20.24	V10 additional speed 4										
Variants	Unidrive SP, Unidrive ES										
Drive modes	Open-loop, Closed-loop vector, Servo										
Coding	Bit	Txt	VM	RO	US	RW					
					1	1					
Range	Open-loop, Closed-loop vector, Servo					0 to 10,000 (mm/s)					
Default	Open-loop, Closed-loop vector, Servo					V8 = 50, V9 = 400, V10 = 800					
Linked to											
Update rate	4ms read										

20.25	Current loop Kp -Gain 1 Start											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Closed-loop vector, Servo					0 to 30000						
Default	Drive voltage rating:					200V	400V	575V	690V			
	Closed-loop vector, Servo					75	150	180	215			
Linked to	Pr 0.16[2]											
Update rate	Background read											

20.26	Current loop Ki -Gain 1 Start											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Closed-loop vector, Servo					0 to 30000						
Default	Drive voltage rating					200V	400V	575V	690V			
	Closed-loop vector, Servo					1000	2000	2400	3000			
Linked to	Pr 0.17[2]											
Update rate	Background read											

The following is a guide to setting the current loop Kp proportional and Ki integral gains for different applications. The current controller loop consists of both a Kp proportional and Ki integral gain.

NOTE

The current controller Kp proportional and Ki integral gains derived from the auto-tune system give the best response at all switching frequencies

Open-loop control

The current controller provides current limit operation by modifying the drive output frequency. Although the default settings have been chosen to give suitable gains for less demanding applications it may be necessary for the user to adjust the performance of the controller.

The current limits will normally operate with an integral term only, particularly below the point where field weakening begins. The proportional term is inherent in the loop. The integral term must be increased enough to counter the effect of the ramp which is still active even in current limit.

For example, if the drive is operating at constant frequency and is overloaded the current limit system will try to reduce the output frequency to reduce the load. At the same time the ramp will try to increase the frequency back up to the demand level.

- If the Ki integral gain is increased too far the first signs of instability will occur when operating around base speed / the point where field weakening begins.
- Increasing the Kp proportional gain can reduce oscillations around base speed / the point where field weakening begins

Closed-loop vector and Servo

The proportional gain is the most critical value in controlling the performance of the current controllers. The value for the current controller Kp proportional gain can be set up through either a stationary or rotating auto tune. The current controller Kp proportional and Ki integral gains derived from the auto-tune system give the best response at all switching frequencies with minimal overshoot.

If required the gains can be adjusted to improve performance as follows:

- The Ki integral gain can be used to improve the performance of the current controllers by reducing the effects of inverter non-linearity. If the Ki integral gain is increased by a factor of 4 it is possible to get up to 10% overshoot in response to a step change of current reference. For high performance applications, it is recommended that the Ki integral gain be increased by a factor of 4 from the auto-tuned value.

As the inverter non-linearity increases with higher switching frequencies it may be necessary to increase the Ki integral gain by a factor of 8 for operation with 16kHz switching frequency.
- It is possible to increase the Kp proportional gain to reduce the response time of the current controller. If the Kp proportional gain is increased by a factor of 1.5 then the response to a step change of reference will give an increased overshoot of 12.5%.

NOTE

It is recommended that Ki integral gain be increased in preference to the Kp proportional gain.

Current loop sample rate

The following table gives the sampling rate for the current controller for the different switching frequencies.

Table 7-7 Current loop sampling rates

	3, 6, 12kHz	4, 8, 16kHz	Open-loop	Closed-loop vector	Servo
Level 1	3 = 167µs 6 = 83µs 12 = 83µs	125µs	Peak limit	Current controller	Current controller
Level 2	250µs	250µs	Current limit Ramps	Speed controller Ramps	Speed controller Ramps
Level 3	1ms	1ms	Voltage controller	Voltage controller	Voltage controller

NOTE

The current loop kp proportional gain from the auto tuned value may need to be reduced for some motors due to acoustic noise. If acoustic noise is present, the current loop kp proportional gain can be reduced by up to half, provided the reduced performance of the current loop remains acceptable. Where the gain cannot be reduced, consider using a current loop filter.

NOTE

For open loop mode there are no variable current loop gains, therefore F41, Pr 4.13[20] and F42, Pr 4.14[40] are active during the complete travel.

20.27	Speed loop Kp - Gain 3 Positioning												
Variants	Unidrive SP, Unidrive ES												
Drive modes	Closed-loop vector, Servo												
Coding	Bit	Txt	VM	RO	US	RW							
					1	1							
Range	Closed-loop vector, Servo						0.00 to 20,000 ([0.0001 * 1/rad s ⁻¹])						
Default	Closed-loop vector, Servo						500						
Linked to	Pr 0.31[2]												
Update rate	Background read												

20.28	Speed loop Ki - Gain 3 Positioning											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Closed-loop vector, Servo						0.00 to 20,000 ([0.01 * s/rad s ⁻¹])					
Default	Closed-loop vector, Servo						500					
Linked to	Pr 0.32[2]											
Update rate	Background read											

For optimization of the speed loop on Unidrive SP the following gains are available,

- Kp** Proportional Gain
- Ki** Integral Gain
- Kd** Differential Gain

The following parameters can be used to monitor the performance of the drive during adjustment of the speed loop gains, comparing the speed reference to the speed feedback. Adjustment of the speed loop gains is carried out to minimize the speed loop following error and reach the required performance.

- Pr 3.01 Final speed reference
- Pr 3.02 Unidrive SP speed feedback
- Pr 3.03 Speed loop following error

NOTE

In addition to the speed loop gains, there is also a speed feedback filter Pr 3.42 which can be adjusted to improve the speed feedback for the closed loop control.

NOTE

In order to tune the speed loop the worst case conditions must be used, low speed and high speed under both full and low load conditions.

Kd Differential Gain

For virtually all elevator applications the Kd differential gain is not required. Therefore when referring to tuning of the speed loop gains we refer mainly to the Kp proportional and Ki integral gains.

Kp Proportional Gain

If Kp proportional gain has a value and Ki is set to zero the controller will only have a proportional term, and there must be a speed error to produce a torque reference. As the motor load increases there will be a difference between the speed reference and actual speed (speed feedback). This effect, called regulation depends on the level of the proportional gain, the higher the gain, the smaller the speed following error for a given load.

If the Kp proportional gain is too low for a given load condition;


- The speed following error will increase
- Speed droop and overshoot can be present during transitions in speed reference
- Oscillations can be present during constant speed operation.

If the Kp proportional gain is increased for a given load the speed following error along with the speed droop and overshoot will be reduced.

If the Kp proportional gain is increased too high, either;

- The acoustic noise generated from the motor due to the Kp proportional gain amplifying the speed feedback quantization, will become unacceptably high.
- The closed loop stability limit will be reached where quantization due to the encoder feedback resolution will appear on the speed feedback as oscillations.

Figure 7-11 Speed loop Kp Proportional gain




Ki Integral Gain

The Ki integral gain responds proportionally to the accumulated speed error over a period of time. The Ki integral gain prevents regulation and increases the output dynamic performance.

- Increasing the integral gain reduces the time taken for the speed to reach the correct level and increases the stiffness of the system, i.e. it reduces the shaft displacement produced when applying a load torque to the motor.
- Increasing the integral gain also reduces the system damping giving overshoot after a transient. For a given Ki integral gain the damping can be improved by further increasing the Kp proportional gain.
- A compromise must be reached where the system response, stiffness and damping are all adequate for the application.

Figure 7-12 Speed loop Ki Integral gain



NOTE

The resolution of the encoder feedback device will affect the maximum achievable Kp proportional gain. Higher resolution encoders such as Sincos encoders provide much higher resolution and are the preferred feedback device for high ride quality.

- Ab** 1024 ppr encoder **10bit** (10bit incremental)
- SinCos** 1024 ppr encoder **20bit** (10bit incremental + 10bit interpolated)

20.29	Variable gains speed threshold											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Closed-loop vector, Servo						0 to 30,000 (mm/s)					
Default	Closed-loop vector, Servo						0					
Linked to												
Update rate	Background read											

This parameter is used to define the speed threshold point for acceleration and deceleration where the variable gains change.

Separate Speed loop gains, Current loop gains, Current demand filter

Start, Travel, Stop

Pr 0.21[2], Pr 18.48 = On, Pr 19.48 = On

This parameter is used to define the speed threshold point at which the variable gains begin to change.

Separate speed loop gains, current loop gains, current demand filter

Start, Travel, Positioning

Pr 0.21[2], Pr 18.48 = On, Pr 19.48 = On

20.30	Variable gains transition time											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Closed-loop vector, Servo						0 to 30,000 (ms)					
Default	Closed-loop vector, Servo						0					
Linked to												
Update rate	Background read											

This parameter is used to define the deceleration time for the variable gains from the deceleration threshold in Pr 20.29 to Stop.

Pr 20.30 = 0 speed dependant transition

Pr 20.30 > 0 time dependant transition and Pr 20.29 is the speed threshold for deceleration

Separate Speed loop gains, Current loop gains, Current demand filter

Start, Travel, Stop

Pr 0.21[2], Pr 18.48 = On, Pr 19.48 = On

20.35	Diagnostic code											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1	1							
Range	Open loop, Closed-loop vector, Servo						0 to 30,000					
Default	Open loop, Closed-loop vector, Servo						0					
Linked to												
Update rate	Background read											

The above diagnostic code is only available in this parameter up to software version 01.21.

20.36	Run jerk – Acceleration											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open loop, Closed-loop vector, Servo						0 to 10,000 (mm/s ³)					
Default	Open loop, Closed-loop vector, Servo						1000					
Linked to												
Update rate	Background read											

This is a separate jerk that can be enabled for the end of the acceleration to travel, replacing the standard run jerk Pr 19.15. This is enabled with Pr 19.47 and replaces the standard Run jerk in Pr 19.15.

20.39	Diagnostic travel interrupt											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
				1	1							
Range	Open loop, Closed-loop vector, Servo						0 to 30,000					
Default	Open loop, Closed-loop vector, Servo						0					
Linked to												
Update rate	Background read											

The above diagnostic code is only available in this parameter from software version 01.21 onwards.

20.40	Motor contactor release delay time											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open loop, Closed-loop vector, Servo						0 to 90,000 (ms)					
Default	Open loop, Closed-loop vector, Servo						100					
Linked to												
Update rate	Background read											

This parameter is used to introduce a delay to the motor contactor release time to allow for motor demagnetization.

7.11 Menu 21 parameters

Parameter	Description	Type	Range	Default			Units
				OL	VT	SV	
21.01	Not used						
21.02	Not used						
21.03	Not used						
21.04	Not used						
21.05	Fast stop deceleration ramp	RW	0 to 1000	200.0			cm/s ²
			0 to 10		2.000		m/s ²
21.06	Not used						
21.07	Not used						
21.08	Not used						
21.09	Not used						
21.10	Not used						
21.11	Not used						
21.12	Stator resistance Travel, Stop	RW	0 to 60.000	0.000			
21.13	Not used						
21.14	Not used						
21.15	Not used						
21.16	Current loop filter 3 Positioning	RW	0 to 25.0		2.0		ms
21.17	Not used						
21.18	Not used						
21.19	Not used						
21.20	Not used						
21.21	Not used						
21.22	Current loop Kp -Gain 3 Positioning	RW	0 to 30,000		75		
21.23	Current loop Ki -Gain 3 Positioning	RW	0 to 30,000		1000		
21.24	Not used						
21.25	Not used						
21.26	Not used						
21.27	Not used						
21.28	Evacuation current limit full load	RW	0 to 30,000		110.0		%
21.29	Evacuation current limit no load	RW	0 to 30,000		80.0		%

Pr 20.25 through to Pr 20.28 and Pr 21.16, Pr 21.22, Pr 21.23 these parameters are RO until the variable gains are selected through Pr 0.21[2], Pr 18.48 and Pr 19.48 = On, only then do they become RW allowing the user to adjust.

21.05	Fast Stop rate												
Variants	Unidrive SP, Unidrive ES												
Drive modes	Open loop, Closed loop vector, Servo												
Coding	Bit	Txt	VM	RO	US	RW							
					1	1							
Range	Open loop, Closed-loop vector, Servo						0 to 10,000 (cm/s ²) 0 to 10,000 (m/s ²)						
Default	Open loop, Closed-loop vector, Servo						200.0 2.000						
Linked to													
Update rate	Background read												

When the fast stop is enabled using Pr 0.51[3], Pr 19.49 this is the fast stop rate used.

For the fast stop the Jerk is also modified, default 200ms, this being calculated from the fast deceleration rate Pr 21.05, Jerk = Pr 21.05 / 0.2

21.12	Stator resistance Travel, Stop											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open-loop											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open-loop						0.000 to 65.000 (ohms)					
Default	Open-loop						0.000					
Linked to												
Update rate	Background read											

Pr 21.12 shows the stator resistance of the motor. The units vary with the drive size to ensure that the full range of likely resistances can be represented with suitable resolution. The value displayed here is the stator resistance used during the travel when enabled through Pr 18.48.

Pr 18.48 Enable variable stator resistance

Pr 5.17 Start stator resistance [optimum value for start]

Pr 21.12 Travel stator resistance [autotune value]

Pr 19.11 Stator resistance transition time

The value in Pr 21.12 should be the autotuned value for the motor.

21.16	Current filter 3 positioning											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Closed-loop vector, Servo						0 to 25 (ms)					
Default	Closed-loop vector, Servo						0					
Linked to	Pr 0.33[2]											
Update rate	Background read											

This parameter is a current loop filter which can be introduced for the positioning / stop of the elevator. This filter can be used to overcome acoustic noise and instability in the motor due to current instability.

21.22	Current loop Kp -Gain 3 positioning												
Variants	Unidrive SP, Unidrive ES												
Drive modes	Closed-loop vector, Servo												
Coding	Bit	Txt	VM	RO	US	RW							
					1	1							
Range	Closed-loop vector, Servo						0 to 30,000						
Default	Drive voltage rating:						200V	400V	575V	690V			
	Closed-loop vector, Servo						75	150	180	215			
Linked to	Pr 0.34[2]												
Update rate	Background read												

21.23	Current loop Ki -Gain 3 positioning												
Variants	Unidrive SP, Unidrive ES												
Drive modes	Closed-loop vector, Servo												
Coding	Bit	Txt	VM	RO	US	RW							
					1	1							
Range	Closed-loop vector, Servo						0 to 30,000						
Default	Drive voltage rating						200V	400V	575V	690V			
	Closed-loop vector, Servo						1000	2000	2400	3000			
Linked to	Pr 0.35[2]												
Update rate	Background read												

The following is a guide to setting the current loop Kp proportional and Ki integral gains for different applications. The current controller loop consists of both a Kp proportional and Ki integral gain.

NOTE

The current controller Kp proportional and Ki integral gains derived from the auto-tune system give the best response at all switching frequencies

Open-loop control

The current controller provides current limit operation by modifying the drive output frequency. Although the default settings have been chosen to give suitable gains for less demanding applications it may be necessary for the user to adjust the performance of the controller.

The current limits will normally operate with an integral term only, particularly below the point where field weakening begins. The proportional term is inherent in the loop. The integral term must be increased enough to counter the effect of the ramp which is still active even in current limit.

For example, if the drive is operating at constant frequency and is overloaded the current limit system will try to reduce the output frequency to reduce the load. At the same time the ramp will try to increase the frequency back up to the demand level.

- If the Ki integral gain is increased too far the first signs of instability will occur when operating around base speed / the point where field weakening begins.
- Increasing the Kp proportional gain can reduce oscillations around base speed / the point where field weakening begins

Closed-loop vector and Servo

The proportional gain is the most critical value in controlling the performance of the current controllers. The value for the current controller Kp proportional gain can be set up through either a stationary or rotating auto tune. The current controller Kp proportional and Ki integral gains derived from the auto-tune system give the best response at all switching frequencies with minimal overshoot.

If required the gains can be adjusted to improve performance as follows:

- The Ki integral gain can be used to improve the performance of the current controllers by reducing the effects of inverter non-linearity. If the Ki integral gain is increased by a factor of 4 it is possible to get up to 10% overshoot in response to a step change of current reference. For high performance applications, it is recommended that the Ki integral gain be increased by a factor of 4 from the auto-tuned value. As the inverter non-linearity increases with higher switching frequencies it is may be necessary to increase the Ki integral gain by a factor of 8 for operation with 16kHz switching frequency.
- It is possible to increase the Kp proportional gain to reduce the response time of the current controller. If the Kp proportional gain is increased by a factor of 1.5 then the response to a step change of reference will give an increased overshoot of 12.5%.

NOTE

It is recommended that Ki integral gain be increased in preference to the Kp proportional gain.

Current loop sample rate

The following table gives the sampling rate for the current controller for the different switching frequencies.

Table 7-8 Current loop sampling rates

	3, 6, 12kHz	4, 8, 16kHz	Open-loop	Closed-loop vector	Servo
Level 1	3 = 167µs 6 = 83µs 12 = 83µs	125µs	Peak limit	Current controller	Current controller
Level 2	250µs	250µs	Current limit Ramps	Speed controller Ramps	Speed controller Ramps
Level 3	1ms	1ms	Voltage controller	Voltage controller	Voltage controller

NOTE

The current loop Kp proportional gain from the auto tuned value may need to be reduced for some motors due to acoustic noise. If acoustic noise is present, the current loop Kp proportional gain can be reduced by up to half, provided the reduced performance of the current loop remains acceptable. Where the gain cannot be reduced, consider using a current loop filter.

NOTE

For open loop mode there are no variable current loop gains and therefore **F41**, Pr **4.13** = 20 and **F42** Pr **4.14** = 40 are active during the complete travel.

21.28	Evacuation current limit full load										
Variants	Unidrive SP, Unidrive ES										
Drive modes	Open loop, Closed-loop vector, Servo										
Coding	Bit	Txt	VM	RO	US	RW					
					1	1					
Range	Open loop, Closed-loop vector, Servo						0 to current limit (%)				
Default	Open loop, Closed-loop vector, Servo						110				
Linked to											
Update rate	Background read										

This parameter defines the maximum allowable overload during evacuation control to prevent the UPS power supply from being overloaded.

21.29	Evacuation current limit no load											
Variants	Unidrive SP, Unidrive ES											
Drive modes	Open loop, Closed-loop vector, Servo											
Coding	Bit	Txt	VM	RO	US	RW						
					1	1						
Range	Open loop, Closed-loop vector, Servo						0 to current limit (%)					
Default	Open loop, Closed-loop vector, Servo						80					
Linked to												
Update rate	Background read											

This parameter defines the maximum no load current limit during evacuation control to prevent the UPS power supply from being overloaded.

8 Set-up

For set-up of the Unidrive SP Elevator Solution Software, follow the instructions given in this section. Software tools are also available to assist with the commissioning and set-up of the Unidrive SP elevator solution, refer to Chapter 11 *Commissioning software tools*

Table 8-1 Initial set-up and configuration

Initial configuration and set-up procedure		
Before power-up	Motor connections	Make motor connections ensuring correct orientation for closed loop operation. Ensure shield and grounding connections follow the recommendations for EMC.
	Brake connections	Make connections for brake control and set-up for either elevator control, or Unidrive SP and the Elevator Solution Software control.
	Motor contactor connections	Make connections for motor contactor control for either the elevator controller or Unidrive SP and the Elevator Solution Software. For servo mode a Fast disable may also be required to prevent any arcing of the output motor contactors.
	Encoder feedback connections	Connect encoder feedback ensuring correct cable with shielding is used and is terminated correctly. Ensure correct connections for orientation of feedback with respect to motor.
	Encoder output connections	Fit a Solutions Module to provide simulated encoder output if required.
	Control connections	Make all connections from the elevator controller to the Unidrive SP.
Power-up Parameter configuration	Control connections	Ensure all control connections required for elevator speed selection and direction control are configured, along with brake control and motor contactor control, if control is required from the Unidrive SP Elevator Solution Software.
	Motor	Set-up all motor map parameters
	Encoder feedback	Set-up encoder feedback connected to Unidrive SP along with simulated encoder output if required for the elevator controller.
	Elevator parameters	Set-up elevator control parameters. <ul style="list-style-type: none"> • Rated speed mm/s • Preset speeds • Accel, Decel ramp rates • Direction control • Jerks • Brake control • Motor contactor control
Autotune		<p>An autotune should be carried out to set-up the drive to the motor.</p> <ul style="list-style-type: none"> • Voltage offset [OL] • Power factor [OL CL] • Stator resistance [OL CL SV] • Transient inductance [OL CL SV] • Stator inductance [CL] • Phase offset [SV] <p>NOTE</p> <p>For Servo operation an autotune must be carried out with no load present to derive the required phase offset value, unless this is already known and therefore can be entered manually. In some systems a balanced load condition may be sufficient for the autotune to be carried out.</p>

8.1 Autotune

For the initial set-up of the elevator motor, adjustment of the motor control parameters must be carried out, this is performed by the drive through an automatic self-tuning autotune. There are two possible autotunes available, a "rotating" and "static" autotune.

During the rotating autotune the elevator must be operated manually, therefore the inspection command has to be provided. If the inspection command is active and the drive is not enabled / the motor does not run, refer to configuration of the control terminals and parameter settings within the drive. The rotating autotune should be carried out with no load on the motor.

NOTE

For Servo operation with a PM motor, the Unidrive SP must be autotuned under a no load condition (i.e. ropes removed from the motor/sheave), unless the motor phase offset value is already known, in which case this can simply be entered and a static autotune carried out. In some systems a balanced load condition may be sufficient for the autotune to be carried out.

8.1.1 Open loop vector - autotune

STATIC autotune	
For open loop vector control it is necessary to measure the motor's stator resistance Pr 5.17 and voltage offset Pr 5.23 . These can automatically be measured by the drive through a static autotune with the motor at standstill and the brake applied, Pr 0.40 = 1 as follows.	
1	Set F14 , Pr 0.40 = 1, selecting static autotune
2	Apply an enable to Unidrive SP and maintain
3	Close the motor contactor(s) at the output of Unidrive SP
4	Note settings of Pr 5.17 and Pr 5.23
5	Wait until F14 , Pr 0.40 = 0, static autotune has completed
6	Remove enable to Unidrive SP and maintain
7	Open the motor contactor(s) at the output of Unidrive SP
8	Save parameters in Unidrive SP Pr MM.00 = 1000

8.1.2 Closed loop vector - autotune

STATIC autotune	
To ensure best performance it is recommended that the motor's stator resistance Pr 5.17 and transient inductance Pr 5.24 be measured, these can be automatically carried out by the drive through a static autotune with the motor at standstill and the brake applied. It should also be noted that following the static autotune will set-up the current loop gains (F 41 , Pr 0.38 , Pr 4.13 & F 42 , Pr 0.39 , Pr 4.14) automatically for the motor based on the resistance and inductance measurements from the static autotune.	
1	Set F14 , Pr 0.40 = 1, selecting static autotune
2	Apply an enable to Unidrive SP and maintain
3	Close the motor contactor(s) at the output of Unidrive SP
4	Note settings of Pr 5.17 and Pr 5.24
5	Note settings of F 41 , Pr 0.38 , Pr 4.13 and F 42 , Pr 0.39 , Pr 4.14
6	Wait until F14 , Pr 0.40 = 0, static autotune completed
7	Remove enable to Unidrive SP and maintain
8	Open the motor contactor(s) at the output of Unidrive SP
9	Save parameters in Unidrive SP Pr MM.00 = 1000

For closed loop vector operation it is also possible to carry out a static autotune to set-up the current loop gains alone based on the motors resistance and inductance values stored in Pr **5.17** and Pr **5.24** as follows.

To carry out the static autotune for the current loop gains alone, set **F14**, Pr **0.40** = 4, selecting static current loop gains autotune.

For further optimization of the drive when operating in closed loop vector, a rotating autotune is also possible with the rotating autotune, it is necessary to remove the ropes from the sheave due to the motor having to run for several seconds.

ROTATING autotune – Full motor characteristics	
For complete optimization the Unidrive SP can measure in addition to the stator resistance Pr 5.17 , transient inductance Pr 5.24 and current loop gain set-up Pr 0.38 , Pr 4.13 & Pr 0.39 , Pr 4.14 the full motor characteristics.	
1	Set F14 , Pr 0.40 = 2, select static autotune
2	Apply Inspection speed, enable and maintain
3	Close the motor contactor(s) at the output of Unidrive SP
4	Open brake
5	The motor should now rotate at inspection speed
6	Note settings of Pr 5.17 and Pr 5.24
7	Note settings of F 41 , Pr 0.38 , Pr 4.13 and F 42 , Pr 0.39 , Pr 4.14
8	Note settings of Pr 5.25 , Pr 5.29 , and Pr 5.30
9	Wait until F14 , Pr 0.40 = 0, Rotating autotune is complete
10	Remove inspection speed and enable
11	Apply brake
12	Open motor contactor(s) at the output of Unidrive SP
13	Save parameters in Unidrive SP Pr MM.00 = 1000

8.1.3 Servo - autotune

The phase angle of magnetic rotor flux relative to the rotor's feedback device angular orientation must be measured with a rotating autotune, or if given on the motor's nameplate information, be entered into the Unidrive SP parameter, **F11**, Pr **0.43**, Pr **3.25**.

Manual setting of the motor phase offset from motor nameplate

If the motor phase offset value is known and the connection of the output motor phases is U - V - W at the drive, proceed as follows

- Set parameter **F11**, Pr **0.43**, Pr **3.25** = Motor phase offset
- Save parameter in Unidrive SP Pr **MM.00** = 1000.

If the motor phase offset value is not known and not available on the motor nameplate, then a rotating autotune must be carried out to derive this value. The rotating autotune must be carried out with no load present on the motor (ropes removed from sheave). In some systems a balanced load condition may be sufficient for the autotune to be carried out.

ROTATING autotune - Measurement of the encoder phase angle - Full motor characteristics & current loop

If the motor phase offset is not known or the connection of the motor phases is not U - V - W, the value can be measured automatically by the drive through an autotune. To get exact values it is necessary to have no load on the motor shaft, therefore remove the ropes from the sheave. If the elevator has very low friction it may be sufficient in some cases to have a balanced load in the car for the autotune.

1	F14 , Pr 0.40 = 2, Activate normal low speed autotune
2	Apply Inspection speed, enable and maintain
3	Close the motor contactor(s) at the output of Unidrive SP
4	Open brake
5	The motor will rotate at low speed for approximately 30 seconds.
If a trip ENC1 occurs swap motor cables U with V at the drive	
6	Note settings of Pr 0.43 , Pr 3.25
7	Note settings of F41 , Pr 0.38 , Pr 4.13 and F42 , Pr 0.39 , Pr 4.14
8	Note settings of Pr 5.17 and Pr 5.24
9	Wait until F14 , Pr 0.40 = 0, Normal low speed autotune complete
10	Remove inspection speed / enable
11	Apply brake
12	Open motor contactor(s) at the output of Unidrive SP
13	Save parameters in Unidrive SP Pr MM.00 = 1000

STATIC autotune

For best performance it is recommended that the motors stator resistance Pr **5.17** and transient inductance Pr **5.24** be measured, this can be automatically carried out by the drive through a static autotune at standstill with the brake applied. It should also be noted that following the static autotune will automatically set-up the current loop gains (**F41**, Pr **0.38**, Pr **4.13** & **F42**, Pr **0.39**, Pr **4.14**) for the motor based on the resistance and inductance measured during the Static autotune.

1	Set F14 , Pr 0.40 = 4, select Static autotune
2	Apply enable to Unidrive SP and maintain
3	Close the motor contactor(s) at the output of Unidrive SP
4	Note settings of Pr 5.17 and Pr 5.24
5	Note settings of F41 , Pr 0.38 , Pr 4.13 and F42 , Pr 0.39 , Pr 4.14
6	Wait until F14 , Pr 0.40 = 0, Static autotune complete.
7	Remove enable to Unidrive SP and maintain
8	Open the motor contactor(s) at the output of Unidrive SP
9	Save parameters in Unidrive SP Pr MM.00 = 1000

The current loop gains can only be set-up automatically through a static autotune at standstill with the brake applied. In order for this static autotune to be carried out correctly there must be values in both Pr **5.17** motor stator resistance and Pr **5.24** transient inductance. This autotune does not require an enable, as it is purely a calculation carried out inside the drive based on Pr **5.17** and Pr **5.24** and by setting **F14**, Pr **0.40** = 6, select Static current loop gains autotune.

NOTE

Following the autotune, the current loop gains calculated may be slightly high and require adjustment (acoustic noise from motor). If this is the case both **F41**, Pr **0.38**, Pr **4.13** and **F42**, Pr **0.39**, Pr **4.14** can be reduced.

8.2 First start with empty car

8.2.1 Activate first start

On the first start of the elevator it is important that the correct control terminals are configured for the required speed selection from the Elevator controller along with the enable and direction inputs.

It is also essential that the rotation of the motor phases and the encoder feedback connections be in the same direction for correct closed loop operation.

Activate first start	
Ensure enable, T.31 is connected and the active current Pr 0.11 , Pr 4.02 is displayed	
Start with Inspection speed and check the active current display Pr 0.11 , Pr 4.02 and the shaft rotation	
If status display does not change to "run"	Check logic polarity Control terminals connections
If the motor active current Pr 0.11 , Pr 4.02 = 0.00	Check logic polarity Control terminals Motor connections, contactors, brake
Following error trip (t070 or t071)	Check encoder feedback Motor connections Encoder phase angle Motor map settings
If the motor shaft does not rotate	Check speed ref. selected F50 , Pr 0.28[0] , Pr 18.10 Run command is applied
If speed ref. F50 , Pr 0.28[0] , Pr 18.10 = 1810 (no speed reference selected)	Check terminal configuration for speed selection and status of speed selection
If It.AC trip occurs	Check load balance Motor phase offset (Servo mode) Motor connection
If motor turns shortly / stops with current	Check motor pole count F09 , Pr 0.42[0] , Pr 5.11 Encoder lines F05 , Pr 0.29[0] , Pr 3.34
If motor turns opposite direction	Set direction invert F23 , Pr 0.22[1] , Pr 18.45 = 1
For closed loop vector and servo where speed instability is present during operation	Check encoder feedback cable connections and shielding Follow EMC recommendations to prevent induced noise onto feedback
Other trips	See Diagnostics section 12
If no trip	Continue with optimization refer to section 9 <i>Optimization</i> on page 136

8.2.2 Motor contactor / Brake control adjustment

To prevent over voltages at the motor windings and the drive output during motor contactor opening, the drive output should be disabled after the brake apply time is completed. The delay between the drive output disable and the opening of the motor contactor is displayed in Pr **0.26[1]**, Pr **20.20** Motor contactor delay time in ms.

NOTE

For operation in servo mode a Fast disable may be required. For more details please refer to section 4.20.2 *Fast disable* on page 45.

A negative value in Pr **0.26[1]**, Pr **20.20** indicates that the motor contactor opened whilst current was flowing, which should be prevented. In this case the brake apply time, **F38**, Pr **0.25[0]**, Pr **18.24** must be increased, at least, to the value of Pr **0.26[1]**, Pr **20.20**.

Motor contactor / Brake control adjustment	
Start normal floor level runs	
Check the motor contactor delay time	Pr 0.26[1] , Pr 20.20 (ms)
Increase the brake apply delay time if a negative value is in Pr 0.26[1] , Pr 20.20 (ms)	Increase brake apply time F38[0] , Pr 0.25[1] , Pr 18.24 (ms)
Positive values of 50...100 ms in (ms) Pr 0.26[1] , Pr 20.20 are acceptable, for excessive values reduce brake apply delay.	Reduce brake apply time F38 , Pr 0.25[1] , Pr 18.24 (ms)

8.2.3 Adjustment of motor rated speed / slip

The motor rated speed and slip should be set-up correctly for induction machines controlled in open and closed loop vector. For open loop control the rated load rpm is used with the motor rated frequency to calculate the rated slip in Hz. For closed loop the rated load rpm is used with the motor rated frequency to determine the full load slip of the motor that is used by the vector control algorithm.

Incorrect settings for the motor rated slip can result in:

- Reduced efficiency of the motor
- Reduction of maximum torque available from the motor
- Reduced transient performance

Adjustment of motor rated speed / slip – manual with tachometer	
Select creep speed "V1" parameter F24, Pr 0.15[0], Pr 18.11	
Ensure slip compensation enabled	Set Pr 5.27 = 1 (Default = 1)
Start inspection "UP" and "DOWN"	
Measure speed manually with tachometer	Target is UP speed = DOWN speed
If speed "UP" > "DOWN"	Reduce F10 , Pr 0.45[0] , Pr 5.08 in steps of 1...10
If speed "UP" < "DOWN"	Increase F10 , Pr 0.45 , Pr 5.08 in steps of 1...10

For servo mode, the rated load rpm defines the rated speed of the motor and is used in the thermal motor protection. Slip does not apply to a PM motor and servo operation.

8.2.4 Adjustment of variable stator resistance (Open loop)

Adjustment of variable stator resistance	
Adjustment of the elevator start in open loop can include the variable stator resistance function.	
Starting torque requires optimization for the Open loop mode to ensure smooth start and prevent rollback.	
Enable	Enable variable stator resistance control Pr 0.21[2] , Pr 18.48 = On (1)
	Ensure auto tune has been carried out and values in Pr 5.17 Start and Pr 21.12 Travel
Adjustment	Increase Pr 5.17 the start stator resistance to obtain the maximum rated torque from the motor. Value should be increased gradually in order to prevent overloading of the motor at the start during low speed.
	The transition time from the start torque to the travel torque is controlled through Pr 0.22[2] , Pr 19.11 and should be kept as low as possible to avoid overloading the motor at the start during low speed

9 Optimization

9.1 Open loop vector

For standard open loop control and maximum torque at low / zero speed, the timing sequence and brake control are essential and therefore have to be adjusted precisely.

Therefore the motor model has to be optimally configured, i.e. the motor stator resistance and slip compensation.

An autotune should be carried out and all motor related parameters set-up as accurately as possible. The motor rated speed / slip should be set-up initially from the motor's nameplate and where possible optimized manually with a tachometer as covered in Chapter 8 *Set-up* on page 131.

Optimization – open loop	
Jerk at start too high	
Start jerk	Adjust start jerk F34 , Pr 0.23[0] , Pr 19.14 e.g. ...300 mm/s ³ (Softer)
AND / OR	
Brake control	Adjust brake release delay F37 , Pr 0.24[1] , Pr 19.25 e.g. ...500 ms
Start optimizer	Adjust speed for start optimizer Pr 0.18[1] , Pr 18.18 e.g. ...300 mm/s
	Adjust time for start optimizer F31 , Pr 0.19[1] , Pr 19.28 e.g. ... 1000 ms
	Adjust jerk for start optimizer Pr 0.20[1] , Pr 19.17 e.g. ... 50 mm/s ³
Jerk or backward rotation when brake releases	Increase speed for start optimizer Pr 0.18[1] , Pr 18.18 e.g. ... 500 mm/s ³
Ensure correct value of stator resistance	Stator resistance in Pr 5.17 can be derived from static autotune and further optimized manually if required.
Optimize constant speed	
Vibrations or overshoot present	Reduce slip compensation by increasing Pr 5.08 motor-rated speed.
	Disable Quasi-square wave to prevent over modulation Pr 5.20 = 0
Optimize stop	
High jerk as the elevator stops	Reduce stop jerk F36 , Pr 0.25 , Pr 19.16 e.g. ...500 mm/s ³ (Softer)
	Reduce zero speed threshold Pr 3.05 e.g. 0.5 ... 2 Hz

9.1.1 Adjustment of deceleration / positioning

Adjustment of deceleration positioning	
Check for correct speed selection Pr 18.10 reference value selected	If not correct, check the connections from elevator controller to the control terminal of Unidrive SP for selection of speed, Pr 18.10
Check stopping distance V1 Pr 0.29[3] , Pr 19.05	Change V1 (creep speed) F24 , Pr 0.15[0] , Pr 18.11 or stop jerk level F36 , Pr 0.25 , Pr 19.16
Check reference deceleration distance Pr 0.14[3] , Pr 19.08	Select speed for deceleration distance via control input from elevator controller Read selected speed in F50 , Pr 0.28[0] , Pr 18.10 Read reference distance in Pr 0.14[3] , Pr 19.08 Change Deceleration rate F33 , Pr 0.04[0] Pr 2.21 Run jerk F35 , Pr 0.24 , Pr 19.15
Start normal floor levelling runs	Check the measured creep distance in Pr 20.21 mm

9.2 Closed loop vector

During this step the elevator performance is optimized to ensure the travel speed is correct and the required comfort level is achieved with the designed operating speeds also being achieved. In addition to the subjective test of the elevator performance, it is advisable to use the oscilloscope function included in the PC based scope software to achieve the best performance and to prevent any issues being overlooked. The oscilloscope will allow all associated drives parameters to be monitored. For more information see section 11.2 *CTScope* on page 145.

9.2.1 Adjustment of the control

With recommended gain values only a few adjustments will be necessary to achieve good performance. The type of encoder feedback device used will have an effect on the maximum value of speed loop gains and performance achieved.

A low-resolution feedback device, e.g. quadrature AB 1024ppr encoder will provide reduced speed loop gains and performance compared to a high-resolution feedback device, e.g. SinCos encoder, which will allow much higher speed loop gains and performance.

Optimization - closed loop, servo	
Optimize start	
If the car lurches at start	Increase brake release delay F37 , Pr 0.24[1] , Pr 19.25 to 2500ms
If the car lurches or rotates during brake release	Activate separate speed loop gains Pr 0.21[2] , Pr 18.48 = 1
Adjustment of the speed loop Kp gain	Kp gain start F43 , Pr 0.25[2] , Pr 18.27 adjust to 2 x F45 , Pr 0.23[2] , Pr 18.25 (Harder)
	Increase F43 , Pr 0.25[2] , Pr 18.27 in steps of 0.01 until noisy or unstable
	Run gain is typically 50% to 60% of start gain
Adjustment of speed loop Ki gain	Ki gain start F44 , Pr 0.26[2] , Pr 18.28 adjust to 2 x F46 , Pr 0.24[2] , Pr 18.26 (Stiffer)
	Increase F44 , Pr 0.26[2] , Pr 18.28 to 20...50% of 100 * F43 , Pr 0.25[2] , Pr 18.27
	Run gain is typically 50% to 60% of start gain
AND / OR	
Position controller for start	Enable Kp position controller gain F47 , Pr 0.19[2] , Pr 19.20 = 3 to 30
	Enable Kd position controller gain Pr 0.20 , Pr 19.12 = 10 to 100
If the jerk is too high at the start of ramp profile	Reduce start jerk F34 , Pr 0.23[0] , Pr 19.14 up to 300 mm/s ³ (Softer)
AND / OR	
Start optimizer	Activate start optimizer by setting the time in F38 , Pr 0.19[1] , Pr 19.28 > 0
	Set the speed for start optimizer Pr 0.18[1] , Pr 18.18 e.g. 5 to 15 mm/s
	Set time for start optimizer F38 , Pr 0.19[1] , Pr 19.28 e.g. 800...1000 ms
	Set jerk for start optimizer Pr 0.20[1] , Pr 19.17 e.g. 10 to 20 mm/s ³
Check elevator starts, if OK, reduce brake release delay as follows	
Adjustment of brake release delay	Reduce F37 , Pr 0.24[1] , Pr 19.25 to 300ms as long as no lurch appears at start

Optimize constant speed	
Vibration of gearless motors	Adjust the Ki gain for the current loop in F41 , Pr 0.38[0] to a maximum of 10000
	Adjust the Kp gain of the current loop in F42 , Pr 0.39[0] to a maximum of 1000
If unstable	Reduce to 60% of the instability value
Regulation noise increases	Stop adjustment of gains and reduce slightly
If OI.AC- trip or instability occurs	Reduce the current loop Kp and Ki gain values by 60%
Over / undershoot during acceleration / deceleration to or from contract speed	Reduce run jerk level F35 , Pr 0.24[0] , Pr 19.15 for example 500 mm/s ³ (Softer)
	Consider increased deceleration distances
AND / OR	
Enable inertia compensation	Pr 0.28[2] , Pr 18.49 = 1
Check speed loop output Pr 0.22[4] , Pr 3.04	Adjust Pr 0.27[2] , Pr 19.19 , so that Pr 0.22[4] , Pr 3.04 is nearly constant
Optimize stop	
Lurch present at stop from creep speed	Reduce stop jerk F36 , Pr 0.25[0] , Pr 19.16 in the region of ...500 mm/s ³ (Softer)
	Reduce zero speed threshold Pr 3.05 = 2...4 rpm
Unwanted rotation during brake apply	Increase brake apply delay F38 , Pr 0.25[1] , Pr 18.24
	Check motor contactor delay to Pr 0.26[1] , Pr 20.20 > 0
Following error detection set up	
Check speed error at travel Pr 0.25[4] , Pr 18.07	Set max speed error Pr 0.26[4] , Pr 19.24 = 10 x Pr 0.16[4] , Pr 18.10 (200 mm/s)
Check distance error at travel Pr 0.27[4] , Pr 18.06	Set max distance error Pr 0.28[4] , Pr 19.18 = 10 x Pr 0.27[4] , Pr 18.06 (200 mm)
Save Setting: Pr x.00 = 1000 and RESET	

9.2.2 Adjustment of deceleration / positioning

Adjustment of deceleration positioning	
Check for correct speed selection Pr 18.10 reference value selected	If not correct, check connections from elevator controller to the control terminals of Unidrive SP for selection of speed, Pr 18.10
Check stopping distance V1 Pr 0.29[3] , Pr 19.05	Change V1 (creep speed) F24 , Pr 0.15[0] , Pr 18.11 or stop jerk level F36 , Pr 0.25 , Pr 19.16
Check reference deceleration distance Pr 0.14[3] , Pr 19.08	Select speed for deceleration distance via control input from elevator controller Read selected speed in F50 , Pr 0.28[0] , Pr 18.10 Read reference distance in Pr 0.14[3] , Pr 19.08 Change Deceleration rate F33 , Pr 0.04[0] Pr 2.21 Run jerk F35 , Pr 0.24 , Pr 19.15
Start normal floor levelling runs	Check the measured creep distance in Pr 20.21 mm

NOTE

Induced noise on the encoder feedback can result in instability, reduced performance and limited speed loop gains. Also increased acoustic noise can also be generated dependant upon the motor design. The Unidrive SP has a speed feedback filter available in Pr **3.42** which can overcome low levels of induced noise. For higher levels of induced noise the encoder feedback cable connections and terminations must be checked.

10 SMARTCARD operation

10.1 Introduction

This is a standard feature that enables simple configuration of parameters in a variety of ways. The SMARTCARD can be used for:

- Parameter cloning between drives
- Saving whole drive parameter sets
- Saving 'differences from default' parameter sets
- Automatically saving all user parameter changes for maintenance purposes
- Loading complete motor map parameters

Size 0


When inserting the SMARTCARD, always ensure that ST SP0 arrow points upwards.

Size 1 to 6

The SMARTCARD is located at the top of the module under the drive display (if installed) on the left-hand side. Ensure the SMARTCARD is inserted with the SP1-9 arrow pointing upwards.

The drive only communicates with the SMARTCARD when commanded to read or write, meaning the card may be "hot swapped".

Figure 10-1 Installation of the SMARTCARD



The SMARTCARD has 999 individual data block locations. Each individual location from 1 to 499 can be used to store data until the capacity of the SMARTCARD is used. With software V01.07.00 and later the drive can support SMARTCARDS with a capacity of between 4kB and 512kB. With software V01.06.02 and earlier the drive can support SMARTCARDS with a capacity of 4kB.

The data block locations of the SMARTCARD are arranged to have the following usage:

Table 10-1 SMARTCARD data blocks

Data Block	Type	Example Use
1 to 499	Read / Write	Application set ups
500 to 999	Read Only	Macros

'Differences from default' parameter sets will be much smaller than whole parameter sets and thus take up a lot less memory as most applications only require a few parameters to be changed from the default setting.

The whole card may be protected from writing or erasing by setting the read-only flag as detailed 9888 / 9777 - *Setting and clearing the SMARTCARD read only flag*.

Data transfer to or from the SMARTCARD is indicated by one the following:

- SM-Keypad/SP0-Keypad: The decimal point after the fourth digit in the upper display will flash.
- SM-Keypad Plus: The symbol 'CC' will appear in the lower left hand corner of the display

The card should not be removed during data transfer, as the drive will produce a trip. If this occurs then either the transfer should be reattempted or in the case of a card to drive transfer, default parameters should be loaded.

NOTE

Storing of Menu 20 parameters onto a SMARTCARD and transferring to the drive is not possible with software versions up to V1.13 unless the following sequence is carried out. The issue with Menu 20 parameter downloads from the SMARTCARD to the drive when using the Elevator Solution Software is due to parameters being set to default values when reading SMARTCARD blocks with differences to default (4xxx).

Encoder phase angle (servo mode only)

With drive software version V01.08.00 onwards, the encoder phase angle in Pr **3.25** is cloned to the SMARTCARD when using any of the SMARTCARD transfer methods.

With drive software version V01.05.00 to V01.07.01, the encoder phase angle in Pr **3.25** is only cloned to the SMARTCARD when using either Pr **0.30** set to Prog (2) or Pr **xx.00** set to 3yyy.

This is useful when the SMARTCARD is used to back-up the parameter set of a drive but caution should be used if the SMARTCARD is used to transfer parameter sets between drives. Unless the encoder phase angle of the servo motor connected to the destination drive is known to be the same as the servo motor connected to the source drive, an autotune should be performed or the encoder phase angle should be entered manually into Pr **3.25**. If the encoder phase angle is incorrect the drive may lose control of the motor resulting in an O.SPd or Enc10 trip when the drive is enabled.

With drive software version V01.04.00 and earlier, or when using software version V01.05.00 to V01.07.01 and Pr **xx.00** set to 4yyy is used, then the encoder phase angle in Pr **3.25** is not cloned to the SMARTCARD. Therefore, Pr **3.25** and Pr **21.20** in the destination would not be changed during a transfer of this data block from the SMARTCARD.

Following is the required procedure for loading the correct Menu 20 parameters from the SMARTCARD to the drive (V1.13 or earlier).

- Copy parameter set from first drive Pr **x.00** = 400x + Reset
- Transfer to second drive
 - Pr **17.13** = 0
Stops Elevator Solution Software running during transfer
 - Pr **17.19** = ON
Reset SM-Applications Lite (changes ON to OFF)
 - Pr **x.00** = 600x + Reset
Program parameters from SMARTCARD to drive with Pr **x.00** = 600x
 - Pr **17.19** = ON
Reset SM-Applications Lite (changes On to OFF)

This issue has been corrected with Elevator Solution Software version V1.14.

10.2 Transferring data

Data transfer, erasing and protecting the information is performed by entering a code in Pr **xx.00** and then resetting the drive as shown in Table 10-2.

Table 10-2 SMARTCARD codes

Code	Action
2001	Transfer drive parameters as difference from defaults to a bootable SMARTCARD block in data block number 001
3yyy	Transfer drive parameters to a SMARTCARD block number yyy
4yyy	Transfer drive data as difference from defaults to SMARTCARD block number yyy
5yyy	Transfer drive Onboard PLC program to SMARTCARD block number yyy
6yyy	Transfer SMARTCARD data block yyy to the drive
7yyy	Erase SMARTCARD data block yyy
8yyy	Compare drive parameters with block yyy
9555	Clear SMARTCARD warning suppression flag (V01.07.00 and later)
9666	Set SMARTCARD warning suppression flag (V01.07.00 and later)
9777	Clear SMARTCARD read-only flag
9888	Set SMARTCARD read-only flag
9999	Erase SMARTCARD

Where yyy indicates the block number 001 to 999. See Table 10-1 for restrictions on block numbers.

NOTE

If the read only flag is set then only codes 6yyy or 9777 are effective.

10.2.1 Writing to the SMARTCARD 3yyy - Transfer data to the SMARTCARD

The data block contains the complete parameter data from the drive, i.e. all user save (US) parameters except parameters with the NC coding bit set. Power-down save (PS) parameters are not transferred to the SMARTCARD.

With software V01.06.02 and earlier, a save must have been performed on the drive to transfer the parameters from the drive RAM to the EEPROM before the transfer to the SMARTCARD is carried out.

4yyy - Write default differences to a SMARTCARD

The data block only contains the parameter differences from the last time default settings were loaded.

Six bytes are required for each parameter difference. The data density is not as high as when using the 3yyy transfer method as described in the previous section, but in most cases the number of differences from default is small and the data blocks are therefore smaller. This method can be used for creating drive macros. Power-down save (PS) parameters are not transferred to the SMARTCARD.

The data block format is different depending on the software version. The data block holds the following parameters:

Software V01.06.02 and earlier

All user save (US) parameters, except those with the NC (Not Cloned) coding bit set or those that do not have a default value, can be transferred to the SMARTCARD.

Software V01.07.xx

All user save (US) parameters, except those with the NC (Not Cloned) coding bit set or those that do not have a default value, can be transferred to the SMARTCARD. In addition to these parameters all menu 20 parameters (except Pr **20.00**), can be transferred to the SMARTCARD even though they are not user save parameters and have the NC coding bit set.

Software V01.08.00 onwards

All user save (US) parameters including those that do not have a default value (i.e. Pr **3.25** or Pr **21.20 Encoder phase angle**), but not including those with the NC (Not Cloned) coding bit set can be transferred to the SMARTCARD. In addition to these parameters all menu 20 parameters (except Pr **20.00**), can be transferred to the SMARTCARD even though they are not user save parameters and have the NC coding bit set.

It is possible to transfer parameters between drive with each of the different formats, however, the data block compare function does not work with data produced by different formats.

Writing a parameter set to the SMARTCARD (Pr 11.42 = Prog (2))

Setting Pr **11.42** to Prog (2) and resetting the drive will save the parameters to the SMARTCARD, i.e. this is equivalent to writing 3001 to Pr **xx.00**. All SMARTCARD trips apply except 'C.Chg'. If the data block already exists it is automatically overwritten. When the action is complete this parameter is automatically reset to nonE (0).

10.2.2 Reading from the SMARTCARD 6yyy - Read default differences from a SMARTCARD

When the data is transferred back to a drive, using 6yyy in Pr **xx.00**, it is transferred to the drive RAM and the drive EEPROM. A parameter save is not required to retain the data after power-down. Set up data for any Solutions Modules fitted are stored on the card and are transferred to the destination drive. If the Solutions Modules are different between the source and destination drive, the menus for the slots where the Solutions Module categories are different are not updated from the card and will contain their default values after the cloning action. The drive will produce a 'C.Optn' trip if the Solutions Modules fitted to the source and destination drive are different or are in different slots. If the data is being transferred to a drive of a different voltage or current rating a 'C.rtg' trip will occur.

The following drive rating dependant parameters (RA coding bit set) will not be transferred to the destination drive by a SMARTCARD when the rating of the destination drive is different from the source drive and the file is a parameter file (i.e. created using the 3yyy transfer method). However, with software V01.09.00 and later drive rating dependent parameters will be transferred if only the current rating is different and the file is a differences from default type file (i.e. created using the 4yyy transfer method). If drive rating dependant parameters are not transferred to the destination drive they will contain their default values.

Pr **2.08 Standard ramp voltage**

Pr **4.05** to Pr **4.07** and Pr **21.27** to Pr **21.29 Current limits**

Pr **4.24, User current maximum scaling**

Pr **5.07, Pr 21.07 Motor rated current**

Pr **5.09, Pr 21.09 Motor rated voltage**

Pr **5.10, Pr 21.10 Rated power factor**

Pr **5.17, Pr 21.12 Stator resistance**

Pr **5.18 Switching frequency**

Pr **5.23, Pr 21.13 Voltage offset**

Pr **5.24, Pr 21.14 Transient inductance**

Pr **5.25, Pr 21.24 Stator inductance**

Pr **6.06 DC injection braking current**

Pr **6.48 Mains loss ride through detection level**

Reading a parameter set from the SMARTCARD (Pr 11.42 =rEAd (1))

Setting Pr 11.42 to rEAd (1) and resetting the drive will transfer the parameters from the card into the drive parameter set and the drive EEPROM, i.e. this is equivalent to writing 6001 to Pr xx.00. All SMARTCARD trips apply. Once the parameters are successfully copied this parameter is automatically reset to nonE (0). Parameters are saved to the drive EEPROM after this action is complete.

NOTE

This operation is only performed if data block 1 on the card is a full parameter set (3yyy transfer) and not a default difference file (4yyy transfer). If block 1 does not exist a 'C.dAt' trip occurs.

10.2.3 Auto saving parameter changes (Pr 11.42 = Auto (3))

This setting causes the drive to automatically save any changes made to menu 0 parameters on the drive to the SMARTCARD. The latest menu 0 parameter set in the drive is therefore always backed up on the SMARTCARD. Changing Pr 11.42 to Auto (3) and resetting the drive will immediately save the complete parameter set from the drive to the card, i.e. all user save (US) parameters except parameters with the NC coding bit set. Once the whole parameter set is stored only the individual modified menu 0 parameter setting is updated.

Advanced parameter changes are only saved to the card when Pr xx.00 is set to a 1000 and the drive reset.

All SMARTCARD trips apply, except 'C.Chg'. If the data block already contains information it is automatically overwritten.

If the card is removed when Pr 11.42 is set to 3 Pr 11.42 is then automatically set to nonE (0).

When a new SMARTCARD is installed Pr 11.42 must be set back to Auto (3) by the user and the drive reset so the complete parameter set is rewritten to the new SMARTCARD if auto mode is still required.

When Pr 11.42 is set to Auto (3) and the parameters in the drive are saved, the SMARTCARD is also updated, therefore the SMARTCARD becomes a copy of the drives stored configuration.

At power-up, if Pr 11.42 is set to Auto (3), the drive will save the complete parameter set to the SMARTCARD. The drive will display 'cArd' during this operation. This is done to ensure that if a user puts a new SMARTCARD in during power down the new SMARTCARD will have the correct data.

NOTE

When Pr 11.42 is set to Auto (3) the setting of Pr 11.42 itself is saved to the drive EEPROM but NOT to the SMARTCARD.

10.2.4 Booting up from the SMARTCARD on every power-up (Pr 11.42 = boot (4))

When Pr 11.42 is set to boot (4) the drive operates the same as Auto mode except when the drive is powered-up. The parameters on the SMARTCARD will be automatically transferred to the drive at power-up if the following are true:

- A card is inserted in the drive
- Parameter data block 1 exists on the card
- The data in block 1 is type 1 to 5 (as defined in Pr 11.38)
- Pr 11.42 on the card set to boot (4)

The drive will display 'boot' during this operation. If the drive mode is different from that on the card, the drive gives a 'C.Type'. trip and the data is not transferred.

If 'boot' mode is stored on the copying SMARTCARD this makes the copying SMARTCARD the master device. This provides a very fast and efficient way of re-programming a number of drives.

If data block 1 contains a bootable parameter set and data block 2 contains an Onboard PLC program (type 17 as defined in Pr 11.38), then if the drive software version is V01.07.00 and later, the onboard PLC program will be transferred to the drive at power-up along with the parameter set in data block 1.

NOTE

'Boot' mode is saved to the card, but when the card is read, the value of Pr 11.42 is not transferred to the drive.

10.2.5 Booting up from the SMARTCARD on every power-up (Pr xx.00 = 2001), software V01.08.00 and later

It is possible to create a difference from default bootable file by setting Pr xx.00 to 2001 and resetting the drive. This type of file causes the drive to behave in the same way at power-up as a file created with boot mode set up with Pr 11.42. The difference from the default file is that it has the added advantage of including menu 20 parameters.

Setting Pr xx.00 to 2001 will overwrite data block 1 on the card if it already exists.

If a data block 2 exists and contains an Onboard PLC program (type 17 as defined in Pr 11.38), this will also be loaded after the parameters have been transferred.

A bootable difference from default file can only be created in one operation and parameters cannot be added, as they are saved via menu 0.

10.2.6 8yyy - Comparing the drive full parameter set with the SMARTCARD values

Setting 8yyy in Pr xx.00, will compare the SMARTCARD file with the data in the drive. If the compare is successful Pr xx.00 is simply set to 0. If the compare fails a 'C.cpr' trip is initiated.

10.2.7 7yyy / 9999 - Erasing data from the SMARTCARD

Data can be erased from the SMARTCARD either one block at a time or blocks all in one go.

- Setting 7yyy in Pr xx.00 will erase SMARTCARD data block yyy.
- Setting 9999 in Pr xx.00 will erase SMARTCARD data blocks.

10.2.8 9666 / 9555 - Setting and clearing the SMARTCARD warning suppression flag (V01.07.00 and later)

If the Solutions Modules fitted to the source and destination drive are different or are in different slots the drive will produce a 'C.Optn' trip. If the data is being transferred to a drive of a different voltage or current rating a 'C.rtg' trip will occur. It is possible to suppress these trips by setting the warning suppression flag. If this flag is set the drive will not trip if the Solutions Module(s) or drive ratings are different between the source and destination drives. The Solutions Module or rating dependent parameters will not be transferred.

- Setting 9666 in Pr xx.00 will set the warning suppression flag
- Setting 9555 in Pr xx.00 will clear the warning suppression flag

10.2.9 9888 / 9777 - Setting and clearing the SMARTCARD read only flag

The SMARTCARD may be protected from writing or erasing by setting the read only flag. If an attempt is made to write or erase a data block when the read only flag is set, a 'C.rdo' trip is initiated. When the read only flag is set only codes 6yyy or 9777 are effective.

- Setting 9888 in Pr xx.00 will set the read only flag
- Setting 9777 in Pr xx.00 will clear the read only flag.

10.3 Data block header information

Each data block stored on a SMARTCARD has header information detailing the following:

- A number which identifies the block (Pr 11.37)
- The type of data stored in the block (Pr 11.38)
- The drive mode if the data is parameter data (Pr 11.38)
- The version number (Pr 11.39)
- The checksum (Pr 11.40)
- The read-only flag
- The warning suppression flag (V01.07.00 and later)

The header information for each data block which has been used can be viewed in Pr 11.38 to Pr 11.40 by increasing or decreasing the data block number set in Pr 11.37.

Software V01.07.00 and later

If Pr 11.37 is set to 1000 the checksum parameter (Pr 11.40) shows the number of 16 byte pages left on the card.

If Pr 11.37 is set to 1001 the checksum parameter (Pr 11.40) shows the total capacity of the card in 16 byte pages. Therefore, for a 4kB card this parameter would show 254.

If Pr 11.37 is set to 1002 the checksum parameter (Pr 11.40) shows the state of the read-only (bit 0) and warning suppression flags (bit 1). Software version V01.11.00 and later: If Pr 11.37 is set to 1003, the checksum parameter (Pr 11.40) shows the product identifier (255 = Unidrive SP, 1 = Commander GP20, 2 = Digitax ST, 3 = Affinity, 4 = Mentor MP).

If there is no data on the card Pr 11.37 can only have values of 0 or 1,000 to 1,003.

Software V01.06.02 and earlier

If Pr 11.37 is set to 1000 the checksum parameter (Pr 11.40) shows the number of bytes left on the card. If there is no data on the card Pr 11.37 can only have values of 0 or 1,000.

The version number is intended to be used when data blocks are used as drive macros. If a version number is to be stored with a data block, Pr 11.39 should be set to the required version number before the data is transferred. Each time Pr 11.37 is changed by the user the drive puts the version number of the currently viewed data block in Pr 11.39.

If the destination drive has a different drive mode to the parameters on the card, the drive mode will be changed by the action of transferring parameters from the card to the drive.

The actions of erasing a card, erasing a file, changing a menu 0 parameter, or inserting a new card will effectively set Pr 11.37 to 0 or the lowest file number in the card.

10.4 SMARTCARD parameters

Table 10-3 Key to parameter table coding

RW	Read / Write	RO	Read only	Uni	Unipolar
Bi	Bi-polar	Bit	Bit parameter	Txt	Text string
Fl	Filtered	DE	Destination	NC	Not cloned
RA	Rating dependent	PT	Protected	US	User save
PS	Power down save				

11.36 {0.29} SMARTCARD parameter data previously loaded											
RO	Uni					NC	PT	US			
⇅	0 to 999					⇒	0				

This parameter shows the number of the data block last transferred from a SMARTCARD to the drive.

11.37 SMARTCARD data number											
RW	Uni					NC					
⇅	0 to 1,003					⇒	0				

This parameter should have the data block number entered for which the user would like information displayed in Pr 11.38, Pr 11.39 and Pr 11.40.

11.38 SMARTCARD data type/mode											
RO	Txt						NC	PT			
⇅	0 to 18					⇒					

Gives the type/mode of the data block selected with Pr 11.37:

Pr 11.38	String	Type/mode	Data stored
0	FrEE	Value when Pr 11.37 = 0, 1,000, 1,001 or 1,002	Data from EEPROM
1		Reserved	
2	3OpEn.LP	Open-loop mode parameters	
3	3CL.VECt	Closed-loop vector mode parameters	
4	3SErVO	Servo mode parameters	
5	3rEgEn	Regen mode parameters	
6 to 8	3Un	Unused	
9		Reserved	
10	4OpEn.LP	Open-loop mode parameters	
11	4CL.VECt	Closed-loop vector mode parameters	
12	4SErVO	Servo mode parameters	
13	4rEgEn	Regen mode parameters	
14 to 16	4Un	Unused	
17	LAddEr	Onboard PLC program	
18	Option	A Solutions Module file	

11.39 SMARTCARD data version											
RW	Uni						NC				
⇅	0 to 9,999					⇒	0				

Gives the version number of the data block selected in Pr 11.37.

11.40 SMARTCARD data checksum											
R0	Uni						NC	PT			
⇅	0 to 65,335					⇒					

Gives the checksum of the data block selected in Pr 11.37.

11.42 {0.30} Parameter copying											
RW	Txt						NC		US*		
⇅	0 to 4					⇒	nonE (())				

NOTE

If Pr 11.42 is equal to 1 or 2, this value is not transferred to the drive or saved to the EEPROM. If Pr 11.42 is set to a 3 or 4 the value is transferred.

- nonE (0) = Inactive
- rAd (1) = Read parameter set from the SMARTCARD
- Prog (2) = Programming a parameter set to the SMARTCARD
- Auto (3) = Auto save
- boot (4) = Boot mode

10.5 SMARTCARD trips

After an attempt to read, write or erase data to or from a SMARTCARD a trip may occur if there has been a problem with the command. The following trips indicate various problems as detailed in Table 10-4.

Table 10-4 Trip conditions

Trip	Diagnosis
C.Acc	SMARTCARD trip: SMARTCARD Read / Write fail
185	Check SMARTCARD is fitted / located correctly Replace SMARTCARD
C.boot	SMARTCARD trip: The menu 0 parameter modification cannot be saved to the SMARTCARD because the necessary file has not been created on the SMARTCARD
177	A write to a menu 0 parameter has been initiated via the keypad with Pr 11.42 set to auto(3) or boot(4), but the necessary file on the SMARTCARD has not been created Ensure that Pr 11.42 is correctly set and reset the drive to create the necessary file on the SMARTCARD Re-attempt the parameter write to the menu 0 parameter
C.bUSY	SMARTCARD trip: SMARTCARD can not perform the required function as it is being accessed by a Solutions Module
178	Wait for the Solutions Module to finish accessing the SMARTCARD and then re-attempt the required function
C.Chg	SMARTCARD trip: Data location already contains data
179	Erase data in data location Write data to an alternative data location
C.Cpr	SMARTCARD trip: The values stored in the drive and the values in the data block on the SMARTCARD are different
188	Press the red  reset button
C.dat	SMARTCARD trip: Data location specified does not contain any data
183	Ensure data block number is correct
C.Err	SMARTCARD trip: SMARTCARD data is corrupted
182	Ensure the card is located correctly Erase data and retry Replace SMARTCARD
C.Full	SMARTCARD trip: SMARTCARD full
184	Delete a data block or use a different SMARTCARD
C.Optn	SMARTCARD trip: Solutions Modules fitted are different between source drive and destination drive
180	Ensure correct Solutions Modules are fitted Ensure Solutions Modules are in the same Solutions Module slot Press the red  reset button
C.Prod	SMARTCARD trip: The data blocks on the SMARTCARD are not compatible with this product
175	Erase all data on the SMARTCARD by setting Pr xx.00 to 9999 and pressing the red  reset button Replace SMARTCARD
C.RdO	SMARTCARD trip: SMARTCARD has the Read only bit set
181	Enter 9777 in Pr xx.00 to allow SMARTCARD Read / Write access Ensure card is not writing to data locations 500 to 999

Table 10-4 Trip conditions

Trip	Diagnosis																												
C.rtg	SMARTCARD trip: The voltage and/or current rating of the source and destination drives are different																												
186	<p>Drive rating dependent parameters (parameters with the RA coding) are likely to have different values and ranges with drives of different voltage and current ratings. Parameters with this attribute will not be transferred to the destination drive by SMARTCARDs when the rating of the destination drive is different from the source drive and the file is a parameter file. However, with software V01.09.00 and later drive rating dependent parameters will be transferred if only the current rating is different and the file is a differences from default type file.</p> <p>Press the red  reset button</p> <p>Drive rating parameters are:</p> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>2.08</td> <td>Standard ramp voltage</td> </tr> <tr> <td>4.05/6/7, 21.27/8/9</td> <td>Current limits</td> </tr> <tr> <td>4.24</td> <td>User current maximum scaling</td> </tr> <tr> <td>5.07, 21.07</td> <td>Motor rated current</td> </tr> <tr> <td>5.09, 21.09</td> <td>Motor rated voltage</td> </tr> <tr> <td>5.10, 21.10</td> <td>Rated power factor</td> </tr> <tr> <td>5.17, 21.12</td> <td>Stator resistance</td> </tr> <tr> <td>5.18</td> <td>Switching frequency</td> </tr> <tr> <td>5.23, 21.13</td> <td>Voltage offset</td> </tr> <tr> <td>5.24, 21.14</td> <td>Transient inductance</td> </tr> <tr> <td>5.25, 21.24</td> <td>Stator inductance</td> </tr> <tr> <td>6.06</td> <td>DC injection braking current</td> </tr> <tr> <td>6.48</td> <td>Mains loss ride through detection level</td> </tr> </tbody> </table> <p>The above parameters will be set to their default values.</p>	Parameter	Function	2.08	Standard ramp voltage	4.05/6/7, 21.27/8/9	Current limits	4.24	User current maximum scaling	5.07, 21.07	Motor rated current	5.09, 21.09	Motor rated voltage	5.10, 21.10	Rated power factor	5.17, 21.12	Stator resistance	5.18	Switching frequency	5.23, 21.13	Voltage offset	5.24, 21.14	Transient inductance	5.25, 21.24	Stator inductance	6.06	DC injection braking current	6.48	Mains loss ride through detection level
Parameter	Function																												
2.08	Standard ramp voltage																												
4.05/6/7, 21.27/8/9	Current limits																												
4.24	User current maximum scaling																												
5.07, 21.07	Motor rated current																												
5.09, 21.09	Motor rated voltage																												
5.10, 21.10	Rated power factor																												
5.17, 21.12	Stator resistance																												
5.18	Switching frequency																												
5.23, 21.13	Voltage offset																												
5.24, 21.14	Transient inductance																												
5.25, 21.24	Stator inductance																												
6.06	DC injection braking current																												
6.48	Mains loss ride through detection level																												
C.Type	SMARTCARD trip: SMARTCARD parameter set not compatible with drive																												
187	<p>Press the red  reset button</p> <p>Ensure destination drive type is the same as the source parameter file drive type</p>																												

Table 10-5 SMARTCARD status indications

Lower display	Description
boot	A parameter set is being transferred from the SMARTCARD to the drive during power-up. For further information, please refer to section 10.2.4
cArd	The drive is writing a parameter set to the SMARTCARD during power-up For further information, please refer to section 10.2.3 <i>Auto saving parameter changes (Pr 11.42 = Auto (3))</i>

11 Commissioning software tools

When commissioning the elevator, there are number of PC tools available which permit the set-up, monitoring and optimization of the Unidrive SP:


- CTSofT
- CTScope
- Elevator-SP

All of these PC programs assist with the commissioning of the Unidrive SP Elevator Solution Software. Standard parameter files that may have been available from previous applications can be downloaded, or the final parameter files can be uploaded for future applications. Using CTScope (see CTScope below), waveforms can be taken during commissioning and saved for future reference.

11.1 CTSofT

CTSofT allows a project for an application to be set-up and from this all parameters in the drive can be programmed with either a pre-defined parameter file or configured and saved by the user. The project can be generated manually or through use of the available set-up wizard.

Figure 11-1 CTSofT main screen



Additional features also available in CTSofT are


- Drive properties and summary screen
- Detailed parameter differences from default
- Detailed parameter descriptions
- Block diagrams
- Terminal configurations
- Monitoring features
- Solutions Modules support and configuration
- Help files

11.2 CTScope

CTScope is a PC based software oscilloscope that includes all features normally associated with an oscilloscope. The oscilloscope features include:

- 4 channels
- Adjustable time-base and scaling
- Trigger
- Cursors
- Zoom feature
- Save and recall waveforms
- Sampling rate down to 1ms
- Connection via Unidrive SP RJ-45 or via CT-Net
- Single or multiple drives can be monitored simultaneously on CT-Net

Figure 11-2 CT Scope main screen



11.3 Elevator-SP


Elevator-SP is also a PC based software program that includes features which allow the Unidrive SP to be set-up (parameter download) and which also has an oscilloscope feature included.

Figure 11-3 Elevator-SP



There are however additional features which are specific to the elevator set-up included with this PC based software program. For example the following screen provides all the required set-up parameters for the creep-to-floor positioning.


Figure 11-4 Creep-to-floor profile and parameters



Other custom screens available for set-up include

- Elevator installation parameters
- Speed set points
- Creep-to-floor, direct-to-floor
- Floor sensor control
- Inertia and load compensation
- Error detection

Figure 11-5 LiftSP Oscilloscope



12 Diagnostics

12.1 Display

The integral display located on the drive, provides information about the current drive status, which are grouped under the following three headings:

- Trip indications
- Alarm indications
- Status indications



WARNING Users must not attempt to repair a drive if it is faulty, nor carry out fault diagnosis other than through the use of the diagnostic features described in this chapter. If a drive is faulty, it must be returned to an authorized Control Techniques distributor for repair.

If the drive trips, the output of the drive is disabled so that the drive stops controlling the motor. The lower display indicates that a trip has occurred and the upper display shows the trip. If this is a multi-module drive and a power module has indicated a trip, then the upper display will alternate between the trip string and the module number.

Figure 12-1 Keypad status modes





Table 12-1 Example trip description

Trip	Diagnosis
OI.AC	Instantaneous output over current detected: peak output current greater than 225%
3	Acceleration / deceleration rate is too short. If seen during autotune reduce voltage boost Pr 5.15 Check for short circuit on output cabling Check integrity of motor insulation Check feedback device wiring Check feedback device mechanical coupling Check feedback signals are free from noise Is motor cable length within limits for that frame size? Reduce the values in speed loop gain parameters – Pr 3.10, Pr 3.11 and Pr 3.12 (closed loop vector and servo modes only) Has offset measurement test been completed? (servo mode only) Reduce the values in current loop gain parameters - Pr 4.13 and Pr 4.14 (closed loop vector and servo modes only)

Figure 12-2 Location of the status LED



Possible trips are listed alphabetically in Table 12.4 on page 153, based on the trip indication shown on the drive display. If a display is not used, the drive LED Status indicator will flash if the drive has tripped. The trips indication can be read in Pr 10.20. Trip numbers are listed in numerical order in Table 12.4 on page 153.

Example:

1. Trip code 3 is read from Pr 10.20 via serial communications.
2. Checking Table 12-1 shows Trip 3 is an OI.AC trip.

Figure 12-3



3. Look up OI.AC in Table 12.4 on page 153
4. Perform checks detailed under Diagnosis.

12.2 Elevator specific diagnostics

This section covers specific diagnostics related to the Elevator Solution Software (SM-Applications, SM-Applications Lite) which is required for the Unidrive SP elevator solution

Table 12-2 Numerical list of trip numbers

Trip	Diagnosis
t070 Speed error trip	Excessive speed error detected
t071 Distance error trip	Excessive distance error detected Not active for open loop operations
t072 Internal Secure Disable trip	This trip is generated after 3 seconds if after disabling the drive 25% motor current is still detected.
t073 Temperature trip	Drive temperature drops below 0°C (level defined in Pr 70.81).
t074 Fast disable input defect	If a Fast disable input is not switched according to the control state (opened or closed) in 3 seconds this trip is generated.
t075 Secure Disable input defect	If the Secure Disable (SD) input on control terminal 31 is not switched according to the control state (opened or closed) in 3 seconds this trip is generated.
t076 Motor fluxed detection trip	Motor not fluxed above defined threshold
t077 Motor phase loss trip	Motor phase loss due to intermittent or broken connection.
t078 Motor contactor monitor	The motor contactor monitor auxiliary contacts If these do not switch as required the t078 trip will become active
t079 Software version trip	If the Fast disable input is used but is not supported by the drive this is detected through a software version check (Pr 11.29 ≥ 1.10.).
t080 Inverted encoder trip	Detected inverted orientation of the encoder from the following error detection.

12.3 Error detection

The following section covers in detail the error detection features provided in the elevator software.

12.3.1 Speed error detection t070

Open loop

For open loop mode the speed error detection is activated once the drive enters current limit operation resulting in the t070 trip being generated after the time defined in Pr **0.26[4]**, Pr **19.24** (2s default). Pr **0.26[4]**, Pr **19.24** is used to define the allowable time to operate in current limit, selecting very high values can result in the speed error detection being disabled.

Closed loop

The speed error is calculated from the difference between the ramp speed Pr **19.03** and the actual speed in **F49**, Pr **0.34[0]**, Pr **19.02**. The speed error is then compared with the user defined speed threshold set in Pr **0.26[4]**, Pr **19.24**. If the threshold is exceeded for more than 100ms a t070 trip is generated. The speed error during one travel is displayed in Pr **0.25[4]**, Pr **18.07** independent of the activation of the speed error detection. The display is reset to 0 at each start.

NOTE

The speed error detection can be disabled by setting Pr **0.26[4]**, Pr **19.24** = 0, but doing so will mean that the system will continue to operate with a constant speed error and possible system fault. Where possible the threshold should be increased before disabling the error detection.

12.3.2 Distance error detection t071

The distance error detection is the integral of the difference between the ramp speed Pr **19.03** and the actual speed in **F49**, Pr **0.34[0]**, Pr **19.02** and is active for closed loop operation.

The calculated distance error is compared to the user defined distance error threshold in Pr **0.28[4]**, Pr **19.18**. If the actual distance error exceeds the user defined distance error a t071 trip is generated. The distance error during one travel is displayed in Pr **0.27[4]**, Pr **18.06** independent of the activation of the distance error detection being enabled. The distance error is reset to zero at the start of each travel.


NOTE

The distance error detection can be disabled by setting Pr **0.28[4]**, Pr **19.18** = 0, but doing so will mean that the system will continue to operate with a constant speed error and possible system fault. Where possible the threshold should be increased before disabling the error detection.

NOTE

Distance error detection is only active for closed loop operation.

Figure 12-4 Speed and Distance error detection



Possible causes for the Speed error t070 and Distance error t071 detection trips can be due to the following

Errors with motor connections

1. Phase rotation

Encoder feedback fault

2. Phases rotated
3. Induced noise
4. Encoder feedback failure

Drive set-up errors

5. Encoder feedback parameter set-up
6. Motor map parameter set-up
7. Phase offset, PM motors rotating auto tune required
8. Gains settings resulting in instability

12.3.3 Secure disable - Fast disable input t072, t074, t075

Both the Secure disable and Fast disable inputs are monitored during operation and a trip generated when a fault condition occurs to ensure correct operation of the elevator. The trips generated are as follows:

t072, Internal secure disable trip

The t072 trip is generated when the Secure disable at control terminal T.31 of the drive is disabled but there is still current present on the motor, which indicates a possible fault internally on the drive, which has resulted in the output of the drive not being disabled.

Under a fault condition check the sequencing of the Secure disable input on control terminal T.31.

t074, Fast disable input defect

The t074 trip monitors the Fast disable input if configured on the drives control terminal. To configure the Fast disable a digital input is routed to Pr **6.29** in the drive. The digital input which is selected for the Fast disable is then automatically monitored and under a fault condition where the digital input is not switched in 3 seconds as expected, the t074 trip is generated.

Setting the digital input from 6.29 to 00.00 will disable the trip and the Fast disable input.

t075, Secure disable input defect

The t075 trip is generated when the Secure disable on control terminal T.31 of the drive which is monitored does not switch state as expected in 3 seconds. This indicates a possible fault in the Secure disable circuit of the system and the trip t075 is generated.

Under a fault condition check the Secure disable control connections between the drive and the elevator controller.

12.3.4 Temperature trip t073

The elevator software monitors the drive temperatures if these exceed the lower limit set in Pr **70.81** (default 0°C) a t073 will be generated. This trip is present to protect the drive when starting in extreme cold conditions.

If the t073 trip is experienced during start up of the elevator a pre heater will be required to ensure the minimum temperature for operation is greater than 0°C.

In addition to the t073 trip there is also a motor thermistor trip for more details refer to section 5.2 *Motor thermistor input* on page 54.

12.3.5 Motor fluxed t076

During the start sequence of the elevator the elevator software monitors the magnetization current Pr **0.14[4]**, Pr **20.07** in the motor and compares this to a user defined threshold Pr **0.29[2]**, Pr **18.23**. If the magnetization current does not reach or exceed the threshold a trip is generated and the start sequence stopped. This ensures that the brake will not be lifted unless the motor is fully magnetized. Detection is active for the first 3 seconds after enable.

If a trip is encountered check motor connections, motor map settings and motor contactor control.

12.3.6 Motor phase loss t077

The motor phase loss detection can be enabled and disabled with Pr **19.43**. This feature monitors the motor voltage and if during start, after 200ms more than 66% of the nominal motor voltage required is not present, the t077 trip is generated.

Check motor map settings, motor connections at both drive and motor, output motor contactor connections.

12.3.7 Motor contactor monitor t078

The motor contactor monitor uses an auxiliary contact on the motor contactors that is used to feed a signal back to the drive. A digital input is used to route this signal to Pr **19.33**. The motor contactor monitor is enabled with Pr **19.40** = ON.

If experiencing a t078 trip, check both the motor contactor or contactors and also the auxiliary feedback to the drives control terminal. Ensure the digital input is routed correctly to Pr **19.33**.

12.3.8 Software version t079

The software trip t079 is available to check the elevator software where a Fast disable input has been set-up and the software version of the drive is incompatible, i.e the drive software must be greater than 1.10.

If experiencing the t079 trip the drive software must be re-programmed or the Fast disable input deactivated by setting the digital input routed to Pr **6.29** to 00.00.

12.3.9 Inverted encoder connections t080

The t080 trip indicates that either the encoder feedback signals or the motor power connections have been rotated. This results in the motor rotating in one direction and the feedback incrementing in the opposite direction. The trip is generated by monitoring the following error and if the following error is greater than the actual ramp speed, the trip is generated.

Check both the motor and encoder feedback connections.

12.4 Unidrive SP trip codes

Trip	Diagnosis
br.th	Internal braking resistor thermistor temperature monitoring fail (size 0 only)
10	If no internal brake resistor is installed, set Pr 0.51 (or Pr 10.37) to 8 to disable this trip. If an internal brake resistor is installed: <ul style="list-style-type: none"> • Ensure that the internal braking resistor thermistor is connected correctly • Ensure that the fan in the drive is working correctly • Replace the internal braking resistor
C.Acc	SMARTCARD trip: SMARTCARD Read / Write fail
185	Check SMARTCARD is installed / located correctly Ensure SMARTCARD is not writing data to data location 500 to 999 Replace SMARTCARD
C.boot	SMARTCARD trip: The menu 0 parameter modification cannot be saved to the SMARTCARD because the necessary file has not been created on the SMARTCARD
177	A write to a menu 0 parameter has been initiated via the keypad with Pr 11.42 set to auto(3) or boot(4), but the necessary file on the SMARTCARD has not been created Ensure that Pr 11.42 is correctly set and reset the drive to create the necessary file on the SMARTCARD Re-attempt the parameter write to the menu 0 parameter
C.bUSY	SMARTCARD trip: SMARTCARD can not perform the required function as it is being accessed by a Solutions Module
178	Wait for the Solutions Module to finish accessing the SMARTCARD and then re-attempt the required function
C.Chg	SMARTCARD trip: Data location already contains data
179	Erase data in data location Write data to an alternative data location
C.cPr	SMARTCARD trip: The values stored in the drive and the values in the data block on the SMARTCARD are different
188	Press the red  reset button
C.dAt	SMARTCARD trip: Data location specified does not contain any data
183	Ensure data block number is correct
C.Err	SMARTCARD trip: SMARTCARD data is corrupted
182	Ensure the card is located correctly Erase data and retry Replace SMARTCARD
C.Full	SMARTCARD trip: SMARTCARD full
184	Delete a data block or use different SMARTCARD
cL2	Analog input 2 current loss (current mode)
28	Check analog input 2 (terminal 7) current signal is present (4-20mA, 20-4mA)
cL3	Analog input 3 current loss (current mode)
29	Check analog input 3 (terminal 8) current signal is present (4-20mA, 20-4mA)
CL.bit	Trip initiated from the control word (Pr 6.42)
35	Disable the control word by setting Pr 6.43 to 0 or check setting of Pr 6.42
ConF.P	The number of power modules installed no longer matches the value stored in Pr 11.35
111	Ensure that all power modules are correctly connected Ensure that all power modules have powered up correctly Ensure that the value in Pr 11.35 matches the number of power modules connected
C.OPtn	SMARTCARD trip: Solutions Modules installed are different between source drive and destination drive
180	Ensure correct Solutions Modules are installed Ensure Solutions Modules are in the same Solutions Module slot Press the red  reset button
C.Prod	SMARTCARD trip: The data blocks on the SMARTCARD are not compatible with this product
175	Erase all data on the SMARTCARD by setting Pr xx.00 to 9999 and pressing the red  reset button Replace SMARTCARD
C.rdo	SMARTCARD trip: SMARTCARD has the Read Only bit set
181	Enter 9777 in Pr xx.00 to allow SMARTCARD Read / Write access Ensure the drive is not writing to data locations 500 to 999 on the card

Trip	Diagnosis																												
C.rtg	SMARTCARD trip: The voltage and/or current rating of the source and destination drives are different																												
186	<p>Drive rating dependent parameters (parameters with the RA coding) are likely to have different values and ranges with drives of different voltage and current ratings. Parameters with this attribute will not be transferred to the destination drive by SMARTCARDs when the rating of the destination drive is different from the source drive and the file is a parameter file. However, with software V01.09.00 and later drive rating dependent parameters will be transferred if only the current rating is different and the file is a differences from default type file.</p> <p>Press the red  reset button</p> <p>Drive rating parameters are:</p> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>2.08</td> <td>Standard ramp voltage</td> </tr> <tr> <td>4.05/6/7, 21.27/8/9</td> <td>Current limits</td> </tr> <tr> <td>4.24</td> <td>User current maximum scaling</td> </tr> <tr> <td>5.07, 21.07</td> <td>Motor rated current</td> </tr> <tr> <td>5.09, 21.09</td> <td>Motor rated voltage</td> </tr> <tr> <td>5.10, 21.10</td> <td>Rated power factor</td> </tr> <tr> <td>5.17, 21.12</td> <td>Stator resistance</td> </tr> <tr> <td>5.18</td> <td>Switching frequency</td> </tr> <tr> <td>5.23, 21.13</td> <td>Voltage offset</td> </tr> <tr> <td>5.24, 21.14</td> <td>Transient inductance</td> </tr> <tr> <td>5.25, 21.24</td> <td>Stator inductance</td> </tr> <tr> <td>6.06</td> <td>DC injection braking current</td> </tr> <tr> <td>6.48</td> <td>Line power supply loss ride through detection level</td> </tr> </tbody> </table> <p>The above parameters will be set to their default values.</p>	Parameter	Function	2.08	Standard ramp voltage	4.05/6/7, 21.27/8/9	Current limits	4.24	User current maximum scaling	5.07, 21.07	Motor rated current	5.09, 21.09	Motor rated voltage	5.10, 21.10	Rated power factor	5.17, 21.12	Stator resistance	5.18	Switching frequency	5.23, 21.13	Voltage offset	5.24, 21.14	Transient inductance	5.25, 21.24	Stator inductance	6.06	DC injection braking current	6.48	Line power supply loss ride through detection level
Parameter	Function																												
2.08	Standard ramp voltage																												
4.05/6/7, 21.27/8/9	Current limits																												
4.24	User current maximum scaling																												
5.07, 21.07	Motor rated current																												
5.09, 21.09	Motor rated voltage																												
5.10, 21.10	Rated power factor																												
5.17, 21.12	Stator resistance																												
5.18	Switching frequency																												
5.23, 21.13	Voltage offset																												
5.24, 21.14	Transient inductance																												
5.25, 21.24	Stator inductance																												
6.06	DC injection braking current																												
6.48	Line power supply loss ride through detection level																												
C.TyP	SMARTCARD trip: SMARTCARD parameter set not compatible with drive																												
187	<p>Press the reset button</p> <p>Ensure destination drive type is the same as the source parameter file drive type</p>																												
dESt	Two or more parameters are writing to the same destination parameter																												
199	Set Pr xx.00 = 12001 check all visible parameters in the menus for duplication																												
EEF	EEPROM data corrupted - Drive mode becomes open loop and serial comms will timeout with remote keypad on the drive RS485 comms port.																												
31	This trip can only be cleared by loading default parameters and saving parameters																												
EnC1	Drive encoder trip: Encoder power supply overload																												
189	<p>Check encoder power supply wiring and encoder current requirement</p> <p>Maximum current = 200mA @ 15V, or 300mA @ 8V and 5V</p>																												
EnC2	Drive encoder trip: Wire break (Drive encoder terminals 1 & 2, 3 & 4, 5 & 6)																												
190	<p>Check cable continuity</p> <p>Check wiring of feedback signals is correct</p> <p>Check encoder power supply is set correctly in Pr 3.36</p> <p>Replace feedback device</p> <p>If wire break detection on the main drive encoder input is not required, set Pr 3.40 = 0 to disable the Enc2 trip</p>																												
EnC3	Drive encoder trip: Phase offset incorrect while running																												
191	<p>Check the encoder signal for noise</p> <p>Check encoder shielding</p> <p>Check the integrity of the encoder mechanical mounting</p> <p>Repeat the offset measurement test</p>																												
EnC4	Drive encoder trip: Feedback device comms failure																												
192	<p>Ensure encoder power supply is correct</p> <p>Ensure baud rate is correct</p> <p>Check encoder wiring</p> <p>Replace feedback device</p>																												
EnC5	Drive encoder trip: Checksum or CRC error																												
193	<p>Check the encoder signal for noise</p> <p>Check the encoder cable shielding</p> <p>With EnDat encoders, check the comms resolution and/or carry out the auto-configuration Pr 3.41</p>																												
EnC6	Drive encoder trip: Encoder has indicated an error																												
194	<p>Replace feedback device</p> <p>With SSI encoders, check the wiring and encoder supply setting</p>																												

Trip	Diagnosis
EnC7	Drive encoder trip: Initialization failed
195	Re-set the drive Check the correct encoder type is entered into Pr 3.38 Check encoder wiring Check encoder power supply is set correctly Carry out the auto-configuration Pr 3.41 Replace feedback device
EnC8	Drive encoder trip: Auto configuration on power-up has been requested and failed
196	Change the setting of Pr 3.41 to 0 and manually enter the drive encoder turns (Pr 3.33) and the equivalent number of lines per revolution (Pr 3.34) Check the comms resolution
EnC9	Drive encoder trip: Position feedback selected is selected from a Solutions Module slot which does not have a speed / position feedback Solutions Module installed
197	Check setting of Pr 3.26 (or Pr 21.21 if the second motor parameters have been enabled)
EnC10	Drive encoder trip: Servo mode phasing failure because encoder phase angle (Pr 3.25 or Pr 21.20) is incorrect
198	Check the encoder wiring. Perform an autotune to measure the encoder phase angle or manually enter the correct phase angle into Pr 3.25 (or Pr 21.20). Spurious Enc10 trips can be seen in very dynamic applications. This trip can be disabled by setting the overspeed threshold in Pr 3.08 to a value greater than zero. Caution should be used in setting the over speed threshold level as a value which is too large may mean that an encoder fault will not be detected.
Enc11	Drive encoder trip: A failure has occurred during the alignment of the analog signals of a SINCOS encoder with the digital count derived from the sine and cosine waveforms and the comms position (if applicable). This fault is usually due to noise on the sine and cosine signals.
161	Check encoder cable shield. Examine sine and cosine signals for noise.
Enc12	Drive encoder trip: Hiperface encoder - The encoder type could not be identified during auto-configuration
162	Check encoder type can be auto-configured. Check encoder wiring. Enter parameters manually.
Enc13	Drive encoder trip: EnDat encoder - The number of encoder turns read from the encoder during auto-configuration is not a power of 2
163	Select a different type of encoder.
Enc14	Drive encoder trip: EnDat encoder - The number of comms bits defining the encoder position within a turn read from the encoder during auto-configuration is too large.
164	Select a different type of encoder. Faulty encoder.
Enc15	Drive encoder trip: The number of periods per revolution calculated from encoder data during auto-configuration is either less than 2 or greater than 50,000.
165	Linear motor pole pitch / encoder ppr set up is incorrect or out of parameter range i.e. Pr 5.36 = 0 or Pr 21.31 = 0. Faulty encoder.
Enc16	Drive encoder trip: EnDat encoder - The number of comms bits per period for a linear encoder exceeds 255.
166	Select a different type of encoder. Faulty encoder.
Enc17	Drive encoder trip: The periods per revolution obtained during auto-configuration for a rotary SINCOS encoder is not a power of two.
167	Select a different type of encoder. Faulty encoder.
ENP.Er	Data error from electronic nameplate stored in selected position feedback device
176	Replace feedback device
Et	External trip
6	Check terminal 31 signal Check value of Pr 10.32 Enter 12001 in Pr xx.00 and check for parameter controlling Pr 10.32 Ensure Pr 10.32 or Pr 10.38 (=6) are not being controlled by serial comms
HF01	Data processing error: CPU address error
	Hardware fault - return drive to supplier

Trip	Diagnosis
HF02	Data processing error: DMAC address error
	Hardware fault - return drive to supplier
HF03	Data processing error: Illegal instruction
	Hardware fault - return drive to supplier
HF04	Data processing error: Illegal slot instruction
	Hardware fault - return drive to supplier
HF05	Data processing error: Undefined exception
	Hardware fault - return drive to supplier
HF06	Data processing error: Reserved exception
	Hardware fault - return drive to supplier
HF07	Data processing error: Watchdog failure
	Hardware fault - return drive to supplier
HF08	Data processing error: Level 4 crash
	Hardware fault - return drive to supplier
HF09	Data processing error: Heap overflow
	Hardware fault - return drive to supplier
HF10	Data processing error: Router error
	Hardware fault - return drive to supplier
HF11	Data processing error: Access to EEPROM failed
	Hardware fault - return drive to supplier
HF12	Data processing error: Main program stack overflow
	Hardware fault - return drive to supplier
HF13	Data processing error: Software incompatible with hardware
	Hardware or software fault - return drive to supplier
HF17	Multi-module system thermistor short circuit or open circuit
217	Hardware fault - return drive to supplier
HF18	Multi-module system interconnect cable error
218	Hardware fault - return drive to supplier
HF19	Temperature feedback multiplexing failure
219	Hardware fault - return drive to supplier
HF20	Power stage recognition: serial code error
220	Hardware fault - return drive to supplier
HF21	Power stage recognition: unrecognized frame size
221	Hardware fault - return drive to supplier
HF22	Power stage recognition: multi module frame size mismatch
222	Hardware fault - return drive to supplier
HF23	Power stage recognition: multi module voltage or current rating mismatch
223	Hardware fault - return drive to supplier
HF24	Power stage recognition: unrecognized drive size
224	Hardware fault - return drive to supplier
HF25	Current feedback offset error
225	Hardware fault - return drive to supplier
HF26	Soft start relay failed to close, soft start monitor failed or braking IGBT short circuit at power-up
226	Hardware fault - return drive to supplier
HF27	Power stage thermistor 1 fault
227	Hardware fault - return drive to supplier

Trip	Diagnosis
HF28	Power stage thermistor 2 fault, or internal fan fault (size 3)
228	Hardware fault - return drive to supplier
HF29	Control board thermistor fault
229	Hardware fault - return drive to supplier
HF30	DCCT wire break trip from power module
230	Hardware fault - return drive to supplier
HF31	Internal capacitor bank fan failure (size 4 and larger) or a module has not powered up in a multi-module parallel drive
231	Check the AC or DC power supply to all modules in a multi-module parallel drive If the AC or DC power supply is present, or if this is a single drive, then there is a hardware fault - return drive to the supplier
HF32	Power stage - Identification and trip information serial code error
232	Hardware fault - return drive to the supplier
It.AC	Output current overload timed out (I^2t) - accumulator value can be seen in Pr 4.19
20	Ensure the load is not jammed / sticking Check the load on the motor has not changed If seen during an autotune in servo mode, ensure that the motor rated current Pr 0.46 (Pr 5.07) or Pr 21.07 is \leq Heavy Duty current rating of the drive Tune the rated speed parameter (closed loop vector only) Check feedback device signal for noise Check the feedback device mechanical coupling
It.br	Braking resistor overload timed out (I^2t) – accumulator value can be seen in Pr 10.39
19	Ensure the values entered in Pr 10.30 and Pr 10.31 are correct Increase the power rating of the braking resistor and change Pr 10.30 and Pr 10.31 If an external thermal protection device is being used and the braking resistor software overload is not required, set Pr 10.30 or Pr 10.31 to 0 to disable the trip
L.SYnC	Drive failed to synchronize to the supply voltage in Regen mode
39	Refer to the <i>Diagnostics</i> chapter in the <i>Unidrive SP Regen Installation Guide</i> .
O.CtL	Drive control board over temperature
23	Check enclosure / drive fans are still functioning correctly Check enclosure ventilation paths Check enclosure door filters Check ambient temperature Reduce drive switching frequency
O.ht1	Power device over temperature based on thermal model
21	Reduce drive switching frequency Reduce duty cycle Decrease acceleration / deceleration rates Reduce motor load
O.ht2	Heatsink over temperature
22	Check enclosure / drive fans are still functioning correctly Check enclosure ventilation paths Check enclosure door filters Increase ventilation Decrease acceleration / deceleration rates Reduce drive switching frequency Reduce duty cycle Reduce motor load
Oht2.P	Power module heatsink over temperature
105	Check enclosure / drive fans are still functioning correctly Check enclosure ventilation paths Check enclosure door filters Increase ventilation Decrease acceleration / deceleration rates Reduce drive switching frequency Reduce duty cycle Reduce motor load

Trip	Diagnosis
O.ht3	Drive over-temperature based on thermal model
27	The drive will attempt to stop the motor before tripping. If the motor does not stop in 10s the drive trips immediately. Check enclosure / drive fans are still functioning correctly Check enclosure ventilation paths Check enclosure door filters Increase ventilation Decrease acceleration / deceleration rates Reduce duty cycle Reduce motor load
Oht4.P	Power module rectifier over temperature or input snubber resistor over temperature (size 4 and above)
102	Check for supply imbalance Check for supply disturbance such as notching from a DC drive Check enclosure / drive fans are still functioning correctly Check enclosure ventilation paths Check enclosure door filters Increase ventilation Decrease acceleration / deceleration rates Reduce drive switching frequency Reduce duty cycle Reduce motor load
OI.AC	Instantaneous output over current detected: peak output current greater than 225%
3	Acceleration /deceleration rate is too short. If seen during autotune reduce voltage boost Pr 5.15 Check for short circuit on output cabling Check integrity of motor insulation Check feedback device wiring Check feedback device mechanical coupling Check feedback signals are free from noise Is motor cable length within limits for that frame size? Reduce the values in speed loop gain parameters – Pr 3.10 , Pr 3.11 and Pr 3.12 (closed loop vector and servo modes only) Has offset measurement test been completed? (servo mode only) Reduce the values in current loop gain parameters - Pr 4.13 and Pr 4.14 (closed loop vector and servo modes only)
OIAC.P	Power module over current detected from the module output currents
104	Acceleration /deceleration rate is too short. If seen during autotune reduce voltage boost Pr 5.15 Check for short circuit on output cabling Check integrity of motor insulation Check feedback device wiring Check feedback device mechanical coupling Check feedback signals are free from noise Is motor cable length within limits for that frame size? Reduce the values in speed loop gain parameters – Pr 3.10 , Pr 3.11 and Pr 3.12 (closed loop vector and servo modes only) Has offset measurement test been completed? (servo mode only) Reduce the values in current loop gain parameters - Pr 4.13 and Pr 4.14 (closed loop vector and servo modes only)
OI.br	Braking transistor over-current detected: short circuit protection for the braking transistor activated
4	Check braking resistor wiring Check braking resistor value is greater than or equal to the minimum resistance value Check braking resistor insulation
Oibr.P	Power module braking IGBT over current
103	Check braking resistor wiring Check braking resistor value is greater than or equal to the minimum resistance value Check braking resistor insulation
OldC.P	Power module over current detected from IGBT on state voltage monitoring
109	Vce IGBT protection activated. Check motor and cable insulation.
O.Ld1	Digital output overload: total current drawn from 24V supply and digital outputs exceeds 200mA
26	Check total load on digital outputs (terminals 24,25,26)and +24V rail (terminal 22)
O.SPd	Motor speed has exceeded the over speed threshold
7	Increase the over speed trip threshold in Pr 3.08 (closed loop vector and servo modes only) Speed has exceeded 1.2 x Pr 1.06 or Pr 1.07 (open loop mode) Reduce the speed loop P gain (Pr 3.10) to reduce the speed overshoot (closed loop vector and servo modes only)

Trip	Diagnosis															
OV	DC bus voltage has exceeded the peak level or the maximum continuous level for 15 seconds															
2	<p>Increase deceleration ramp (Pr 0.04) Decrease braking resistor value (staying above the minimum value) Check nominal AC supply level Check for supply disturbances which could cause the DC bus to rise – voltage overshoot after supply recovery from a notch induced by DC drives Check motor insulation</p> <table border="1"> <thead> <tr> <th>Drive voltage rating</th> <th>Peak voltage</th> <th>Maximum continuous voltage level (15s)</th> </tr> </thead> <tbody> <tr> <td>200</td> <td>415</td> <td>410</td> </tr> <tr> <td>400</td> <td>830</td> <td>815</td> </tr> <tr> <td>575</td> <td>990</td> <td>970</td> </tr> <tr> <td>690</td> <td>1190</td> <td>1175</td> </tr> </tbody> </table> <p>If the drive is operating in low voltage DC mode the overvoltage trip level is 1.45 x Pr 6.46.</p>	Drive voltage rating	Peak voltage	Maximum continuous voltage level (15s)	200	415	410	400	830	815	575	990	970	690	1190	1175
Drive voltage rating	Peak voltage	Maximum continuous voltage level (15s)														
200	415	410														
400	830	815														
575	990	970														
690	1190	1175														
OV.P	Power module DC bus voltage has exceeded the peak level or the maximum continuous level for 15 seconds															
106	<p>Increase deceleration ramp (Pr 0.04) Decrease braking resistor value (staying above the minimum value) Check nominal AC supply level Check for supply disturbances which could cause the DC bus to rise – voltage overshoot after supply recovery from a notch induced by DC drives Check motor insulation</p> <table border="1"> <thead> <tr> <th>Drive voltage rating</th> <th>Peak voltage</th> <th>Maximum continuous voltage level (15s)</th> </tr> </thead> <tbody> <tr> <td>200</td> <td>415</td> <td>410</td> </tr> <tr> <td>400</td> <td>830</td> <td>815</td> </tr> <tr> <td>575</td> <td>990</td> <td>970</td> </tr> <tr> <td>690</td> <td>1190</td> <td>1175</td> </tr> </tbody> </table> <p>If the drive is operating in low voltage DC mode the overvoltage trip level is 1.45 x Pr 6.46.</p>	Drive voltage rating	Peak voltage	Maximum continuous voltage level (15s)	200	415	410	400	830	815	575	990	970	690	1190	1175
Drive voltage rating	Peak voltage	Maximum continuous voltage level (15s)														
200	415	410														
400	830	815														
575	990	970														
690	1190	1175														
PA.d	Keypad has been removed when the drive is receiving the speed reference from the keypad															
34	<p>Install keypad and reset Change speed reference selector to select speed reference from another source</p>															
PH	AC voltage input phase loss or large supply imbalance detected															
32	<p>Ensure all three phases are present and balanced Check input voltage levels are correct (at full load)</p> <p>NOTE</p> <p>Load level must be between 50 and 100% for the drive to trip under phase loss conditions. The drive will attempt to stop the motor before this trip is initiated.</p>															
PH.P	Power module phase loss detection															
107	<p>Ensure all three phases are present and balanced Check input voltage levels are correct (at full load)</p>															
PS	Internal power supply fault															
5	<p>Remove any Solutions Modules and reset Hardware fault - return drive to supplier</p>															
PS.10V	10V user power supply current greater than 10mA															
8	<p>Check wiring to terminal 4 Reduce load on terminal 4</p>															
PS.24V	24V internal power supply overload															
9	<p>The total user load of the drive and Solutions Modules has exceeded the internal 24V power supply limit. The user load consists of the drive's digital outputs, the SM-I/O Plus digital outputs, the drive's main encoder supply, and the SM-Universal Encoder Plus encoder supply, and the SM-Encoder Output Plus encoder supply.</p> <ul style="list-style-type: none"> Reduce load and reset Provide an external 24V >50W power supply Remove any Solutions Modules and reset 															
PS.P	Power module power supply fail															
108	<p>Remove any Solutions Modules and reset Hardware fault - return drive to supplier</p>															
PSAVE.Er	Power down save parameters in the EEPROM are corrupt															
37	<p>Indicates that the power was removed when power down save parameters were being saved. The drive will revert back to the power down parameter set that was last saved successfully. Perform a user save (Pr xx.00 to 1000 or 1001 and reset the drive) or power down the drive normally to ensure this trip does or occur the next time the drive is powered up.</p>															

Trip	Diagnosis
rS	Failure to measure resistance during autotune or when starting in open loop vector mode 0 or 3
33	Check motor power connection continuity
SAVE.Er	User save parameters in the EEPROM are corrupt
36	Indicates that the power was removed when user parameters were being saved. The drive will revert back to the user parameter set that was last saved successfully. Perform a user save (Pr xx.00 to 1000 or 1001 and reset the drive) to ensure this trip does or occur the next time the drive is powered up.
SCL	Drive RS485 serial comms loss to remote keypad
30	Reinstall the cable between the drive and keypad Check cable for damage Replace cable Replace keypad
SLX.dF	Solutions Module slot X trip: Solutions Module type installed in slot X changed
204,209,214	Save parameters and reset

Trip	Diagnosis			
SLX.Er	Solutions Module slot X trip: Solutions Module in slot X has detected a fault			
202,207,212	Feedback module category			
	Check value in Pr 15/16/17.50 . The following table lists the possible error codes for the SM-Universal Encoder Plus, SM-Encoder Output Plus, SM-Encoder Plus and SM-Resolver. See the <i>Diagnostics</i> section in the relevant Solutions Module User Guide for more information.			
	Error code	Module	Trip Description	Diagnostic
	0	All	No trip	No fault detected
	1	SM-Universal Encoder Plus & SM-Encoder Output Plus	Encoder power supply overload	Check encoder power supply wiring and encoder current requirement Maximum current = 200mA @ 15V, or 300mA @ 8V and 5V
		SM-Resolver	Excitation output short circuit	Check the excitation output wiring.
	2	SM-Universal Encoder Plus & SM-Resolver	Wire break	Check cable continuity Check wiring of feedback signals is correct Check supply voltage or excitation output level Replace feedback device
	3	SM-Universal Encoder Plus	Phase offset incorrect while running	Check the encoder signal for noise Check encoder shielding Check the integrity of the encoder mechanical mounting Repeat the offset measurement test
	4	SM-Universal Encoder Plus	Feedback device communications failure	Ensure encoder power supply is correct Ensure baud rate is correct Check encoder wiring Replace feedback device
	5	SM-Universal Encoder Plus	Checksum or CRC error	Check the encoder signal for noise Check the encoder cable shielding
	6	SM-Universal Encoder Plus	Encoder has indicated an error	Replace encoder
	7	SM-Universal Encoder Plus	Initialisation failed	Check the correct encoder type is entered into Pr 15/16/17.15 Check encoder wiring Check supply voltage level Replace feedback device
	8	SM-Universal Encoder Plus	Auto configuration on power-up has been requested and failed	Change the setting of Pr 15/16/17.18 and manually enter the number of turns bits (Pr 15/16/17.09) and the equivalent number of lines per revolution (Pr 15/16/17.10) and the single turn comms bits (Pr 15/16/17.11)
	9	SM-Universal Encoder Plus	Motor thermistor trip	Check motor temperature Check thermistor continuity
	10	SM-Universal Encoder Plus	Motor thermistor short circuit	Check motor thermistor wiring Replace motor / motor thermistor
	11	SM-Universal Encoder Plus	Failure of the sincos analog position alignment during encoder initialisation	Check encoder cable shield. Examine sine and cosine signals for noise.
		SM-Resolver	Poles not compatible with motor	Check that the correct number of resolver poles has been set in Pr 15/16/17.15 .
	12	SM-Universal Encoder Plus	Encoder type could not be identified during auto-configuration	Check encoder type can be auto-configured. Check encoder wiring. Enter parameters manually.
	13	SM-Universal Encoder Plus	Number of encoder turns read from the encoder during auto-configuration is not a power of 2	Select a different type of encoder.
	14	SM-Universal Encoder Plus	Number of comms bits defining the encoder position within a turn read from the encoder during auto-configuration is too large.	Select a different type of encoder. Faulty encoder.
15	SM-Universal Encoder Plus	The number of periods per revolution calculated from encoder data during auto-configuration is either <2 or >50,000.	Linear motor pole pitch / encoder ppr set up is incorrect or out of parameter range i.e. Pr 5.36 = 0 or Pr 21.31 = 0. Faulty encoder.	
16	SM-Universal Encoder Plus	The number of comms bits per period for a linear encoder exceeds 255.	Select a different type of encoder. Faulty encoder.	
74	All	Solutions Module has overheated	Check ambient temperature Check enclosure ventilation	

Trip	Diagnosis																																																																																								
SLX.Er	Solutions Module slot X trip: Solutions Module in slot X has detected a fault																																																																																								
202,207,212	<p>Automation (Applications) module category</p> <p>Check value in Pr 15/16/17.50. The following table lists the possible error codes for the SM-Applications and SM-Applications Lite. See the <i>Diagnostics</i> section in the relevant Solutions Module User Guide for more information.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Error Code</th> <th style="text-align: center;">Trip Description</th> </tr> </thead> <tbody> <tr><td style="text-align: center;">39</td><td>User program stack overflow</td></tr> <tr><td style="text-align: center;">40</td><td>Unknown error - please contact supplier</td></tr> <tr><td style="text-align: center;">41</td><td>Parameter does not exist</td></tr> <tr><td style="text-align: center;">42</td><td>Attempt to write to a read-only parameter</td></tr> <tr><td style="text-align: center;">43</td><td>Attempt to read from a write-only parameter</td></tr> <tr><td style="text-align: center;">44</td><td>Parameter value out of range</td></tr> <tr><td style="text-align: center;">45</td><td>Invalid synchronisation modes</td></tr> <tr><td style="text-align: center;">46</td><td>Unused</td></tr> <tr><td style="text-align: center;">48</td><td>RS485 not in user mode</td></tr> <tr><td style="text-align: center;">49</td><td>Invalid RS485 configuration</td></tr> <tr><td style="text-align: center;">50</td><td>Maths error - divide by zero or overflow</td></tr> <tr><td style="text-align: center;">51</td><td>Array index out of range</td></tr> <tr><td style="text-align: center;">52</td><td>Control word user trip</td></tr> <tr><td style="text-align: center;">53</td><td>DPL program incompatible with target</td></tr> <tr><td style="text-align: center;">54</td><td>DPL task overrun</td></tr> <tr><td style="text-align: center;">55</td><td>Unused</td></tr> <tr><td style="text-align: center;">56</td><td>Invalid timer unit configuration</td></tr> <tr><td style="text-align: center;">57</td><td>Function block does not exist</td></tr> <tr><td style="text-align: center;">58</td><td>Flash PLC Storage corrupt</td></tr> <tr><td style="text-align: center;">59</td><td>Drive rejected application module as Sync master</td></tr> <tr><td style="text-align: center;">60</td><td>CTNet hardware failure. Please contact your supplier</td></tr> <tr><td style="text-align: center;">61</td><td>CTNet invalid configuration</td></tr> <tr><td style="text-align: center;">62</td><td>CTNet invalid baud-rate</td></tr> <tr><td style="text-align: center;">63</td><td>CTNet invalid node ID</td></tr> <tr><td style="text-align: center;">64</td><td>Digital Output overload</td></tr> <tr><td style="text-align: center;">65</td><td>Invalid function block parameter(s)</td></tr> <tr><td style="text-align: center;">66</td><td>User heap too large</td></tr> <tr><td style="text-align: center;">67</td><td>RAM file does not exist or a non-RAM file id has been specified</td></tr> <tr><td style="text-align: center;">68</td><td>The RAM file specified is not associated to an array</td></tr> <tr><td style="text-align: center;">69</td><td>Failed to update drive parameter database cache in Flash memory</td></tr> <tr><td style="text-align: center;">70</td><td>User program downloaded while drive enabled</td></tr> <tr><td style="text-align: center;">71</td><td>Failed to change drive mode</td></tr> <tr><td style="text-align: center;">72</td><td>Invalid CTNet buffer operation</td></tr> <tr><td style="text-align: center;">73</td><td>Fast parameter initialisation failure</td></tr> <tr><td style="text-align: center;">74</td><td>Over-temperature</td></tr> <tr><td style="text-align: center;">75</td><td>Hardware unavailable</td></tr> <tr><td style="text-align: center;">76</td><td>Module type cannot be resolved. Module is not recognised.</td></tr> <tr><td style="text-align: center;">77</td><td>Inter-option module comms error with module in slot 1</td></tr> <tr><td style="text-align: center;">78</td><td>Inter-option module comms error with module in slot 2</td></tr> <tr><td style="text-align: center;">79</td><td>Inter-option module comms error with module in slot 3</td></tr> <tr><td style="text-align: center;">80</td><td>Inter-option module comms error with module unknown slot</td></tr> <tr><td style="text-align: center;">81</td><td>APC internal error</td></tr> <tr><td style="text-align: center;">82</td><td>Communications to drive faulty</td></tr> </tbody> </table>	Error Code	Trip Description	39	User program stack overflow	40	Unknown error - please contact supplier	41	Parameter does not exist	42	Attempt to write to a read-only parameter	43	Attempt to read from a write-only parameter	44	Parameter value out of range	45	Invalid synchronisation modes	46	Unused	48	RS485 not in user mode	49	Invalid RS485 configuration	50	Maths error - divide by zero or overflow	51	Array index out of range	52	Control word user trip	53	DPL program incompatible with target	54	DPL task overrun	55	Unused	56	Invalid timer unit configuration	57	Function block does not exist	58	Flash PLC Storage corrupt	59	Drive rejected application module as Sync master	60	CTNet hardware failure. Please contact your supplier	61	CTNet invalid configuration	62	CTNet invalid baud-rate	63	CTNet invalid node ID	64	Digital Output overload	65	Invalid function block parameter(s)	66	User heap too large	67	RAM file does not exist or a non-RAM file id has been specified	68	The RAM file specified is not associated to an array	69	Failed to update drive parameter database cache in Flash memory	70	User program downloaded while drive enabled	71	Failed to change drive mode	72	Invalid CTNet buffer operation	73	Fast parameter initialisation failure	74	Over-temperature	75	Hardware unavailable	76	Module type cannot be resolved. Module is not recognised.	77	Inter-option module comms error with module in slot 1	78	Inter-option module comms error with module in slot 2	79	Inter-option module comms error with module in slot 3	80	Inter-option module comms error with module unknown slot	81	APC internal error	82	Communications to drive faulty
	Error Code	Trip Description																																																																																							
	39	User program stack overflow																																																																																							
	40	Unknown error - please contact supplier																																																																																							
	41	Parameter does not exist																																																																																							
	42	Attempt to write to a read-only parameter																																																																																							
	43	Attempt to read from a write-only parameter																																																																																							
	44	Parameter value out of range																																																																																							
	45	Invalid synchronisation modes																																																																																							
	46	Unused																																																																																							
	48	RS485 not in user mode																																																																																							
	49	Invalid RS485 configuration																																																																																							
	50	Maths error - divide by zero or overflow																																																																																							
	51	Array index out of range																																																																																							
	52	Control word user trip																																																																																							
	53	DPL program incompatible with target																																																																																							
	54	DPL task overrun																																																																																							
	55	Unused																																																																																							
	56	Invalid timer unit configuration																																																																																							
	57	Function block does not exist																																																																																							
	58	Flash PLC Storage corrupt																																																																																							
	59	Drive rejected application module as Sync master																																																																																							
	60	CTNet hardware failure. Please contact your supplier																																																																																							
	61	CTNet invalid configuration																																																																																							
	62	CTNet invalid baud-rate																																																																																							
	63	CTNet invalid node ID																																																																																							
	64	Digital Output overload																																																																																							
	65	Invalid function block parameter(s)																																																																																							
	66	User heap too large																																																																																							
	67	RAM file does not exist or a non-RAM file id has been specified																																																																																							
	68	The RAM file specified is not associated to an array																																																																																							
	69	Failed to update drive parameter database cache in Flash memory																																																																																							
	70	User program downloaded while drive enabled																																																																																							
	71	Failed to change drive mode																																																																																							
	72	Invalid CTNet buffer operation																																																																																							
	73	Fast parameter initialisation failure																																																																																							
	74	Over-temperature																																																																																							
	75	Hardware unavailable																																																																																							
	76	Module type cannot be resolved. Module is not recognised.																																																																																							
	77	Inter-option module comms error with module in slot 1																																																																																							
78	Inter-option module comms error with module in slot 2																																																																																								
79	Inter-option module comms error with module in slot 3																																																																																								
80	Inter-option module comms error with module unknown slot																																																																																								
81	APC internal error																																																																																								
82	Communications to drive faulty																																																																																								

Trip	Diagnosis																																																																																								
SLX.Er	Solutions Module slot X trip: Solutions Module in slot X has detected a fault																																																																																								
202,207,212	Automation (I/O Expansion) module category Check value in Pr 15/16/17.50 . The following table lists the possible error codes for the SM-I/O Plus, SM-I/O Lite, SM-I/O Timer, SM-I/O PELV, SM-I/O 120V, SM-I/O 32 and SM-I/O 24V Protected. See the <i>Diagnostics</i> section in the relevant Solutions Module User Guide for more information.																																																																																								
	<table border="1"> <thead> <tr> <th>Error code</th> <th>Module</th> <th>Reason for fault</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>All</td> <td>No errors</td> </tr> <tr> <td>1</td> <td>All</td> <td>Digital output overload</td> </tr> <tr> <td rowspan="2">2</td> <td>SM-I/O Lite, SM-I/O Timer</td> <td>Analog input 1 current input too high (>22mA) or too low (<3mA)</td> </tr> <tr> <td>SM-I/O PELV, SM-I/O 24V Protected</td> <td>Digital input overload</td> </tr> <tr> <td rowspan="2">3</td> <td>SM-I/O PELV, SM-I/O 24V Protected</td> <td>Analog input 1 current input too low (<3mA)</td> </tr> <tr> <td>SM-I/O 24V Protected</td> <td>Communications error</td> </tr> <tr> <td>4</td> <td>SM-I/O PELV</td> <td>User power supply absent</td> </tr> <tr> <td>5</td> <td>SM-I/O Timer</td> <td>Real time clock communication error</td> </tr> <tr> <td>74</td> <td>All</td> <td>Module over temperature</td> </tr> </tbody> </table>	Error code	Module	Reason for fault	0	All	No errors	1	All	Digital output overload	2	SM-I/O Lite, SM-I/O Timer	Analog input 1 current input too high (>22mA) or too low (<3mA)	SM-I/O PELV, SM-I/O 24V Protected	Digital input overload	3	SM-I/O PELV, SM-I/O 24V Protected	Analog input 1 current input too low (<3mA)	SM-I/O 24V Protected	Communications error	4	SM-I/O PELV	User power supply absent	5	SM-I/O Timer	Real time clock communication error	74	All	Module over temperature																																																												
	Error code	Module	Reason for fault																																																																																						
	0	All	No errors																																																																																						
	1	All	Digital output overload																																																																																						
	2	SM-I/O Lite, SM-I/O Timer	Analog input 1 current input too high (>22mA) or too low (<3mA)																																																																																						
		SM-I/O PELV, SM-I/O 24V Protected	Digital input overload																																																																																						
	3	SM-I/O PELV, SM-I/O 24V Protected	Analog input 1 current input too low (<3mA)																																																																																						
		SM-I/O 24V Protected	Communications error																																																																																						
	4	SM-I/O PELV	User power supply absent																																																																																						
	5	SM-I/O Timer	Real time clock communication error																																																																																						
74	All	Module over temperature																																																																																							
SLX.Er	Solutions Module slot X trip: Solutions Module in slot X has detected a fault																																																																																								
202,207,212	Fieldbus module category Check value in Pr 15/16/17.50 . The following table lists the possible error codes for the Fieldbus modules. See the <i>Diagnostics</i> section in the relevant Solutions Module User Guide for more information.																																																																																								
	<table border="1"> <thead> <tr> <th>Error code</th> <th>Module</th> <th>Trip Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>All</td> <td>No trip</td> </tr> <tr> <td>1</td> <td>SM-EtherCAT</td> <td>No fieldbus mode has been selected</td> </tr> <tr> <td>2</td> <td>SM-EtherCAT</td> <td>Critical task over-run</td> </tr> <tr> <td>52</td> <td>SM-PROFIBUS-DP, SM-INTERBUS, SM-DeviceNet, SM-CANOpen</td> <td>User control word trip</td> </tr> <tr> <td>58</td> <td>SM-LON</td> <td>Incorrect non-volatile storage</td> </tr> <tr> <td>61</td> <td>SM-PROFIBUS-DP, SM-INTERBUS, SM-DeviceNet, SM-CANOpen, SM-SERCOS, SM-LON</td> <td>Configuration error</td> </tr> <tr> <td>62</td> <td>SM-EtherCAT</td> <td>Database initialization error</td> </tr> <tr> <td>63</td> <td>SM-EtherCAT</td> <td>File system initialization error</td> </tr> <tr> <td>64</td> <td>SM-DeviceNet</td> <td>Expected packet rate timeout</td> </tr> <tr> <td>65</td> <td>SM-PROFIBUS-DP, SM-INTERBUS, SM-DeviceNet, SM-CANOpen, SM-SERCOS, SM-LON</td> <td>Network loss</td> </tr> <tr> <td rowspan="2">66</td> <td>SM-PROFIBUS-DP</td> <td>Critical link failure</td> </tr> <tr> <td>SM-CAN, SM-DeviceNet, SM-CANOpen</td> <td>Bus off error</td> </tr> <tr> <td>69</td> <td>SM-CAN, SM-EtherCAT</td> <td>No acknowledgement</td> </tr> <tr> <td rowspan="2">70</td> <td>All (except SM-Ethernet and SM-LON)</td> <td>Flash transfer error</td> </tr> <tr> <td>SM-Ethernet, SM-LON</td> <td>No valid menu data available for the module from the drive</td> </tr> <tr> <td>74</td> <td>All</td> <td>Solutions module over temperature</td> </tr> <tr> <td>75</td> <td>SM-Ethernet, SM-EtherCAT</td> <td>The drive is not responding</td> </tr> <tr> <td>76</td> <td>SM-Ethernet, SM-EtherCAT</td> <td>The Modbus connection has timed out</td> </tr> <tr> <td>80</td> <td>All (except SM-SERCOS)</td> <td>Inter-option communications error</td> </tr> <tr> <td>81</td> <td>All (except SM-SERCOS)</td> <td>Communications error to slot 1</td> </tr> <tr> <td>82</td> <td>All (except SM-SERCOS)</td> <td>Communications error to slot 2</td> </tr> <tr> <td>83</td> <td>All (except SM-SERCOS)</td> <td>Communications error to slot 3</td> </tr> <tr> <td>84</td> <td>SM-Ethernet, SM-EtherCAT</td> <td>Memory allocation error</td> </tr> <tr> <td>85</td> <td>SM-Ethernet, SM-EtherCAT</td> <td>File system error</td> </tr> <tr> <td>86</td> <td>SM-Ethernet, SM-EtherCAT</td> <td>Configuration file error</td> </tr> <tr> <td>87</td> <td>SM-Ethernet</td> <td>Language file error</td> </tr> <tr> <td>97</td> <td>SM-Ethernet</td> <td>Timed event over-run</td> </tr> <tr> <td>98</td> <td>All</td> <td>Internal watchdog error</td> </tr> <tr> <td>99</td> <td>All</td> <td>Internal software error</td> </tr> </tbody> </table>	Error code	Module	Trip Description	0	All	No trip	1	SM-EtherCAT	No fieldbus mode has been selected	2	SM-EtherCAT	Critical task over-run	52	SM-PROFIBUS-DP, SM-INTERBUS, SM-DeviceNet, SM-CANOpen	User control word trip	58	SM-LON	Incorrect non-volatile storage	61	SM-PROFIBUS-DP, SM-INTERBUS, SM-DeviceNet, SM-CANOpen, SM-SERCOS, SM-LON	Configuration error	62	SM-EtherCAT	Database initialization error	63	SM-EtherCAT	File system initialization error	64	SM-DeviceNet	Expected packet rate timeout	65	SM-PROFIBUS-DP, SM-INTERBUS, SM-DeviceNet, SM-CANOpen, SM-SERCOS, SM-LON	Network loss	66	SM-PROFIBUS-DP	Critical link failure	SM-CAN, SM-DeviceNet, SM-CANOpen	Bus off error	69	SM-CAN, SM-EtherCAT	No acknowledgement	70	All (except SM-Ethernet and SM-LON)	Flash transfer error	SM-Ethernet, SM-LON	No valid menu data available for the module from the drive	74	All	Solutions module over temperature	75	SM-Ethernet, SM-EtherCAT	The drive is not responding	76	SM-Ethernet, SM-EtherCAT	The Modbus connection has timed out	80	All (except SM-SERCOS)	Inter-option communications error	81	All (except SM-SERCOS)	Communications error to slot 1	82	All (except SM-SERCOS)	Communications error to slot 2	83	All (except SM-SERCOS)	Communications error to slot 3	84	SM-Ethernet, SM-EtherCAT	Memory allocation error	85	SM-Ethernet, SM-EtherCAT	File system error	86	SM-Ethernet, SM-EtherCAT	Configuration file error	87	SM-Ethernet	Language file error	97	SM-Ethernet	Timed event over-run	98	All	Internal watchdog error	99	All	Internal software error
	Error code	Module	Trip Description																																																																																						
	0	All	No trip																																																																																						
	1	SM-EtherCAT	No fieldbus mode has been selected																																																																																						
	2	SM-EtherCAT	Critical task over-run																																																																																						
	52	SM-PROFIBUS-DP, SM-INTERBUS, SM-DeviceNet, SM-CANOpen	User control word trip																																																																																						
	58	SM-LON	Incorrect non-volatile storage																																																																																						
	61	SM-PROFIBUS-DP, SM-INTERBUS, SM-DeviceNet, SM-CANOpen, SM-SERCOS, SM-LON	Configuration error																																																																																						
	62	SM-EtherCAT	Database initialization error																																																																																						
	63	SM-EtherCAT	File system initialization error																																																																																						
	64	SM-DeviceNet	Expected packet rate timeout																																																																																						
	65	SM-PROFIBUS-DP, SM-INTERBUS, SM-DeviceNet, SM-CANOpen, SM-SERCOS, SM-LON	Network loss																																																																																						
	66	SM-PROFIBUS-DP	Critical link failure																																																																																						
		SM-CAN, SM-DeviceNet, SM-CANOpen	Bus off error																																																																																						
	69	SM-CAN, SM-EtherCAT	No acknowledgement																																																																																						
	70	All (except SM-Ethernet and SM-LON)	Flash transfer error																																																																																						
		SM-Ethernet, SM-LON	No valid menu data available for the module from the drive																																																																																						
	74	All	Solutions module over temperature																																																																																						
	75	SM-Ethernet, SM-EtherCAT	The drive is not responding																																																																																						
	76	SM-Ethernet, SM-EtherCAT	The Modbus connection has timed out																																																																																						
	80	All (except SM-SERCOS)	Inter-option communications error																																																																																						
	81	All (except SM-SERCOS)	Communications error to slot 1																																																																																						
	82	All (except SM-SERCOS)	Communications error to slot 2																																																																																						
	83	All (except SM-SERCOS)	Communications error to slot 3																																																																																						
	84	SM-Ethernet, SM-EtherCAT	Memory allocation error																																																																																						
	85	SM-Ethernet, SM-EtherCAT	File system error																																																																																						
	86	SM-Ethernet, SM-EtherCAT	Configuration file error																																																																																						
	87	SM-Ethernet	Language file error																																																																																						
	97	SM-Ethernet	Timed event over-run																																																																																						
	98	All	Internal watchdog error																																																																																						
	99	All	Internal software error																																																																																						

Trip	Diagnosis
SLX.HF	Solutions Module slot X trip: Solutions Module X hardware fault
200,205,210	Ensure Solutions Module is installed correctly Return Solutions Module to supplier
SLX.nF	Solutions Module slot X trip: Solutions Module has been removed
203,208,213	Ensure Solutions Module is installed correctly Reinstall Solutions Module Save parameters and reset drive
SL.rtd	Solutions Module trip: Drive mode has changed and Solutions Module parameter routing is now incorrect
215	Press reset. If the trip persists, contact the supplier of the drive.
SLX.tO	Solutions Module slot X trip: Solutions Module watchdog timeout
201,206,211	Press reset. If the trip persists, contact the supplier of the drive.
t038	User trip defined in 2nd processor Solutions Module code
38	SM-Applications program must be interrogated to find the cause of this trip
t040 to t089	User trip defined in 2nd processor Solutions Module code
40 to 89	SM-Applications program must be interrogated to find the cause of this trip t070 to t080 refer to section 12.2 <i>Elevator specific diagnostics</i> on page 149
t099	User trip defined in 2nd processor Solutions Module code
99	SM-Applications program must be interrogated to find the cause of this trip
t101	User trip defined in 2nd processor Solutions Module code
101	SM-Applications program must be interrogated to find the cause of this trip
t112 to t160	User trip defined in 2nd processor Solutions Module code
112 to 160	SM-Applications program must be interrogated to find the cause of this trip
t168 to t174	User trip defined in 2nd processor Solutions Module code
168 to 174	SM-Applications program must be interrogated to find the cause of this trip
t216	User trip defined in 2nd processor Solutions Module code
216	SM-Applications program must be interrogated to find the cause of this trip
th	Motor thermistor trip
24	Check motor temperature Check thermistor continuity Set Pr 7.15 = VOLT and reset the drive to disable this function
thS	Motor thermistor short circuit
25	Check motor thermistor wiring Replace motor / motor thermistor Set Pr 7.15 = VOLT and reset the drive to disable this function
tunE*	Autotune stopped before completion
18	The drive has tripped out during the autotune The red stop key has been pressed during the autotune The SAFE TORQUE OFF (SECURE DISABLE) signal (terminal 31) was active during the autotune procedure
tunE1*	The position feedback did not change or required speed could not be reached during the inertia test (see Pr 5.12)
11	Ensure the motor is free to turn i.e. brake was released Ensure Pr 3.26 and Pr 3.38 are set correctly Check feedback device wiring is correct Check encoder coupling to motor
tunE2*	Position feedback direction incorrect or motor could not be stopped during the inertia test (see Pr 5.12)
12	Check motor cable wiring is correct Check feedback device wiring is correct Swap any two motor phases
tunE3*	Drive encoder commutation signals connected incorrectly or measured inertia out of range (see Pr 5.12)
13	Check motor cable wiring is correct Check feedback device U,V and W commutation signal wiring is correct

Trip	Diagnosis												
tunE4*	Drive encoder U commutation signal fail during an autotune												
14	Check feedback device U phase commutation wires continuity Replace encoder												
tunE5*	Drive encoder V commutation signal fail during an autotune												
15	Check feedback device V phase commutation wires continuity Replace encoder												
tunE6*	Drive encoder W commutation signal fail during an autotune												
16	Check feedback device W phase commutation wires continuity Replace encoder												
tunE7*	Motor number of poles set incorrectly												
17	Check lines per revolution for feedback device Check the number of poles in Pr 5.11 is set correctly												
Unid.P	Power module unidentified trip												
110	Check all interconnecting cables between power modules Ensure cables are routed away from electrical noise sources												
UP ACC	Onboard PLC program: cannot access Onboard PLC program file on drive												
98	Disable drive - write access is not allowed when the drive is enabled Another source is already accessing Onboard PLC program - retry once other action is complete												
UP div0	Onboard PLC program attempted divide by zero												
90	Check program												
UP OFL	Onboard PLC program variables and function block calls using more than the allowed RAM space (stack overflow)												
95	Check program												
UP ovr	Onboard PLC program attempted out of range parameter write												
94	Check program												
UP PAr	Onboard PLC program attempted access to a non-existent parameter												
91	Check program												
UP ro	Onboard PLC program attempted write to a read-only parameter												
92	Check program												
UP So	Onboard PLC program attempted read of a write-only parameter												
93	Check program												
UP udF	Onboard PLC program un-defined trip												
97	Check program												
UP uSEr	Onboard PLC program requested a trip												
96	Check program												
UV	DC bus under voltage threshold reached												
1	Check AC supply voltage level <table border="1"> <thead> <tr> <th>Drive voltage rating (Vac)</th> <th>Under voltage threshold (Vdc)</th> <th>UV reset voltage (Vdc)</th> </tr> </thead> <tbody> <tr> <td>200</td> <td>175</td> <td>215V</td> </tr> <tr> <td>400</td> <td>330</td> <td>425V</td> </tr> <tr> <td>575 & 690</td> <td>435</td> <td>590V</td> </tr> </tbody> </table>	Drive voltage rating (Vac)	Under voltage threshold (Vdc)	UV reset voltage (Vdc)	200	175	215V	400	330	425V	575 & 690	435	590V
Drive voltage rating (Vac)	Under voltage threshold (Vdc)	UV reset voltage (Vdc)											
200	175	215V											
400	330	425V											
575 & 690	435	590V											

*If a tunE through to a tunE 7 trip occurs, then after the drive is reset the drive cannot be made to run unless it is disabled via the Secure Disable input (terminal 31), drive enable parameter (Pr 6.15) or the control word (Pr 6.42 and Pr 6.43).

Table 12-4 Serial communications look-up table

No.	Trip	No.	Trip	No.	Trip
1	UV	40 to 89	t040 to t089	182	C.Err
2	OV	90	UP div0	183	C.dAt
3	OI.AC	91	UP PAr	184	C.FULL
4	OI.br	92	UP ro	185	C.Acc
5	PS	93	UP So	186	C.rtg
6	Et	94	UP ovr	187	C.TyP
7	O.SPd	95	UP OFL	188	C.cPr
8	PS.10V	96	UP uSEr	189	Enc1
9	PS.24V	97	UP udF	190	Enc2
10	br.th	98	UP ACC	191	Enc3
11	tunE1	99	t099	192	Enc4
12	tunE2	100		193	Enc5
13	tunE3	101	t101	194	Enc6
14	tunE4	102	Oht4.P	195	Enc7
15	tunE5	103	Oibr.P	196	Enc8
16	tunE6	104	OIAC.P	197	Enc9
17	tunE7	105	Oht2.P	198	Enc10
18	tunE	106	OV.P	199	DESt
19	lt.br	107	PH.P	200	SL1.HF
20	lt.AC	108	PS.P	201	SL1.tO
21	O.ht1	109	OldC.P	202	SL1.Er
22	O.ht2	110	Unid.P	203	SL1.nF
23	O.CtL	111	ConF.P	204	SL1.dF
24	th	112 to 160	t112 to t160	205	SL2.HF
25	thS	161	Enc11	206	SL2.tO
26	O.Ld1	162	Enc12	207	SL2.Er
27	O.ht3	163	Enc13	208	SL2.nF
28	cL2	164	Enc14	209	SL2.dF
29	cL3	165	Enc15	210	SL3.HF
30	SCL	166	Enc16	211	SL3.tO
31	EEF	167	Enc17	212	SL3.Er
32	PH	168 to 174	t168 to t174	213	SL3.nF
33	rS	175	C.Prod	214	SL3.dF
34	PAd	176	EnP.Er	215	SL.rtd
35	CL.bit	177	C.boot	216	t216
36	SAVE.Er	178	C.bUSY	217 to 232	HF17 to HF32
37	PSAVE.Er	179	C.Chg		
38	t038	180	C.OPtn		
39	L.SYnC	181	C.RdO		

The trips can be grouped into the following categories. It should be noted that a trip can only occur when the drive is not tripped or is already tripped but with a trip with a lower priority number.

Table 12-5 Trip categories

Priority	Category	Trips	Comments
1	Hardware faults	HF01 to HF16	These indicate fatal problems and cannot be reset. The drive is inactive after one of these trips and the display shows HFxx . The Drive Healthy relay opens and the serial comms will not function.
2	Non-resetable trips	HF17 to HF32, SL1.HF, SL2.HF, SL3.HF	Cannot be reset. Requires the drive to be powered down.
3	EEF trip	EEF	Cannot be reset unless a code to load defaults is first entered in Pr xx.00 or Pr 11.43 .
4	SMARTCARD trips	C.boot, C.Busy, C.Chg, C.OPtn, C.RdO, C.Err, C.dat, C.FULL, C.Acc, C.rtg, C.TyP, C.cpr	Can be reset after 1.0s SMARTCARD trips have priority 5 during power-up
4	Encoder power supply trips	PS.24V, EnC1	Can be reset after 1.0s These trips can only override the following priority 5 trips: EnC2 to EnC8 or Enc11 to Enc17
5	Autotune	tunE, tunE1 to tunE7	Can be reset after 1.0s, but the drive cannot be made to run unless it is disabled via the Secure Disable input (terminal 31), <i>Drive enable</i> (Pr 6.15) or the <i>Control word</i> (Pr 6.42 and Pr 6.43).
5	Normal trips with extended reset	OI.AC, OI.Br, OIAC.P, OIBr.P, OldC.P	Can be reset after 10.0s
5	Normal trips	All other trips not included in this table	Can be reset after 1.0s
5	Non-important trips	th, thS, Old1, cL2, cL3, SCL	If Pr 10.37 is 1 or 3 the drive will stop before tripping
5	Phase loss	PH	The drive attempts to stop before tripping
5	Drive over-heat based on thermal model	O.ht3	The drive attempts to stop before tripping, but if it does not stop within 10s the drive will automatically trip
6	Self-resetting trips	UV	Under voltage trip cannot be reset by the user, but is automatically reset by the drive when the supply voltage is with specification

Although the UV trip operates in a similar way to all other trips, all drive functions can still operate but the drive cannot be enabled. The following differences apply to the UV trip:

1. Power-down save user parameters are saved when UV trip is activated except when the main high voltage supply is not active (i.e. operating in Low Voltage DC Supply Mode, Pr **6.44** = 1).
2. The UV trip is self-resetting when the DC bus voltage rises above the drive restart voltage level. If another trip is active instead of UV at this point, the trip is not reset.
3. The drive can change between using the main high voltage supply and low voltage DC supply only when the drive is in the under voltage condition (Pr **10.16** = 1). The UV trip can only be seen as active if another trip is not active in the under voltage condition.
4. When the drive is first powered up a UV trip is initiated if the supply voltage is below the restart voltage level and another trip is not active. This does not cause save power down save parameters to be saved at this point.

12.5 Alarm indications

In any mode an alarm flashes alternately with the data displayed on the 2nd row when one of the following conditions occur. If action is not taken to eliminate any alarm except "Autotune" the drive may eventually trip.

Table 12-6 Alarm indications

Lower display	Description
br.rS	Braking resistor overload
Braking resistor I ² t accumulator (Pr 10.39) in the drive has reached 75.0% of the value at which the drive will trip and the braking IGBT is active.	
Hot	Heatsink or control board or inverter IGBT over temperature alarms are active
<ul style="list-style-type: none"> • The drive heatsink temperature has reached a threshold and the drive will trip O.ht2 if the temperature continues to rise (see the O.ht2 trip). Or <ul style="list-style-type: none"> • The ambient temperature around the control PCB is approaching the over temperature threshold (see the O.CtL trip). 	
OVLd	Motor overload
The motor I ² t accumulator in the drive has reached 75% of the value at which the drive will be tripped and the load on the drive is >100%	

12.6 Status indications

Table 12-7 Status indications

Upper display	Description	Drive output stage
ACt	Regeneration mode active	Enabled
	The regen unit is enabled and synchronised to the supply.	
ACUU	AC Supply loss	Enabled
	The drive has detected that the AC supply has been lost and is attempting to maintain the DC bus voltage by decelerating the motor.	
*Auto tunE	Autotune in progress	Enabled
	The autotune procedure has been initialised. *'Auto' and 'tunE' will flash alternatively on the display.	
dc	DC applied to the motor	Enabled
	The drive is applying DC injection braking.	
dEC	Decelerating	Enabled
	The drive is decelerating the motor.	
inh	Inhibit	Disabled
	The drive is inhibited and cannot be run. The drive enable signal is not applied to terminal 31 or Pr 6.15 is set to 0.	
PLC	Onboard PLC program is running	Not applicable
	An Onboard PLC program is fitted and running. The lower display will flash 'PLC' once every 10s.	
POS	Positioning	Enabled
	The drive is positioning/orientating the motor shaft.	
rdY	Ready	Disabled
	The drive is ready to be run.	
run	Running	Enabled
	The drive is running.	
SCAn	Scanning	Enabled
	Regen> The drive is enabled and is synchronising to the line.	
StoP	Stop or holding zero speed	Enabled
	The drive is holding zero speed. Regen> The drive is enabled but the AC voltage is too low, or the DC bus voltage is still rising or falling.	
triP	Trip condition	Disabled
	The drive has tripped and is no longer controlling the motor. The trip code appears on the lower display.	

Table 12-8 Solutions Module and SMARTCARD status indications at power-up

Lower display	Description
boot	A parameter set is being transferred from the SMARTCARD to the drive during power-up.
cArd	The drive is writing a parameter set to the SMARTCARD during power-up. For further information, please refer to section <i>Auto saving parameter changes</i> (Pr 11.42 = Auto (3)).
IoAding	The drive is writing information to a Solutions Module.

12.7 Displaying the trip history

The drive retains a log of the last 10 trips that have occurred in Pr 10.20 to Pr 10.29 and the corresponding multi-module drive module number (Pr 6.49 = 1) or the trip time (Pr 6.49 = 0) for each trip in Pr 10.41 to Pr 10.51. The time of the trip is recorded from the powered-up clock (if Pr 6.28 = 0) or from the run time clock (if Pr 6.28 = 1).

Pr 10.20 is the most recent trip, or the current trip if the drive is in a trip condition (with the module number or trip time stored in Pr 10.41 and Pr 10.42). Pr 10.29 is the oldest trip (with the module number or trip time stored in Pr 10.51). Each time a new trip occurs, all the parameters move down one, such that the current trip (and time) is stored in Pr 10.20 (and Pr 10.41 to Pr 10.42) and the oldest trip (and time) is lost out of the bottom of the log.

If any parameter between Pr 10.20 and Pr 10.29 inclusive is read by serial communications, then the trip number in Table 12.4 *Unidrive SP trip codes* on page 153 is the value transmitted.

Index

Numerics

24V external power supply	47
7 segment LED displays	60

A

Absolute feedback devices	20
Access level	68
Acoustic noise	27
Additional distance control	26
Adjusting parameters	5
Advanced door opening	43
Advanced menus	65
Alarm	167
Alarm indications	66, 167
Analog I/O	59
Autotune	131

B

Batteries	47
Binary speed selection	55
Blocked elevator releasing	45
Brake control	41
Brake control output	92
Brake controller	88
Brake opening	27

C

Cable shield requirements	17
Cautions	5
Commissioning	131
Compliance	5
Constant gains	36
Constant stopping distance	31
Contacting opening	134
Control parameters	76
Control terminal status	56
Control terminals	53
Creep speed	55, 117
Creep-to-floor positioning	24
CTScope	145
CTSoft	145
Current limits	27
Current loop	35, 121
Current loop filter	108
Current loop filters	35
Current loop gains	132
Cycle time	24, 29

D

De-bouncing	44
Deceleration and stopping distances	29
Deceleration distance	24
Deceleration distances	86
Deceleration rate	101
Default speed selection	53
Defaults (restoring parameter)	68
Demagnetization time	88
Destination parameters	68
Diagnostic parameters	78
Diagnostics	149
Digital I/O	57
Direction	33
Direction inputs	54, 94
Direction of least load	33
Direct-to-floor	118
Direct-to-floor positioning	26
Display	60
Display messages	66
Distance error	83, 103
Distance parameters	77
Drive enable	44

E

Elevator parameters	70, 119
Elevator Solution Software	9
Elevator Solution Software features	23
Elevator start time	32
Elevator system	8
Elevator-SP	146
EMC bracket	18
EMC compliance	18
Emergency evacuation control	52
Emergency evacuation operation	46
EN81-1	43
Encoder connections	16
Encoder connector details	17
Encoder initialization	20
Encoder types	16
Error detection	149
Evacuation	33
Evacuation control	129

F

F menu	62, 78
F Menu, single line descriptions	79
Fast disable	45, 134
Fast start	112
Fast stop	31, 127
Feedback cable	17
Feedback cable connections	18
First start	134
Floor distance is less than 0.7 m	31
Floor sensor correction	28, 99, 118

G		N	
Gain selections	35	Negative logic	15, 53
Gain transition times	39	New parameter-values	61
Gains	113	Nominal elevator rpm	71
Gear ratio	71	Nominal elevator speed	32
Getting started	60	Notes	5
Ground connection	18	O	
Grounding bracket	19	Operating mode	67
Grounding clamp	18	Operating mode (changing)	66
H		Operational rpm configuration	32, 107
Hard stop	29, 30	Optimize control	35
Help text	62	Over voltages	134
I		Overload	34
Identification	11	P	
Inertia compensation	34	Parameter access	68
Initial set-up	131	Parameter access level	68
Installation of Solutions Modules	14	Parameter defaults	68
Installation parameters	75, 147	Parameter security	68
J		Parameter structure	64
Jerk acceleration to Travel	112	PC tools	145
Jerks	101	Phase angle	133
K		Phase loss	49
Ke value	49	Phase loss detection	111
Keypad and display - fitting / removal 14, 15, 17, 22, 24, 27, 28, 29, 30, 34, 35, 49, 53, 54, 72, 78, 127, 152		Position accuracy	26
Keypad identification	13	Positioning	36
Keypad operation	60	Positioning profiles	22
L		Positive logic	15
LCD display	60	Priority speed selection	55
Load cell compensation	34	R	
Load measurement	33, 109	Reference parameter selected	84
Low voltage DC backup operation	46	Resolver feedback	20
M		Ride comfort during the start	28
Magnetization current	116	Ride quality	101
Magnetization current threshold	25	Rollback	27
Magnetizing current threshold	88	Roping	117
Mains loss	49	Rotating autotune	131
Menu 0	64		
Menu 0 default	74		
Menu 0 parameters	73		
Menu 18 parameters	81		
Menu 19 parameters	97		
Menu structure	61, 62, 64		
Minimum start up voltage	47		
Motor contactor	108, 120		
Motor contactor monitor	110		
Motor contactors	43		
Motor magnetized	43		
Motor rated speed	135		
Motor thermistor	109		
Motor thermistor input	54		

S

SAFE TORQUE OFF (SECURE DISABLE)	43
Safety information	5
Saving parameters	67
Security code	68
Serial communications interface	68
Serial communications look-up table	166
Set-up and commissioning tools	10
Sheave diameter	71
Single output motor contactor	43
Slip	135
SM-Applications	8
SM-Applications Lite	8
SMARTCARD	60, 66
SMARTCARD operation	139
SMARTCARD status	144
SMARTCARD trips	143
Software version	115
Solution Software	115
Solution Software status	72
Solutions module	8
Solutions Module slots	14
SP Solutions Modules	12
Speed error	83, 105
Speed loop	35, 90
Speed thresholds	88
Start	36
Start gains	28
Start locking	27, 100
Starting issues	34
Static autotune	131
Stator resistance	96, 128
Status	66, 168
Status indications	66, 168
Stiction	27
Switching the motor contactor	43

T

Travel	36
Trip categories	167
Trip history	168
Two output motor contactors	43

U

Unidrive SP trip codes	153
UPS power rating	119
UPS protection	51
UPS system	51
User security	68

V

Variable gains	125
Variable gains 1	36
Variable gains 2	37
Variable stator resistance	40, 135
Velocity profile for creep-to-floor positioning	25

Z

Zero output motor contactors	43
------------------------------------	----



0471-0073-02